


INSTALLATION, OPERATION, AND MAINTENANCE MANUAL



Water Heater Models
CTDW 1250
CTDW 1500







A WARNING

WARNING: If the information in these instructions is not followed exactly, a fire or explosion may result causing property damage, personal injury or death.

A DANGER

Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.

WHAT TO DO IF YOU SMELL GAS

- Do not try to light any appliance.
- Do not touch any electrical switch; do not use any phone in your building.
- Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
- If you cannot reach your gas supplier, call the fire department.

Installation and service must be performed by a qualified installer, service agency or the gas supplier.

Model:	Serial Number:
Installation Date:	System Type:
Heating Contractor:	Phone/Email:
Address:	

Table of Contents

I.	Hazard Definitions	4
II.	Read Before Proceeding	5
-	A. Local Codes	5
E	B. Warranty	5
	C. Shipment Damage	5
	D. Connecting Gas Supply Line	5
Е	E. Appliance Operation	5
F	F. Gas Leakage (If you detect or smell gas)	5
	G. Maintenance	5
Н	H. Product Identification Label	5
- 1	I. Factory Test and Inspections	6
J	J. Disclaimers and Local Codes	6
III.	. Product Rating, Specifications, and Dimensional Data	7
IV.	Citadel Water Heater Component Identification	10
V.	Unpacking The Citadel	13
	A. Unpacking and Inspection	13
Е	B. Check Equipment	13
	C. Installation and Operation Manual	13
VI.	. Pre-Installation and Mounting	14
	A. General	14
Е	B. Appliance Mounting	15
	C. Clearances	16
	D. Clearances (French)	16
Е	E. Closet and Alcove installation	16
VII	I. Venting	17
-	A. General Venting Guidelines	17
E	B. Venting Design Requirements	17
(C. Field Installation	18
	D. General Termination	21
	E. Vent and Combustion Air Terminations	26
F	F. Multiple Appliance Terminations	28
	G. Terminal Installation	28
	H. Polypropylene Venting	30
	I. Optional Room Air for Combustion	30
J	J. Removing Existing Appliance	33
k	K. Special Installation Requirements for Massachusetts	34
VII	II. Condensate Disposal	35
	A. General	35
E	B. Condensate trap installation	35
(C. Condensate Neutralizer Installation	36
	D. Common Condensate pump/Sump	36
IX.	. Water Piping	37
	A. General Piping Guidelines	37
E	B. Factory Supplied Outlet Water Manifold	37

2

Table of Contents

C.	1 0 1	38
D.	. Scalding	39
E.	Water Quality	40
F.	Temperature Rise and Heat Exchanger Head Loss	41
G.	. Pump Selection	42
<u>X.</u>	Water Piping Diagrams	43
XI.	Gas Piping	49
A.	·	49
XII.	Electrical	52
Α.	. General.	52
B.	Power Requirements	52
C.	Appliance Wiring	53
D.	. Line voltage connections	53
E.	Low voltage connections	53
F.	System and Circulation Pump Wiring	53
XIII.	System Start-up	58
Α.	. Check System Setup	58
В.	Start the Citadel	58
C.	Combustion Air/Fuel Adjustment	60
D.	. Field Conversion of Gas Type	61
E.	Pump Control	62
F.	Check Thermostat Operation	62
G.	. Adjust Supply Water Temperature	62
Н.	. Testing of Controls and Safety Devices	62
XIV.	Service and Maintenance	63
A.	. General Maintenance	64
В.	Monthly Inspection	64
C.	Annual Inspections and Service	64
D.	. Restarting after Prolong Shutdown	67
E.	Troubleshooting	67
APP	ENDIX A: Tables	68
APP	ENDIX B: Figures	69
APP	ENDIX C: Default Light-off and Modulation Rates	70

I. Hazard Definitions

The following terms are used throughout this manual to bring attention to the presence of hazards of various risk levels, or to important information concerning product life.

It is critical all personnel read and adhere to all information contained in DANGER, WARNING, and CAUTIONS. All DANGERS, WARNINGS, and CAUTIONS are for reference and guidance purpose, and, therefore, do not substitute for strict adherence to applicable jurisdictional and professional codes and regulations.

A DANGER

Indicates an imminently hazardous situation which, if not avoided, will result in death, serious injury or substantial property damage.

A WARNING

Indicates a potentially hazardous situation which, if not avoided, could result in death, serious injury, or substantial property damage.

A CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in moderate or minor injury, or property damage.

NOTICE

Indicates special instructions on installation, operation, or maintenance which are important but not related to personal injury hazards.

II. Read Before Proceeding

A. Local Codes

- This unit shall be installed in accordance with those installation regulations enforced in the area where the installation is to be made. These regulations shall be carefully followed in all cases. Authorities having jurisdiction shall be consulted prior to installation.
- 2. This unit must be installed and serviced by a licensed electrician or certified gas supplier.
- 3. The City of New York requires a Licensed Master Plumber to supervise the installation of this product.
- 4. The Commonwealth of Massachusetts requires this product to be installed by a Licensed Plumber or Gas Fitter.

B. Warranty

- 1. This product has a limited warranty, a copy of which is shipped with the unit. It is the responsibility of the installing contractor to ensure all controls are correctly installed and are operating properly.
- 2. Factory warranty does not apply to units improperly installed or improperly operated.
- 3. Heat exchanger failure due to lime (scale) buildup in the heat exchanger is not covered under the manufacturer's warranty.
- 4. It is the responsibility of the customer to ensure water hardness level and flow rate conform to the levels listed in Table 23.

C. Shipment Damage

- 1. Upon receiving the unit, inspect for signs of shipping damages. If the unit has been hit or otherwise mishandled, immediately notify the carrier.
- 2. Verify total number of factory supplied items as per the packing slip with received parts.

D. Connecting Gas Supply Line

1. Connect supply gas line to the ground joint union inside the jacket of the appliance.

A DANGER

Failure to prevent the gas line from turning could damage the gas train components on the appliance (gas valve, blower, etc.).

⚠ DANGER

This appliance MUST NOT be installed in any location where gasoline or flammable vapors are likely to be present or, in an environment that contains corrosive contaminants (see Table 4).

Do not block or restrict in any way the flow of combustion or ventilation air from or to the appliance.

Do not use this appliance if any part has been under water. Any appliance that has been under water must be replaced. Water damage to the unit can be extensive and present numerous safety hazards.

E. Gas Leakage (If you detect or smell gas...)

A DANGER

- 1. Do not try to light any appliance.
- 2. Do not touch any electrical switch; do not use any phone in the building.
- 3. Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instruction.
- 4. If you cannot reach your gas supplier, call the fire department.

F. Maintenance

- To avoid electrical shock, ensure all electrical connections are disconnected before attempting installation or service of electrical components or connections.
- 2. Lockout all electrical boxes with padlock once power is turned off.
- 3. To prevent severe burns, allow the appliance to cool before performing maintenance.

G. Product Identification Label

- 1. A nameplate, in accordance with the ASME code Section IV, is permanently attached to the heat exchanger.
- 2. To access the nameplate, remove front jacket panel from the appliance.

II. Read Before Proceeding (continued)

H. Factory Test and Inspections

- Prior to shipment, final air-fuel adjustments are performed by factory trained service personnel on each appliance. The factory emissions report is posted on the back of the front jacket panel as a reference for troubleshooting and maintenance.
- In addition, the following tests and inspections are performed to ensure the appliance meets our highest safety and performance standards:

Operating test
Construction inspection
Electrical components inspection
Crating inspection.

I. Disclaimers and Local Codes

- Installation must conform to the requirements of the authority having jurisdiction. In the absence of such requirements, installation must conform to the National Fuel Gas Code, NFPA 54/ANSI Z223.1, and/ or CSA B149.1 Natural Gas and Propane Code. Where required by the authority having jurisdiction, the installation must conform to the Standard for Controls and Safety Devices for Automatically Fired Boilers, ANSI/ ASME CSD-1.
- Installation, start-up, and maintenance of this equipment can be hazardous and requires trained, qualified installers and service personnel. Do not install, operate, service or repair any components of this equipment unless you are qualified and fully understand all requirements and procedures.
- This instruction manual is an integral part of the product and must be retained by the person in charge of the appliance operation, service, and maintenance.

A WARNING

This product can expose you to chemicals, including chromium, which are known to the state of California to cause cancer and birth defects or other reproductive harm. For more information go to: www. P65Warnings.ca.gov.

A DANGER

Should overheating occur or the gas supply fail to shut off, turn off the manual gas control valve to the appliance.

III. Product Rating, Specifications, and Dimensional Data

Citadel Water Heaters are condensing, high-efficiency, gasfired appliances designed for use in direct domestic hot water heating systems where supply water temperature does not exceed 190°F. These water heaters have special coil type stainless steel heat exchangers, constructed, tested and stamped per Section IV of the ASME Boiler and Pressure Vessel Code, which provide maximum heat transfer and simultaneous protection against flue gas product corrosion. These water heaters are **not** designed for use in space heating systems or swimming pool heating systems.

Table 1: Citadel Water Heater Ratings

CTDW	Output Recovery Rate		Output Recovery Rate C www.anridreecory.org		CERTIFIED® www.ahridirectory.org	Combustion Efficiency	
Model	Min.	Max.	(МВН)	(GPH)	Thermal Efficiency (%)	(%)	
1250	250	1250	1225	1485	98	97	
1500	300	1500	1470	1782	98	97	

¹ Ratings shown are for installations at sea level and elevations up to 2000 ft. at minimum vent length. For high altitude installations above 2000 ft. consult factory.

Table 2: Citadel Water Heater Specifications

Specification	CTDW Models					
Specification	1250	1500				
Fuel	NG or LP	NG or LP				
Max. Water Temp. (°F)¹	210	210				
Max. Working Pres. (psi)	160	160				
Standard Temperature & Pressure Relief Valve (psi)	150	150				
Water Vol. (gal)	12	13.9				
Heat Transfer Area (sq. ft.)	100	120				
Approx. Shipping Weight (lb)	922	1217				
¹ Appliance will go into hard lo	ckout if tempe	rature				

¹Appliance will go into hard lockout if temperature exceeds 200 °F.

III. Product Rating, Specifications, and Dimensional Data (continued)

Table 3: Product Dimensions

Dimensions	nsions CTDW Model					
(in.)	1250	1500				
Α	45-1/2	66-1/8				
В	54	72-1/2				
С	55-7/8	76-1/2				
D	34-1/4	34-1/4				
E	13-3/8	13-3/8				
F	42-3/4	42-3/4				
G	36-1/8	36-1/8				
Н	3	3-1/4				
I	6-7/8	18-7/8				
J	10-3/8	10-3/8				
K	8-3/4	6-5/8				
L	40-1/2	40-1/2				
М	44-3/8	44-3/8				
N	2-1/8	2-1/8				
0	9-3/4	9-3/4				
Р	13-3/8	13-3/8				
Q	6-1/8	6-1/8				
R	11-1/8	11-1/8				
S	23-1/4	23-1/4				
Т	32-1/8	32-1/8				
Gas Inlet	1	1.25				
Outlet Pipe	3	3				
Inlet Pipe	2-1/2	2-1/2				
Air Intake	8	8				
Vent Outlet	8	8				
Condensate Drain	1	1				
Drain Line	3/4	3/4				
X-COG	18-3/8	18-3/8				
Y-COG	17-3/4	21-5/8				
Z-COG	21	22-5/8				

III. Product Rating, Specifications, and Dimensional Data (continued)




Figure 1: Citadel water heater dimensions

IV. Citadel Water Heater Component Identification

1. Communication Interface (Concert[™] Control)

The Citadel series is equipped with the Concert[™] Control display which provides easy access for viewing and adjusting operational parameters and alarms/lockouts, and monitoring historical performance characteristics.

2. Main appliance control

It receives and processes input signals from safety switches and sensors to modulate the burner firing rate.

Control box

The control box is designed to allow easy access to safety components and PCB boards for service and troubleshooting purposes.

4. ON/OFF switch

Initiates or interrupts the power to the burner.

5. Main gas valve

It regulates the flow of gas into the pre-mix burner by sensing negative pressure from the blower.

6. Blower

The blower is designed for pre-mix application and delivers combustion air and gas to the burner at a desired ratio over the modulation range.

7. Bluejet^R Burner

The high efficiency, low NOx Bluejet^R Burner is mounted on the burner door with eight M4 x 10 screws.

8. Ignition electrode

The ionization electrode provides electrical spark for ignition. The igniter assembly is installed on the burner door with two M4 x 10 torx screws.

9. Flame observation port

A ¾ inch diameter quartz sight glass provides a means of visual inspection of the burner flame condition.

10. Thermal fuse

If the temperature at the burner door reaches over $320\,^{\circ}$ F, the thermal fuse will interrupt power to the burner. Used to detect dangerous flame blow back and burner door insulation failure.

11. High gas pressure switch

The high gas pressure switch monitors supply gas pressure and shuts off the electrical control circuit when pressure rises above the setpoint (see Table 31).

12. Low gas pressure switch

The low gas pressure switch monitors supply gas pressure and shuts off the electrical control circuit in the event a low gas pressure condition occurs (see Table 31).

13. Outlet/Hot water connection

Outlet manifold with Victaulic grooved connection that delivers hot water to the storage tank. Refer to Table 3 for model specific water pipe connection sizes.

14. Water flow switch

In the event of insufficient water flow the appliance will be shut down by the action of the flow switch. Refer to Table 24 for minimum and maximum water flow rates.

15. Gas supply line

Provides a means of connection for incoming gas line to the gas train assembly. See Table 31 for model specific pipe sizes.

16. Inlet/Cold water connection

Inlet connection that returns water from the tank to the water heater. Refer to Table 3 for model specific pipe connection sizes.

17. Hot/outlet water temperature sensor

Dual element temperature sensor for high limit control. Main control adjusts the firing rate of the burner based on the tank or outlet water temperature and its setpoint.

18. Cold/Inlet water temperature sensor

Used for monitoring the inlet water temperature and temperature rise.

19. Low water cut off probe and reset box

The unit comes with an integrated Low Water Cut Off (LWCO) probe and rest box. The LWCO safeguards the heat exchanger from inadequate water level. The LWCO has a manual reset button.

20. Temperature and pressure gauge

Provides real time outlet water temperature and pressure readings.

21. Temperature and pressure safety relief valve

Protects the heat exchanger from over pressure and over temperature conditions. The Citadel water heater comes standard with a 150 PSI temperature and pressure relief valve.

22. Condensate drain trap

Serves to discharge condensate from the heat exchanger while preventing flue gases from escaping through the drain line.

23. Minimum combustion air proving switch

Ensures adequate combustion air is supplied to the combustion chamber for stable and complete ignition.

24. Blocked vent switch

The blocked vent switch interrupts the control circuit when there is a vent blockage or significant restriction of vent piping.

25. Combustion air filter box

Provides a combustion air connection for direct vent installation, and houses the air filter.

26. Exhaust vent connection

The vent pipe conveys combustion products to a safe point of discharge. The unit is equipped with a standard AL-29 4C stainless steel vent connection. Refer to Table 6 for model specific vent connection sizes.

27. Heat Exchanger

316L Stainless Steel, Condensing, water tube type heat exchanger.

IV. Citadel Water Heater Component Identification (continued)




Figure 2: Component Identification

IV. Citadel Water Heater Component Identification (continued)




Figure 3: Component Identification

V. Unpacking The Citadel

A. Unpacking and Inspection

- 1. Move appliance to approximate installation location.
- 2. Remove all crate fasteners.
- 3. Lift and remove outside container.
- 4. Account for all loose shipped items.
- Remove cardboard positioning sleeves on shipping skid.
- 6. The appliance can be moved to its permanent location via a fork lift or an overhead crane.
- 7. For crane attachment, the lifting lugs are located next to the inlet/outlet water connections.
- 8. The appliance can be lifted from the base using a fork lift inserted into the side, front, or rear.




Figure 4: Lifting Lugs

B. Check Equipment

- 1. Upon receiving the equipment, check for signs of shipment damage.
- Pay particular attention to parts accompanying the appliance which may show sign of being hit or otherwise mishandled.
- Verify total number of pieces shown on packing slip with those actually received. In case there is damage or a shortage, immediately notify the carrier.

C. Installation and Operation Manual

 The instruction manual enclosed with the unit is an integral part of the product and must be retained by the person in charge of the appliance. Please read the instructions contained in this manual carefully as they provide important information regarding the safe installation, use and servicing of this appliance.

A DANGER

Failure to assure the lifting forks are long enough to extend at least half way through the base will result in the appliance tipping and potentially falling. This could result in severe personal injury, death, or substantial property damage.

Do not operate this appliance if any part has been underwater. The possible damage to a flooded appliance can be extensive and present numerous safety hazards. Any appliance that has been underwater must be replaced.

NOTICE

Do not drop, bump, or lean an object against the appliance. This could damaging the heat exchanger or other critical components.

VI. Pre-Installation and Mounting

A. General

- Installation must conform to the requirements of the authority having jurisdiction or, in the absence of such requirements, to the National Fuel Gas Code, ANSI Z223.1/NFPA 54, and/or Natural Gas and Propane Installation Code, CAN/CSA B149.1. Where required by the authority having jurisdiction, the installation must conform to the Standard for Controls and Safety Devices for Automatically Fired Boilers, ANSI/ASME CSD-1.
- Provide clearance between appliance jacket panels and combustible material in accordance with local fire ordinance. Refer to Table 5 for recommended service clearances. Recommended service clearances may be reduced but should not be less than the clearance to combustibles.
- 3. Protect gas ignition system components from water (dripping, spraying, rain, etc.) during operation and service (circulator replacement, condensate trap, control replacement, etc.).
- 4. Provide combustion and ventilation air in accordance with applicable provisions of local building codes, or: USA National Fuel Gas Code, ANSI Z223.1/NFPA 54, Air for Combustion and Ventilation; Canada Natural Gas and Propane Installation Code, CAN/CSA-B149.1, Venting Systems and Air Supply for Appliances.
- 5. The appliance should be located so as to minimize the length of the vent system. Ensure air intake pipe termination is away from areas that may contaminate the combustion air (see Table 4). In particular, avoid areas near chemical products containing chlorines, chlorofluorocarbons, paint removers, cleaning solvents, and detergents. Avoid areas containing saw dust, loose insulation fibers, dry wall dust etc.
- This appliance must not be installed in a room under negative pressure. An equipment room under negative pressure conditions could deplete the combustion air supply to the appliance and cause leakage of flue gas from the venting system.
 - a. Direct vent installation is not complete without screwing down the front door for a proper seal of the combustion air system.

A WARNING

Apply supplied silicone lubricant to the gasket inside the vent connector. Failure to apply lubricant could result in flue gas leaks or gasket deterioration.

Adequate combustion and ventilation air must be provided to assure proper combustion. Install combustion air intake using the methods in this manual.

Installation of this appliance should be undertaken only by trained and skilled personnel from a qualified service agency. Follow these instructions exactly. Improper installation, adjustment, service, or maintenance can cause property damage, personal injury or loss of life.

Do not change or modify any accessories or parts or jump-out any safety limit devices.

NOTICE

Due to the low water content of the appliance, mis-sizing with regard to the heating or hot water system load will result in excessive cycling and accelerated component failure.

U.S. Boiler Company DOES NOT warrant failures caused by mis-sized appliance applications. DO NOT oversize the appliance to the system. Multiple unit installations greatly reduce the likelihood of oversizing.

Ensure all labels on the product are fully visible at all times for the purpose of maintenance and inspections.

A CAUTION

Avoid operating this appliance in an environment where sawdust, loose insulation fibers, dry wall dust, etc. are present. If operated under these conditions, the burner interior and ports must be cleaned and inspected daily to insure proper operation.

VI. Pre-Installation and Mounting (continued)

B. Appliance Mounting

- 1. The Citadel is intended for installation in an area with a floor drain, or in a suitable drain pan to prevent any leaks or T&P relief valve discharge resulting in property damage.
- 2. This appliance is not intended to support external piping or venting. All external piping and venting must be supported independently of the appliance.
- 3. This appliance must be installed on a level surface to prevent condensate from backing up inside the heat exchanger.
- 4. Provide adequate space for condensate piping, condensate pump, or neutralizer kit.
- 5. An elevated base/pad is required when the floor is not level or in areas where water could accumulate around the appliance. The base must be able to support the weight of the appliance, water, and all additional system components.
 - a. This appliance is listed for installation on combustible flooring. Acceptable flooring includes a level metal or wooden base capable of holding the weight of the appliance, water, and aditional components. The base shall extend beyond the edges of the appliance by at least 3 inches (76.2 mm) in any direction. Never install directly on carpeted flooring.
 - b. For closet or alcove installation, the base shall cover the entire floor of the closet/alcove.

A WARNING

For installation and operation only in climates where the ambient temperature will not be less than 32 °F (0 °C). Do not install in climates where condensate can freeze.

Appliance must be protected from standing water. Install on a level platform.

Do not install this appliance under an overhang less than 3 feet from its top. The area under the overhang must be open on 3 sides.

Never install directly on carpeted flooring.

Contaminants to Avoid: Spray cans containing chlorofluorocarbons (CFC's) Permanent wave solutions Chlorinated waxes/cleaners Chlorine-based swimming pool chemicals Calcium chloride used for thawing Sodium chloride used for water softening Refrigerant leaks Paint or varnish removers Hydrochloric acid/muriatic acid Cements and glues Anti-static fabric softeners used in clothes dryers Chlorine-type bleaches, detergents, and cleaning solvents found in household laundry rooms. Adhesives used to fasten building products and other similar products Excessive dust and dirt Areas likely to have contaminants:
CFC's) Permanent wave solutions Chlorinated waxes/cleaners Chlorine-based swimming pool chemicals Calcium chloride used for thawing Sodium chloride used for water softening Refrigerant leaks Paint or varnish removers Hydrochloric acid/muriatic acid Cements and glues Anti-static fabric softeners used in clothes dryers Chlorine-type bleaches, detergents, and cleaning solvents found in household laundry rooms. Adhesives used to fasten building products and other similar products Excessive dust and dirt
Chlorinated waxes/cleaners Chlorine-based swimming pool chemicals Calcium chloride used for thawing Sodium chloride used for water softening Refrigerant leaks Paint or varnish removers Hydrochloric acid/muriatic acid Cements and glues Anti-static fabric softeners used in clothes dryers Chlorine-type bleaches, detergents, and cleaning solvents found in household laundry rooms. Adhesives used to fasten building products and other similar products Excessive dust and dirt
Chlorine-based swimming pool chemicals Calcium chloride used for thawing Sodium chloride used for water softening Refrigerant leaks Paint or varnish removers Hydrochloric acid/muriatic acid Cements and glues Anti-static fabric softeners used in clothes dryers Chlorine-type bleaches, detergents, and cleaning solvents found in household laundry rooms. Adhesives used to fasten building products and other similar products Excessive dust and dirt
Calcium chloride used for thawing Sodium chloride used for water softening Refrigerant leaks Paint or varnish removers Hydrochloric acid/muriatic acid Cements and glues Anti-static fabric softeners used in clothes dryers Chlorine-type bleaches, detergents, and cleaning solvents found in household laundry rooms. Adhesives used to fasten building products and other similar products Excessive dust and dirt
Sodium chloride used for water softening Refrigerant leaks Paint or varnish removers Hydrochloric acid/muriatic acid Cements and glues Anti-static fabric softeners used in clothes dryers Chlorine-type bleaches, detergents, and cleaning solvents found in household laundry rooms. Adhesives used to fasten building products and other similar products Excessive dust and dirt
Refrigerant leaks Paint or varnish removers Hydrochloric acid/muriatic acid Cements and glues Anti-static fabric softeners used in clothes dryers Chlorine-type bleaches, detergents, and cleaning solvents found in household laundry rooms. Adhesives used to fasten building products and other similar products Excessive dust and dirt
Paint or varnish removers Hydrochloric acid/muriatic acid Cements and glues Anti-static fabric softeners used in clothes dryers Chlorine-type bleaches, detergents, and cleaning solvents found in household laundry rooms. Adhesives used to fasten building products and other similar products Excessive dust and dirt
Hydrochloric acid/muriatic acid Cements and glues Anti-static fabric softeners used in clothes dryers Chlorine-type bleaches, detergents, and cleaning solvents found in household laundry rooms. Adhesives used to fasten building products and other similar products Excessive dust and dirt
Cements and glues Anti-static fabric softeners used in clothes dryers Chlorine-type bleaches, detergents, and cleaning solvents found in household laundry rooms. Adhesives used to fasten building products and other similar products Excessive dust and dirt
Anti-static fabric softeners used in clothes dryers Chlorine-type bleaches, detergents, and cleaning solvents found in household laundry rooms. Adhesives used to fasten building products and other similar products Excessive dust and dirt
Chlorine-type bleaches, detergents, and cleaning solvents found in household laundry rooms. Adhesives used to fasten building products and other similar products Excessive dust and dirt
solvents found in household laundry rooms. Adhesives used to fasten building products and other similar products Excessive dust and dirt
other similar products Excessive dust and dirt
Areas likely to have contaminants:
Arous interfeto nave contaminants.
Dry cleaning/laundry areas and establishments
Swimming pools
Metal fabrication plants
Beauty shops
Refrigeration repair shops
Photo processing plants
Auto body shops
Plastic manufacturing plants
Plastic manufacturing plants Furniture refinishing areas and establishments

Garages with workshops

VI. Pre-Installation and Mounting (continued)

C. Clearances

- 1. The Citadel is approved for 0" clearance to combustible materials. The clearances for serviceability are found in Table 5.
- 2. Minimum clearances from combustible or noncombustible construction, 0" sides, 0" back, 0" top.
- 3. It is the installers responsibility to provide enough clearance for servicing the appliance in the installed location.

D. Clearances (French)

- 1. Dégagements minimaux à assurer entre les parois de l'appareil et les constructions combustibles ou incombustibles : 0 po (côtés), 0 po (arrière) et 0 po (dessus).
- 2. Installation dans une garde-robe : assurer un dégagement de 24 po devant l'appareil.

E. Closet and Alcove installation

- 1. Include ventilation air openings in closet installations.
- 2. Provide a 1" minimum clearance around water pipes.
- 3. Follow vent material manufacturer for vent clearances.
- 4. Clearances for closet or alcove Installation:

Front - 24"

Sides - 24"

Rear - 22"

Top - 20"

Table 5: Clearances for Serviceability

CTDW Model	Front (In.)	Rear (In.)	Right (In.)	Left (In.)	Top (In.)	
1250	20	22	6	24	20	
1500	24	22	6	24	20	

NOTICE

This appliance is approved for zero inch clearance to combustible or noncombustible material, but installing the appliance with smaller than the clearances for serviceability will limit access for maintenance.

Consult local codes and inspectors before installing multiple appliances adjacent to each other with zero clearance.

Closet and alcove installation can cause elevated temperatures. Follow the required clearances and use only stainless steel, CPVC, or polypropylene vent material.

VII. Venting

A. General Venting Guidelines

- Install vent system in accordance with National Fuel Gas Code, ANSI Z223.1/NFPA 54 or Natural Gas and Propane Installation Code, CAN/CSA B149.1 Installation Code for Canada, or, applicable provisions of local building codes.
- 2. The Citadel is listed as a direct vent appliance but can also be used with indoor air for combustion.
 - Screw down the front door to the base for proper sealing of the combustion air system. This appliance relys on a sealed jacket for direct vent installations.
- Vent/combustion system materials that are approved for use with this appliance are listed in Table 10. Venting manufacturers not listed in this manual may be acceptable. It is the responsibility of the installer or vent supplier to use compatible adapters and materials.
 - a. It is recommended to consult with venting professionals and designers when determining the vent system for this appliance.
- 4. Enclose vent passing through occupied or unoccupied spaces above the appliance with material having a fire resistance rating at least equal to the rating of adjoining floor or ceiling.
- 5. For flue gas venting, have horizontal runs sloping upwards not less than ¼ inch per foot (21 mm/m) from the appliance to the vent terminal.
- This appliance operates under conditions that permit condensation in the heat exchanger and the flue gas venting. This appliance shall be installed so as to prevent accumulation of condensate, and where necessary, have means provided for drainage of condensate.
- 7. If possible, slope horizontal combustion air pipe minimum 1/4 in/ft (21 mm/m) downward towards terminal. If not, slope towards the appliance.
- It is recommended that a Carbon Monoxide detector be installed and interlocked to the appliance. Consult your local jurisdiction for additional requirements.

B. Venting Design Requirements

At the discretion of the installing contractor, the venting system can be designed by consulting with approved venting engineers or by using the equivalent length method in this manual.

1. Engineered Venting Method

(Recomended Method) Using the operating characteristics and required conditions, an individual or common venting system can be designed to ensure the reliability of the appliance(s).

A WARNING

This appliance must not be installed in a room under negative pressure. These direct vent gas fired appliances are allowed a maximum leakage of 2% from the venting/combustion chamber and 8% from the air inlet portion when pressurized to operating conditions in a neutral pressure room. An equipment room under negative pressure could deplete the combustion air supply to the appliance and cause leakage of flue gas from the venting system.

Exhaust fans installed in equipment rooms can create negative pressure conditions strong enough to cause nuisance shutdowns of the appliance.

NOTICE

Common venting with other manufacturers' appliances or different U.S. Boiler Company models is prohibited.

It is the Responsibility of the installing contractor or venting designers to comply with national and local codes and follow best industry practices for installing vent support, drainage, and pitch.

Do not exceed maximum vent/combustion air system length.

- a. Flue gas temperatures and flow rates can be found in Table 9.
- b. The combustion CO_2 and O_2 ranges are shown in Table 34.
- c. The pressure at the flue outlet of the appliance at any given firing rate must be within the range of negative 0.25" W.C. to positive 0.5" W.C.
- d. The pressure at the intake of the appliance at any given firing rate must be within the range of 0.0" WC to positive 0.1" WC.
- e. Manifolded venting without backflow prevention can allow flue gas from one appliance to interact with the other appliances in the system. Common venting systems must be designed with backflow protection.
- 2. Equivalent length method: Do not exceed maximum vent/combustion air lengths listed in Table 6. Equivalent lengths of fittings are given in Table 7.

C. Field Installation

- 1. A factory installed cast aluminum or steel ring provides a means for air intake connection.
- 2. A factory installed vent connector provides a means for connection to stainless steel venting.
- 3. Vent and combustion air intake pipe must be supported to allow uniform flow of combustion air and flue gas.
- 4. Plan venting system to avoid possible contact with plumbing or electrical wires. Start at the vent connector and work towards the vent termination.
- 5. Design the air intake system to allow 3/8" (9.5mm) of thermal expansion per 10 ft. (3m) of CPVC/PVC pipe. Runs of 20 ft. (6.1m) or longer that are restrained at both ends must have an offset.
 - a. PVC combustion air pipe joints must be cleaned with primer and glued with cement. Follow all manufacturer instructions and drawings when preparing pipe ends for joining and using the primer and the cement.
- Size and cut wall opening such that a minimal clearance is obtained and to allow easy insertion of vent pipe.

A WARNING

Failure to follow these instructions could cause products of combustion to enter the building, resulting in severe property damage, personal injury, or death.

Use CPVC vent components within any interior space where air cannot circulate freely, including through vertical or horizontal chase ways, inside a stud wall, in closets, and through wall penetrations.

The use of cellular core PVC (ASTM F891), cellular core CPVC or Radel (polyphenolsulfone) is prohibited.

All condensate that forms in the vent must be able to drain back to the heat exchanger.

Table 6: Vent and Combustion Air Pipe Diameters and Maximum Lengths

	Comb	oustion Air L	ength	Vent Length				
Model Model	Pipe Dia. in. (mm)	Minimum ft. (m)	Maximum ft. (m)	Pipe Dia. in. (mm)	Minimum ft. (m)	Maximum ft. (m)		
1050	8 (200)	0	150 (45.7)	8 (200)	3 (0.9)	150 (45.7)		
1250	6 (160)	0	50 (15.2)	6 (160)	3 (0.9)	50 (15.2)		
1500	8 (200)	0	150 (45.7)	8 (200)	3 (0.9)	150 (45.7)		
1500	6 (160)	0	50 (15.2)	6 (160)	3 (0.9)	50 (15.2)		

NOTE:

Contact factory for assistance on maximum vent length applications.

This table applies to all listed vent/combustion air system options.

Table 7: Equivalent lengths of Vent and Combustion Air Components

Diameter	6 in. (160 mm)	8 in. (200 mm)	10 in. (250 mm)	12 in. (315 mm)
90° Elbow	7 ft. (2.1 m)	11 ft. (3.4 m)	14 ft. (4.3 m)	18 ft. (5.5 m)
45° Elbow	3 ft. (0.9 m)	4 ft. (1.2 m)	5 ft. (1.5 m)	7 ft. (2.1 m)

Table 8: Vent and Combustion Air Equivalent Length Calculation Worksheet

Combustion				Air			Vent					
Component	Equivalent Length Per Piece	х	Quantity	=	Subtotal Equivalen Length	- 1	Equivalent Length Per Piece	х	Quantity	=	Subtot Equival Lengt	ent
Straight Pipe		Х		=	A	4		х		=		D
90° Elbow		Х		=	Е	3		х		=		Е
45° Elbow		Х		=	C	5		Х		=		F
	Combustion Air Total Equivalent Length		=			Equiv		Vent Total nt Length	=			

Notes

Table 9: Flue Gas and Combustion Air Flow Rates

		At Maximun	n Input Rate	At Minimum Input Rate		
CTDW Model	Vent Dia. (In.)	Flue Gas Flow, Combustion Air, ACFM @ 35% SCFM @ 35% Excess Air, 180 °F Excess Air, 60 °F		Flue Gas Flow, ACFM @ 35% Excess Air, 180 °F	Combustion Air, SCFM @ 35% Excess Air, 60 °F	
1250		352	265	70	53	
1500	8	423	318	84	63	
Note: Flow rates are based on the combustion of natural gas.						

Table 10: Listed Vent Manufacturers and Materials

Material	Model
Stainless Steel	Saf-T Vent EZ Seal*
Stainless Steel/ Polypropylene	Z-Vent/Z-DENS
Polypropylene	PolyPro Single Wall Rigid
Polypropylene	InnoFlue SW Rigid
	Stainless Steel Stainless Steel/ Polypropylene Polypropylene

^{*}Factory supplied flue connection. Adapters are required to transition to alternate vent materials or manufacturers.

^{1.} Total equivalent length cannot exceed maximum equivalent length shown in Table 6.

^{2.} Combustion air and vent terminations do not count towards total equivalent length.

Table 11: Stainless Steel and CPVC Vent Adapters

	Stainless Steel to CPVC	Heat Fab to Z-Vent
Vent Diameter (in.)	USB Part #	Z-Flex Part #
8	109510-01	2SVSHF08
10	109510-02	2SVSHF10
12	109510-03	2SVSHF12

Table 12: Polypropylene Vent Adapters

CTDW	Vent	Centrotherm Part # (Innoflue PP System)	Z-Flex Part #
Model	Diameter (in.)		(Z-DENS PP Systems)
1250 1500	8	ISSA0808	2ZDAHF8

Table 13: Stainless Steel Vent and Intake Terminations

CTDW Model	Vent Diameter (in.)	Style	Heat Fab Part # Saf-T Vent	Z-Flex Part # Z-Vent
	8	Tee	9890TEE	2SVST08
1250 1500		Elbow	9814TERM	2SVEE0890
1000		Straight	9892	2SVSTPX08

Table 14: Polypropylene Vent and Intake Terminations

CTDW Model	Vent Diameter (in.)	Style	Centrotherm Part # InnoFlue	Z-Flex Part # Z-DENS
	8	Tee	ISTT0820	2ZDTT8
1250 1500		Elbow	-	-
1000		Straight	ISEP086	-

D. General Termination

- 1. Use only listed vent/combustion air terminals.
- 2. Follow the termination configurations shown in Table 15, and see Table 18 for acceptable termination components.
- 3. Maintain correct clearance and orientation between vent and combustion air terminals.
 - a. The required spacing between vent and combustion air terminals is to prevent flue gas recirculation. Recirculation of flue gas products into the combustion air supply can cause damage to property or the appliance.
- b. When installed on the same wall, locate vent terminal 4 vent pipe diameters above the combustion air terminal. The snorkle configuration can be used when penetrations are at the same hieght.
- 4. Locate bottom of vent and combustion air terminals at least 12 in. (300 mm) [18 in. (460 mm) in Canada] above the normal snow line and at least 12 in. (300 mm) above grade level.
- 5. Do not install vent terminal directly above windows or doors.
- 6. Locate bottom of vent terminal at least 3 ft. (900 mm) above any forced air inlet located within 10 ft. (3.0 m).

Table 15: Recommended Venting Configurations and Material Options

Vent & Intake Materials	Vent Option		Penetration Through Structure	Termination	Parts Table	Reference Figure
	4	Intake	Horizontal Sidewall	90° elbow		Figure 0
Two Pipe	1	Vent	Horizontal Sidewall	Tee or 45° elbow		Figure 6
Stainless Steel vent	0	Intake	Horizontal Sidewall	90° elbow	T-1-1- 40	
Galvanized Steel or	2	Vent	Vertical Roof	Tee or straight	Table 13	-
PVC intake	0	Intake	Vertical Roof	Tee or 2 90° elbows		Figure 7
	3	Vent	Vertical Roof	Tee or straight		Figure 8
	4	Intake	Horizontal Sidewall	90° elbow		Figure 6
Two Pipe	4	Vent	Horizontal Sidewall	Tee or 45° elbow		Figure 6
Polypropylene vent	5	Intake	Horizontal Sidewall	90° elbow	Table 14	
Galvanized Steel or	5	Vent	Vertical Roof	Tee or straight	Table 14	-
PVC intake	6	Intake	Vertical Roof	Tee or 2 90° elbows		Figure 7
	6	Vent	Vertical Roof	Tee or straight		Figure 8
	7	Intake	Horizontal Sidewall	90° elbow		Figure 6
Two Pipe	7	Vent	Horizontal Sidewall	Tee or 45° elbow		Figure 6
CPVC/PVC vent	8	Intake	Horizontal Sidewall	90° elbow		
Galvanized Steel or	0	Vent	Vertical Roof	Tee or straight	-	-
PVC intake	9	Intake	Vertical Roof	Tee or 2 90° elbows		Figure 7
	9	Vent	Vertical Roof	Tee or straight		Figure 8
SS, PP, or CPVC vent	10	Vent	Horizontal Sidewall	Tee or 45° Elbow	Table 13	_
Room air intake	11	Vent	Vertical Roof	Tee or straight	Table 14	
NOTICE	locat 2. All te	ions. rminatio	ended to use tees for			n extra wind

3. All non-metallic venting exposed to sunlight shall be UV resistant.

- If window and/or air inlet is within 4 ft. (1.2 m) of an inside corner, maintain at least 6 ft. (1.8 m) spacing between terminal and adjoining wall of inside corner.
- 8. Locate bottom of vent terminal at least 7 ft. (2.1 m) above a public walkway.
- Maintain minimum clearance of at least 4 ft. (1.2 m) [3 ft. (900 mm)in Canada] horizontally between vent terminal and gas meters, electric meters, regulators, and relief equipment. Do not install vent terminal above or below this equipment.
- 10. Do not locate the vent terminal under decks or similar structures.
- 11. Top of terminal must be at least 24 in. (600 mm) below ventilated eaves, soffits, and other overhangs. In no case may the overhang exceed 48 in. (1200 mm). Where permitted by the authority having jurisdiction and local experience, the terminal may be located closer to unventilated soffits. The minimum vertical separation depends upon the depth of the soffit.
- 12. For multiple appliance installations with vertical roof terminals, separate vent pipes may be piped through a common conduit or chase so that one roof penetration may be made. Maintain recommended separations of terminations after penetration.

- 13. Maintain minimum 24 in. (610 mm) horizontal spacing between vent terminal and a building corner.
- 14. Under certain conditions, water in the flue gas may condense, and possibly freeze, on objects around the terminal including on the structure itself. If these objects are subject to damage by flue gas condensate, they should be moved or protected.
- 15. If possible, install the vent and combustion air terminals on a wall away from the prevailing wind. Reliable operation of this product cannot be guaranteed if terminals are subjected to winds in excess of 40 mph (64 km/hr).
- 16. Do not locate combustion air terminal in areas that might contain combustion air contaminates, such as near swimming pools.

NOTICE

Use of cellular core PVC (ASTM F891), cellular core CPVC, or Radel® (polyphenylsulfone) in non-metallic venting systems is prohibited.

Covering non-metallic vent pipe and fittings with thermal insulation is prohibited.




Figure 5: Vent Terminal Clearances

Table 16: Direct Vent Terminal Clearances

		Canadian Installations ¹	US Installations ²
А	Clearance above grade, veranda, porch, deck, or balcony	18 in. (46 cm)	12 in (30 cm)
В	Clearance to window or door that may be opened	6 in (15 cm) for appliances ≤ 10,000 Btuh (3 kW), 12 in (30 cm) for appliances > 10,000 Btuh (3 kW) and ≤ 100,000 Btuh (30 kW), 36 in (91 cm) for appliances >100,000 Btuh (30 kW)	6 in (15 cm) for appliances ≤ 10,000 Btuh (3 kW), 9 in (23 cm) for appliances > 10,000 Btuh (3 kW) and ≤ 50,000 Btuh (15 kW), 12 in (30 cm) for appliances > 50,000 Btuh (15 kW)
С	Clearance to permanently closed window	*	*
D	Vertical clearance to ventilated soffit located above the terminal within a horizontal distance of 2 ft (61 cm) from the center line of the terminal.	*	*
Е	Clearance to unventilated soffit	*	*
F	Clearance to outside corner	*	*
G	Clearance to inside corner	*	*
Н	Clearance to each side of center line extended above meter/regulator assembly	3 ft (91 cm) within a height of 15 ft (4.6 m)	*
I	Clearance to service regulator vent outlet	3 ft (91 cm)	*
J	Clearance to nonmechanical air supply inlet to building or the combustion air inlet to any other appliance	6 in (15 cm) for appliances ≤ 10,000 Btuh (3 kW), 12 in (30 cm) for appliances > 10,000 Btuh (3 kW) and ≤ 100,000 Btuh (30 kW), 36 in (91 cm) for appliances >100,000 Btuh (30 kW)	6 in (15 cm) for appliances ≤ 10,000 Btuh (3 kW), 9 in (23 cm) for appliances > 10,000 Btuh (3 kW) and ≤ 50,000 Btuh (15 kW), 12 in (30 cm) for appliances > 50,000 Btuh (15 kW)
K	Clearance to a mechanical air supply inlet	6 ft (1.83 m)	3 ft (91 cm) above if within 10 ft (3 m) horizontally
L	Clearance above paved sidewalk or paved driveway located on public property	7 ft (2.13 m) †	7 ft (2.13 m) for mechanical draft systems (Category I appliances). Vents for Category II and IV appliances cannot be located above public walkways or other areas where condensate or vapor can cause a nuisance or hazard*
М	Clearance under veranda, porch deck, or balcony	12 in (30 cm) ‡	*

NOTICE

^{*} Clearance in accordance with local codes and the requirements of the gas supplier.

[†] A vent shall not terminate directly above a sidewalk or paved driveway that is located between two single family dwellings and serves both dwellings.

[‡] Permitted only if veranda, porch, deck, or balcony is fully open on a minimum of two sides beneath the floor.

¹⁾ In accordance with the current CSA B149.1, Natural Gas and Propane Installation Code

²⁾ In accordance with the current ANSI Z223.1/NFPA 54, National Fuel Gas Code

³⁾ If locally adopted installation codes specify clearances different than those illustrated, then the most stringent clearance shall prevail.

Table 17: Other than Direct Vent Terminal Clearances

		Canadian Installations ¹	US Installations ²
А	Clearance above grade, veranda, porch, deck, or balcony	18 in (46 cm)	12 in (30 cm)
В	Clearance to window or door that may be opened	6 in (15 cm) for appliances ≤ 10,000 Btuh (3 kW), 12 in (30 cm) for appliances > 10,000 Btuh (3 kW) and ≤ 100,000 Btuh (30 kW), 36 in (91 cm) for appliances >100,000 Btuh (30 kW)	4 ft (1.2 m) below or to side of opening; 1 ft (300 mm) above opening
С	Clearance to permanently closed window	*	*
D	Vertical clearance to ventilated soffit located above the terminal within a horizontal distance of 2 ft (61 cm) from the center line of the terminal.	*	*
Е	Clearance to unventilated soffit	*	*
F	Clearance to outside corner	*	*
G	Clearance to inside corner	*	*
Н	Clearance to each side of center line extended above meter/regulator assembly	3 ft (91 cm) within a height 15 ft (4.6 m)	*
ı	Clearance to service regulator vent outlet	3 ft (91 cm)	*
J	Clearance to nonmechanical air supply inlet to building or the combustion air inlet to any other appliance	6 in (15 cm) for appliances ≤ 10,000 Btuh (3 kW), 12 in (30 cm) for appliances > 10,000 Btuh (3 kW) and ≤ 100,000 Btuh (30 kW), 36 in (91 cm) for appliances >100,000 Btuh (30 kW)	4 ft (1.2 m) below or to side of opening; 1 ft (300 mm) above opening
K	Clearance to a mechanical air supply inlet	6 ft (1.83 m)	3 ft (91 cm) above if within 10 ft (3 m) horizontally
L	Clearance above paved sidewalk or paved driveway located on public property	7 ft (2.13 m) †	7 ft (2.13 m) for mechanical draft systems (Category I appliances). Vents for Category II and IV appliances cannot be located above public walkways or other areas where condensate or vapor can cause a nuisance or hazard
М	Clearance under veranda, porch deck, or balcony	12 in (30 cm) ‡	*

NOTICE

Notes:

- 1) In accordance with the current CSA B149.1, Natural Gas and Propane Installation Code
- 2) In accordance with the current ANSI Z223.1/NFPA 54, National Fuel Gas Code

^{*} Clearance in accordance with local codes and the requirements of the gas supplier.

[†] A vent shall not terminate directly above a sidewalk or paved driveway that is located between two single family dwellings and serves both dwellings.

[‡] Permitted only if veranda, porch, deck, or balcony is fully open on a minimum of two sides beneath the floor.


³⁾ If locally adopted installation codes specify clearances different than those illustrated, then the most stringent clearance shall prevail.

Table 18: Table of Acceptable Terminations

Flue Gas Vent Terminations



Combustion Air Intake Terminations



Notes:
Do not use Louvers for direct vent systems
One appliance per gooseneck termination
Vent and intake piping must not share the same gooseneck
All terminations should have Bird/Rodent Screens
Do not use rain caps, Rain will drain through boot tee or condensate drain

E. Vent and Combustion Air Terminations

1. Vent Piping

- a. Install fire stops where vent passes through floors, ceilings or framed walls. The fire stop must close the opening between the vent pipe and the structure.
- Whenever possible, install vent straight through the roof.
- c. Size roof opening to maintain minimum clearance of 1 in. (25 mm) from combustible materials.
- d. Extend vent pipe to maintain minimum vertical distance for expected snow accumulation. Provide brace as required.
- e. Install storm collar on vent pipe immediately above flashing. Apply Dow Corning Silastic 732 RTV Sealant or equivalent between vent pipe and storm collar to provide weather-tight seal.

2. Combustion Air Piping

- a. If possible, locate combustion air termination in the same roof location as the vent termination to prevent nuisance shutdowns. Alternatively, this appliance may be installed with a vertical roof vent terminal and sidewall combustion air terminal.
- b. Size roof opening to allow easy insertion of combustion air piping and allow proper installation of flashing and storm collar to prevent moisture from entering the structure.
- c. Use appropriately designed vent flashing when passing through roofs. Follow flashing manufacturers' instructions for installation.
- d. Extend combustion air pipe to maintain minimum vertical and horizontal distance of 12 in (300 mm) from roof surface or from the maximum snow level.

A CAUTION

Intermittent shutdowns can occur when the vent terminals are subject to winds above 40 mph. The required spacing between vent and combustion air terminals is to prevent flue gas recirculation. Recirculation of flue gas products into the combustion air supply can cause damage to property or the appliance.

NOTICE

Methods of securing and sealing terminals to the outside wall must not restrain the thermal expansion of the vent pipe.

Exterior run should be included in equivalent vent/combustion air lengths.

Vertical Venting and combustion air roof penetrations (where applicable) require the use of roof flashing and storm collar, which are not supplied with appliance, to prevent moisture from entering the structure.

Examine all components for possible shipping damage prior to installation.

All condensate that forms in vent must be able to drain back to the heat exchager or a boot tee with a drain.

The venting system must be free to expand and contract and must be supported in accordance with installation instructions included by the original component manufacturers, whenever applicable. Polypropylene pipe sections must not be fully inserted. Leave 1/4 to 5/8 in. (6 mm to 16 mm) per joint for thermal expansion.

A WARNING

Failure to vent this appliance in accordance with these instructions could cause products of combustion to enter the building resulting in severe property damage, personal injury or death.

Do not locate vent termination under a deck, or where exposed to prevailing winds.

Do not locate combustion air termination where volatile vapors or other chemicals are present. Severe corrosion and failure will result.

Do not interchange vent systems or materials unless otherwise specified.

Do not apply thermal insulation to vent pipe or fittings.

Do not use a barometric damper or draft hood with this appliance.




Figure 6: Horizontal Sidewall Termination

Figure 7: Slopped Roof Termination




Figure 8: Flat Roof Vent Terminations

Notes:

- 1. All terminations must have bird/rodent screens.
- 2. If Possible, Install Sidewall venting on a wall away from prevailing wind.
- 3. For roof terminations, install vent terminal downstream of prevailing winds relative to intake terminal.
- 4. It is recommended to use tee terminations with a vertical run in extra windy areas.

A CAUTION

Installing multiple vent terminations too close together may result in combustion product water vapor condensation on building surfaces where vent terminations are placed, causing subsequent frost damage. To avoid/ minimize frost damage, extend the distance from building surfaces to vent termination end and increase the horizontal distance between adjacent vent terminations.

F. Multiple Appliance Terminations

- 1. Vent Piping Terminations
 - a. Multiple appliance vent terminations are shown in Figure 9.
 - b. Each individual appliance must have its own vent pipe and vent terminal unless a common venting system is used following the guidlines of the "Engineered Venting Method" section in this manual.
 - c. For horizontal sidewall terminations, maintain at least 6 pipe diameters minimum horizontal distance between any adjacent individual vent terminations. Additional horizontal spacing between any adjacent individual vent terminations as well as extending the distance from building surfaces to vent termination end are recommended to avoid frost damage to building surfaces where vent terminations are placed.
 - d. Multiple individual vertical vent pipes may be piped through a common conduit or chase so that one roof penetration may be made.
 - e. For vertical roof terminations, maintain at least 6 pipe diameters minimum horizontal distance between adjacent individual appliance vent terminations.

2. Combustion Air Piping

- a. Multiple appliance combustion air terminations are shown in Figure 9.
- b. Each individual appliance must have its own combustion air pipe and terminal when using category IV venting.
- c. Individual appliance sidewall terminals must be placed at least 12 in. (300 mm) [18 in. (460 mm) in Canada] above the ground plus the expected snow accumulation.

A WARNING

Moisture and ice may form on the surface around vent termination.

To prevent deterioration, surface must be in good repair (sealed, painted, etc.).

Do not allow low spots in the vent where condensate may pool.

Use specified vent and combustion air pipe diameters.

All vent and combustion air piping must be sealed and airtight.

Alteration of the appliance vent connection is prohibited.

A WARNING

The joint between the terminal and the last piece of pipe must be outside of the building.

The vent for this appliance shall not terminate:

- 1. Over public walkways; or
- 2. Near soffit vents or crawl space vents or other areas where condensate or vapor could create a nuisance or hazard or cause property damage; or
- Where condensate vapor could cause damage or could be detrimental to the operation of regulators, pressure relief valves, or other equipment.
- d. Do not exceed the maximum combustion air pipe length for an individual appliance as listed in Table 6.
- e. If possible, locate the vent and combustion air terminals for each appliance on the same wall to prevent nuisance shutdowns. If not, each appliance may be installed with a roof vent terminal and sidewall combustion air terminal.

G. Terminal Installation

- 1. Use the terminal connections supplied by the venting manufacturer. Follow manufacturer's instructions to attach the terminal to the vent system.
- 2. For PVC/CPVC terminals, apply a heavy bead of silicone to the male end of the terminal before inserting it into the last piece of pipe. Orient the terminal so that the seam in the terminal is at 12:00. Smooth the silicone over the seam between the terminal and the last piece of pipe, applying additional silicone if necessary to ensure a tight seal. Allow the silicone to cure per the silicone manufacturer's instructions before operating the appliance.
- 3. Install Bird/Rodent screens in the terminals. Use a screen having 1/2 in. x 1/2 in. (13 mm x 13 mm) mesh.
- 4. Adhere to the minimum and maximum wall thickness specified by the manufacturer of the wall penetration assembly.




Figure 9: Multiple Appliance Direct Vent Termination

H. Polypropylene Venting

- Running Flexible Polypropylene Vent (Liner) Through Unused Chimney Chase
 - a. It is the responsibility of the installing contractor to procure polypropylene vent system pipe and related components.
 - b. All listed polypropylene vent system manufacturers must comply with the requirements of *ULC-S636-08* 'Standard for Type BH Gas Venting Systems'. For Canadian installation, polypropylene vent must be listed as a *ULC-S636* approved system.
 - Flexible polypropylene pipe must be treated carefully and stored at temperatures higher than 41 degrees F.
 - d. When flexible polypropylene pipe (liner) is used for combustion air supply, the pipe (liner) can be installed in a vertical or horizontal position.
 - e. Follow manufacturer instructions regarding application/listing, permits, minimum clearances to combustibles, and installation details (proper joint assembly, pipe support and routing, gasket and fitting installation, optional tooling availability/usage, routing through masonry chimney for combustion product venting or, combination of combustion product venting and combustion air supply).
 - f. When using a masonry chimney as a passageway for flexible polypropylene pipe, the chase must be structurally sound and free of any debris or obstructions.
 - g. To prevent condensate pooling and damage to vent, offsets (bend) cannot exceed 45°. Multiple offsets are allowed in a chase.
- 2. Pressure drop for flexible polypropylene line is 20 % greater than from rigid pipe. Multiply measured flexible polypropylene liner length by 1.2 to obtain equivalent length.
- Maximum equivalent vent length of flexible polypropylene liner is 48 ft. (14.6 m).

I. Optional Room Air for Combustion

- 1. General Guidelines
 - Room air is optional for commercial applications.
 Follow the requirements in this section when air for combustion is supplied from the boiler room.
 - Avoid combustion air contaminants in the boiler room. Permanently remove any contaminants found in the boiler room. If contaminants cannot be removed, do not use room air for combustion.

A WARNING

Asphyxiation Hazard. Vent systems made by listed PP vent system manufacturers rely on gaskets for proper sealing. When this type of vent system is used, take the following precautions:

Make sure that gasket is in position and undamaged in the female end of the pipe.

Make sure that both male and female pipes are free of damage prior to assembly.

Only cut vent pipe as permitted by the vent manufacturer in accordance with their instructions. When pipe is cut, the cut end must be square and carefully deburred prior to assembly.

Use locking band clamps at all vent pipe joints.

Flexible polypropylene vent must be installed only in an unused chimney. A chimney, either single or multiple flue type, is considered unused when one of the flues is being used for any appliance venting, or When one of the multiple flues is being used for appliance venting. The flexible vent installation is not permitted through any of the adjacent flues.

Do not bend or attempt to install flexible pipe if it has been stored at ambient temperature below 41 F. This will cause material to became brittle and will lead to cracks, resulting in flue gas leaks.

Do not install flexible polypropylene pipe at an angle greater than 45 degrees from vertical when used for combustion product venting. Failure to do so will result in improper condensate drainage and possible subsequent vent pipe blockage.

- 2. Outdoor Openings to Boiler Room
- a. Provide combustion and ventilation air to the boiler room or enclosure. Follow the National fuel Gas Code, ANSI Z223.1, or, in Canada, Installation Code for Gas Burning Appliances and Equipment, CSA Standard B149 Code as well as all applicable local codes. Use one of the following methods.

A WARNING

This appliance must not be installed in a room under negative pressure. An equipment room under negative pressure could deplete the combustion air supply to the appliance and cause leakage of flue gas from the venting system.

NOTICE

Pressure drop for flexible polypropylene line is 20 % greater than from rigid pipe. Multiply measured flexible polypropylene liner length by 1.2 to obtain equivalent length.

Maximum equivalent vent length of flexible polypropylene liner is 48 ft. (14.6 m).

Installation of a polypropylene vent system should adhere to the vent manufacturer's installation instructions supplied with the vent system.

A WARNING


DO NOT mix vent systems of different types or manufacturers. Failure to comply could result in severe personal injury, death, or substantial property damage.

DO NOT connect venting to a chimney flue that is servicing a separate appliance designed to burn solid fuel.

DO NOT use chimney for Combustion air intake.

DO NOT insulate polypropylene vent pipes. Excessive heat could cause premature vent pipe failure.

BOILER -



EXHAUST PART OF

PPs FLEX KIT

Figure 10: Flexible Vent in Masonry Chimney with Separate Combustion Air Intake

- b. Natural gas and propane installation code specifies venting systems and air supply for appliances. Air supply shall be provided when either an appliance or a combination of appliances has a total input exceeding 400,000 Btu/h.
- c. Air supply is defined as combustion air, excess air, flue gas dilution air, primary air, secondary air, and ventilation air. The air supply requirements below are a summation of Clause 8.4 specific to this gas appliance.
- 3. Air Supply Requirements for Appliances having an input exceeding 400 MBH:
 - a. Ventilation Air: an opening for ventilation air at the highest point that opens to the outdoors shall provide Ventilation of the space. The cross sectional area of this opening shall be at least 10% of the area required for combustion air, but in no case shall the cross-sectional area be less than 10 in² (6500 mm²).
 - b. Combustion Air: For combustion air where the air supply is provided by natural airflow from outdoors, in addition to the opening for ventilation air, there shall be permanent opening having a total cross-sectional free area of not less than 1 in² for each 30,000 BTU/hr. (70 mm² for each kW) of the total rated input of the appliance(s). The location of the opening(s) shall not interfere with the openings for ventilation air. Please refer to the codes listed above for combustion air openings when natural draft, fan assisted or power draft assisted equipment are in the space.

A WARNING

Sources of combustion air contaminants, including chlorines, chlorofluorocarbons (CFC's), petroleum distillates, detergents, volatile vapors or other chemicals must not be present in the boiler room. If any of these contaminants are present, severe corrosion and failure will result.

Asphyxiation Hazard. Common manifold venting requires special considerations. Follow the instructions in this manual

U.S. Boiler Company takes no responsibility for vent systems that create issues and or affect the performance of the appliance.

Improper Installation of a Category II vent system resulting in positive pressure in the vent system can result in flue gas spillage and carbon monoxide emissions, causing severe personal injury or death.

- c. When an air supply duct is used to supply combustion air, its discharge opening shall be located where there is no possibility of cold air affecting steam/water lines or other temperature sensitive equipment.
- 4. Combustion Air Supply Dampers, Louvers, and Grilles
 - a. The free area of the combustion air supply opening shall be calculated by subtracting the blockage area of all fixed louvers, grilles or screens from the gross area of the opening.
 - b. Openings in a fixed louver, grille, or screen shall have no dimension smaller than ¼" (6 mm).
 - c. No manually operated dampers or manually operated adjustable louvers are permitted.
 - d. Motorized dampers or Louvers shall be interlocked so the burner(s) cannot operate unless the damper or louver is in the fully open position.
- 5. Mechanical Combustion Air Supply
 - a. When combustion air is supplied by mechanical means, an airflow sensing device shall be installed and wired into the safety limit circuit of the primary safety control to shut off the gas in the event of an air supply failure.
- 6. Appliance Venting
 - This appliance is listed as Category IV venting and requires special venting systems as previously described.
 - Venting for Category IV appliances shall be as specified or furnished by the manufacturer of the listed appliance.
 - A special venting system shall be installed in accordance with the terms of its listing and the vent manufacturers certified installation manual.
 - iii. A flue gas vent or a vent connector shall not be installed inside either a duct or a shaft used for return air, hot air, ventilating air, or combustion air
 - iv. An appliance that operates at a positive vent pressure shall not be connected to a venting system serving any other appliance. This appliance operates at a positive vent pressure.
 - v. A factory-built chimney used for venting an appliance shall be certified.

J. Removing Existing Appliance

When an existing appliance is removed from a common venting system, the common venting system is likely to be too large for proper venting of the remaining appliances. At the time of removal of an existing appliance, the following steps should be performed with each appliance remaining connected to the common venting system. Make sure the appliances are not in operation while carrying out these steps.

- 1. Seal any unused openings in the common venting system.
- 2. Visually inspect the venting system for proper size and horizontal pitch and ensure there is no blockage or restriction, leakage, corrosion, or other deficiencies which could cause an unsafe condition.
- 3. Insofar as is practical, close all exterior doors and windows, and all doors between the space where the appliances connect to the common venting system and other spaces of the building. Turn on any exhaust fans, such as range-hoods and bathroom exhausts, so they will operate at maximum speed. Do not operate a summer exhaust fan. Close fireplace dampers.
- 4. Place in operation the appliance being inspected. Follow the Lighting (or Operating) Instructions. Adjust thermostat so appliance will operate continuously.
- 5. Test for spillage at the draft hood relief opening after 5 minutes of main burner operation. Use the flame of a match or candle, or smoke from a cigarette, cigar or pipe.
- After it has been determined that each appliance connected to the common venting system properly vents when tested as outlined above, return doors, windows, exhaust fans, fireplace dampers and any other gas burning appliance to their previous conditions of use.
- 7. Any improper operation of the common venting system should be corrected so the installation conforms with the *National Fuel Gas Code, ANSI Z223.1/NFPA 54* and/or the *Natural Gas and Propane Installation Code, CAN/CSA B149.1.* Resizing of any portion of the common venting system, should be done in accordance with the National Fuel Gas Code, ANSI Z223.1/NFPA 54 and/or the Natural Gas and Propane Installation Code, CAN/CSA B149.1.

NOTICE

Please note that the information provided in this manual relative to the Canadian Standard is not meant to be all-inclusive. Reading the entire Standard is strongly suggested. The final approval of all system designs must be acceptable to the authority having jurisdiction.

K. Special Installation Requirements for Massachusetts

- 1. For all sidewall horizontally vented gas fueled equipment installed in every dwelling, building or structure used in whole or in part for residential purposes and where the sidewall exhaust vent termination is less than seven (7) feet above grade, the following requirements shall be satisfied:
 - a. If there is no carbon monoxide detector with an alarm already installed in compliance with the most current edition of NFPA 720, NFPA 70 and the Massachusetts State Building Code in the residential unit served by the sidewall horizontally vented gas fueled equipment, a battery operated carbon monoxide detector with an alarm shall be installed in compliance with the most current edition of NFPA 720, NFPA 70 and the Massachusetts State Building Code.
 - b. In addition to the above requirements, if there is not one already present, a carbon monoxide detector with an alarm and a battery back-up shall be installed and located in accordance with the installation requirements supplied with the detector on the floor level where the gas equipment is installed. The carbon monoxide detector with an alarm shall comply with 527 CMR, ANSI/UL 2034 Standards or CSA 6.19 and the most current edition of NFPA 720. In the event that the requirements of this subdivision can not be met at the time of the completion of the installation of the equipment, the installer shall have a period of thirty (30) days to comply with this requirement; provided, however, that during said thirty (30) day period, a battery operated carbon monoxide detector with an alarm shall be installed in compliance with the most current edition of NFPA 720, NFPA 70 and the Massachusetts State Building Code. In the event that the sidewall horizontally vented gas fueled equipment is installed in a crawl space or an attic, the carbon monoxide detector may be installed on the next adjacent habitable floor level. Such detector may be a battery operated carbon monoxide detector with an alarm and shall be installed in compliance with the most current edition of NFPA 720, NFPA 70 and the Massachusetts State Building Code.
 - c. A metal or plastic identification plate shall be permanently mounted to the exterior of the building at a minimum height of eight (8) feet above grade directly in line with the exhaust vent terminal for the horizontally vented gas fueled heating appliance or equipment. The sign shall read, in print size no less than one-half (1/2) inch in size, "GAS VENT DIRECTLY BELOW. KEEP CLEAR OF ALL OBSTRUCTIONS".
 - d. A final inspection by the state or local gas inspector of the sidewall horizontally vented equipment shall not be performed until proof is provided that the state or local electrical inspector having jurisdiction has granted a permit for installation of carbon monoxide detectors and alarms as required above.
- 2. EXEMPTIONS: The following equipment is exempt from 248 CMR 5.08(2)(a) 1 through 4:
 - a. The equipment listed in Chapter 10 entitled "Equipment Not Required To Be Vented" in the most current edition of NFPA 54 as adopted by the Board; and
 - b. Product Approved sidewall horizontally vented gas fueled equipment installed in a room or structure separate from the dwelling, building or structure used in whole or in part for residential purposes.
- 3. When the manufacturer of Product Approved sidewall horizontally vented gas equipment provides a venting system design or venting system components with the equipment, the instructions for installation of the equipment and the venting system shall include:
 - a. A complete parts list for the venting system design or venting system; and
 - b. Detailed instructions for the installation of the venting system design or the venting system components.
- 4. When the manufacturer of a Product Approved sidewall horizontally vented gas fueled equipment does not provide the parts for venting flue gases, but identifies "special venting systems", the following shall be satisfied:
 - a. The referenced "special venting system" instructions shall be included with the appliance or equipment installation instructions; and
 - b. The "special venting systems" shall be Product Approved by the Board, and the instructions for that system shall include a parts list and detailed installation instructions.
- 5. A copy of all installation instructions for all Product Approved sidewall horizontally vented gas fueled equipment, all venting instructions, all parts lists for venting instructions, and/or all venting design instructions shall remain with the appliance or equipment at the completion of the installation.

VIII. Condensate Disposal

A. General

- Note the following when disposing of the condensate:
 - a. Condensate is slightly acidic, typical pH around 3.5 4.5. Do not route the drain line through areas that could be damaged by leaking condensate.
 - b. Do not route or terminate the condensate drain line in areas subject to freezing temperatures.
 - c. If the point of condensate disposal is above the trap, a condensate pump is required to move the condensate to the drain. Select a condensate pump approved for use with condensing appliance—and equipped with an overflow switch.
 - d. Do not attempt to substitute another trap for one provided with the appliance.
 - e. Slope condensate drain pipe at least 1/8" per foot in the direction of discharge.
- 2. Refer to Table 19 when sizing condensate drain line, pump and neutralizer kit. Table 20 lists optional neutralizer kits available from factory.

Table 19: Maximum Condensate Flow

CTDW Model	Maximum Condensate Flow Rate (GPH)	
1250	10.32	
1500	12.24	

NOTICE

Do not crimp condensate drain lines or reduce drain line inner diameter size, unless adapting to a neutralizer kit.

Do not manifold condensate drains and vent drains together.

Consult local authorities regarding disposal of flue gas condensate into the public waste water system.

Do not use metallic pipe or fittings for condensate drain lines.

B. Condensate trap installation

- 1. Locate the condensate trap assembly shipped loose with this appliance.
- 2. Install the condensate trap on the lower rear of the appliance as shown in Figure 11.
- 3. Connect condensate float switch wires to the wire harness extended out of the rear junction box (from terminals 75 and 76 on PCB 1).




Figure 11: Condensate Trap Assembly

- 4. The flue gas trap prevents flue gases from escaping into the boiler room.
- 5. The float switch interrupts the limit string in the event the drainage of the condensate is blocked.

C. Condensate Neutralizer Installation

- Some jurisdictions may require that the condensate be neutralized before being disposed of. Follow local codes pertaining to condensate disposal.
- A condensate neutralizer kit is available from factory as optional equipment. Refer to Table 20 for size specific part number. Follow local codes and instructions enclosed with the kit for condensate neutralizer installation.
- Limestone chips will get coated by neutral salts (product of chemical reaction between limestone and acidic condensate) and lose neutralizing effectiveness over time. Therefore, periodic condensate neutralizer maintenance and limestone chip replacement are required for proper neutralization of the condensate.

Table 20: Condensate Neutralizer Kit

CTDW Model	Condensate Neutralizer Kit, PN	Condensate Neutralizer, Refill Kits, PN
1250	107860-02	107886-02
1500	107860-02	107886-02

D. Common Condensate pump/Sump

- A common condensate pump/sump may be used. Run separate piping from each condensate drain to the sump. A common drain may be used to discharge condensate from the sump.
- 2. If a common sump is used, individual drain lines should be constructed, using material listed above, such that one drain cannot back feed into another drain.
- 3. Do not manifold condensate and vent drains together.

A WARNING

Failure to install the condensate drain in accordance with the above instructions could cause flue gas to enter the building, resulting in personal injury or death.

NOTICE

Flue gas condensate is corrosive. Route condensate drain line in a manner such that any condensate leakage will not cause property damage.

If the condensate line is obstructed in any way, the float switch will prevent the appliance from firing. Some jurisdictions may require that condensate

Some jurisdictions may require that condensate be neutralized prior to disposal.

The condensate drain trap should be flushed with clean water as part of the appliance maintenance schedule to remove any debris that might have accumulated.

IX. Water Piping

The Citadel water heater is considered to be a circulating water heater or hot water supply boiler. This Product will operate most efficiently and reliably when paired with one or more storage tanks.

A. General Piping Guidelines

Suggested piping configurations are shown in diagram form in section "X. Water Piping Diagrams". The following steps are general guidelines for installing the Citadel water heater in a hot water supply system. The installer is responsible for complying with local codes.

- The cold water return line shall be connected to the inlet of the appliance labeled "cold water connection"
- 2. The hot water supply line shall be connected to the outlet manifold of the appliance shown in Figure 12.
- 3. The system cold water supply line shall include a backflow preventer/check valve and properly sized expansion tank for the capacity of the system.
- 4. A drain valve should be installed at the lowest point in the system
- 5. The Citadel is a condensing appliance. The return water and cold water supply should be piped to the primary loop going into the appliance.
- 6. Circulation pump must be installed in the primary piping between the tank and the water heater.

B. Factory Supplied Outlet Water Manifold

- 1. A temperature and pressure relief valve is included with every Citadel water heater. If the Relief valve is shipped loose, install it to the outlet manifold as shown in Figure 12.
- 2. When piping the appliance to the system, do not install an elbow closer than 5 pipe diameters from the flow switch.
- When adapting the grooved outlet to the system piping, use a coupling that conforms to local codes and ordinances. Victaulic 107N couplings are available from factory.




Figure 12: Hot Water Outlet Manifold

NOTICE

Failure to properly pipe appliance may result in improper operation and damage.

Install the appliance so that the gas ignition system components are protected from water (dripping, spraying, rain, etc.) during appliance operation and service (circulatory replacement, cleaning, etc.).

Contamination of the water by corrosive chemicals will cause corrosion of the steel components, and can lead to appliance failure. U.S. Boiler Company's Standard Warranty does not cover problems caused by contamination of supply water.

Installation is not complete unless a temperature and pressure relief valve is installed in the outlet manifold of the appliance or the hot water piping shortly downstream of the appliance.

Failure to maintain the flow through the appliance within the specified limits could result in erratic operation or premature failure.

The circulator shall be sized properly based on the pressure drop of the entire loop and the desired temperature rise.

Maintain 1" (24mm) clearance around all uninsulated hot water pipes. The piping going into the cold water inlet of the appliance can still be hot from circulating the water in the tank.

C. Standard Piping Components

1. Circulation Piping

The circulation piping includes both pipelines connecting the appliance to the tank. The pipe diameter for 1 appliance should be sized no smaller than what is recommended in Table 26.

The inlet and outlet connections of the Citadel are grooved Victaulic pipe connections. The Victaulic rigid coupling 107N QuickVic™ is recommended.

2. Temperature and Pressure Relief Valve

- a. This appliance is shipped with a temperature and pressure (T&P) relief valve complying with the standard for relief valves for hot water supply systems ANSI Z21.22 • CSA 4.4 installed on the hot water outlet manifold.
- b. The T&P relief valve must be installed with the spindle in a vertical position. Installation of the relief valve must comply with ASME Boiler and Pressure Vessel Code, Section IV.
- c. If the T&P relief valve is to be replaced, the replacement valve must have a relief capacity equal or exceeding the minimum relief valve capacity shown on the heat exchanger ASME plate. Also, when replacing the T&P relief valve, verify the temperature and pressure gauge meets ASME requirements for the replacement T&P relief valve.
- d. Pipe the T&P relief valve discharge to a location where hot water or steam will not cre ate hazard or property damage if the valve discharges. The end of the discharge pipe must terminate in an untreated pipe.
- e. If the T&P relief valve is not piped to a drain, it must terminate at least 6 in. (150mm) above the floor. Do not run T&P relief valve discharge pipe through an area prone to freezing. The termination of discharge piping must be in an area where it will not became plugged by debris.
- f. The storage tank requires its own T&P relief valve installed according to the manufacturers instructions.

3. Drain Valves

A factory installed 3/4" NPT drain valve and connection is provided with the unit.

A WARNING

Scald Hazard. T&P relief valve discharge shall be piped in such a way to prevent or eliminate potential burn risk.

DO NOT pipe in any area where freezing could occur.

DO NOT install any shut-off valves, plugs, caps, or reducers in the discharge piping.

Discharge line shall be installed to allow complete drainage of both the valve and the line.

Consult local codes for proper discharge pipe arrangement.

Observe a minimum of 1/2 inch (12 mm) clearance around all uninsulated hot water piping.

4. Flow Switch (Factory Supplied)

This appliance is CSD-1 compliant and equipped with water flow switch and reset low water cut out box. A flow switch is required for forced circulation coil-type water boilers to prevent overheating and the heat exchanger failure in accordance with requirements of ASME Boiler and Pressure Vessel Code, Section IV, and ANSI/ASME CSD-1 "Controls and Safety Devices for Automatically Fired Boilers".

5. Circulator Pump (Required)

A pump is required to circulate the water between the storage tank and the appliance. It is the responsibility of the installer to size and install the circulator for the proper flow rate and temperature rise. Refer to Table 25 and Table 26.

6. Expansion Tank (Required)

If this appliance is replacing an existing appliance with no other changes in the system, the old expansion tank can generally be reused. If the expansion tank must be replaced, consult the expansion tank manufacturer's literature for proper sizing.

7. Y-strainer (Recommended)

A Y-strainer or equivalent strainer removes heating system debris from the hydronic system and protects the heat exchanger. Install the strainer in the primary piping going to the inlet of the appliance.

8. Isolation Valves (Recommended)

Isolation valves are useful for servicing and stopping water flow in the case of failure. Full port ball valves are required.

9. Mixing Valve/Anti-scald Valve (Recommended)

A mixing valve is recommended when storing water at scalding hot temperatures.

10. Recirculation Filter (Recommended)

A Recirculation filter can capture suspended solids in the system and help prevent the effects of erosion corrosion.


D. Scalding

This water heater can supply water at scalding temperatures to faucets and other fixtures in the system. Mixing valves are recommended to maintain the supply water at safe temperatures.

- 1. Maintaining the storage tank above 140 °F and using a mixing valve can increase the amount of hot water available and help prevent the growth of water borne bacteria like Legionella.
 - Mixing valves can be installed at the outlet of storage tank or at other zones or fixtures in the system.
- 2. When appliances such as dishwashers or clothes washers are used in a domestic hot water system that require increased temperatures, two hot water supply's can be set up as shown in Figure 14.
- 3. Scalding can occur at temperatures above 125 °F. Young Children, disabled, and elderly are most at risk of hot water scalding.

Table 21: Approximate Time for Scalding

Temperature (°F)	Time
120	More than 5 minutes
125	1-1/2 to 2 minutes
130	About 30 seconds
135	About 10 seconds
140	Less than 5 seconds
145	Less than 3 seconds
150	About 1-1/2 seconds
155	About 1 second



- Water temperatures over 125 °F can cause severe burns instantly or death from scalds.
- Children, disabled, and elderly are at highest risk of scalding.
- Feel water before bathing or showering.
- For domestic hot water supply, adjust the high limit control on the appliance or use tempering (mixing) valves to limit the supply temperature below 125 °F.

NOTICE

The Citadel heat exchanger is made from stainless steel tubular double coil having relatively narrow waterways. Once filled with water, it will be subject to the effects of corrosion. Failure to take the following precautions to minimize corrosion, and overheating could result in severe product damage.

Before connecting the appliance, insure the system is free of impurities, grease, sediment, construction dust, sand copper dust, and flux. Flush the system thoroughly and repeatedly, if needed.

Scale deposit is made up of lime scale contained in most distributed water and settles over the warmest surfaces of the heat exchanger causing subsequent overheating and eventual failure.

Scale can form from high water hardness and slow water velocities. Failure to maintain the recommended water hardness and flow rate will result in a buildup of scale inside the heat exchanger.

E. Water Quality

- The water directly in contact with the appliance must meet the requirements in Table 22. Failure to adhere to the water treatment requirements in this manual can cause damage not covered by warranty to the appliance, pumps, or other components in the system.
- 2. It will be necessary to gain knowledge of the impurities dissolved in the water and consult with a qualified industrial water treatment professional to establish a treatment plan. In addition, a periodic testing/sampling plan should be developed.
- 3. To minimize corrosion and scale effects, adhere to the water quality requirements in Table 22.
 - a. If the water hardness is higher than 205 ppm (12 gpg), a water softener must be used.
 - b. Water with a hardness of less than 80 ppm (5 gpg) can have a pH level that is corrosive.
- Total Dissolved Solids (TDS) contribute to scale buildup. If the TDS or combined water hardness and TDS exceeds 450 ppm, the water needs to be heated indirectly.
 - a. The TDS (in ppm) is determined by measuring the electrical conductivity (μ S/cm) of the water and multiplying by a conversion factor (typically 0.65 for drinking water).
- 5. Chlorine and Chloride can be very corrosive to stainless steel. Ensure the level of chlorine is less than 5 ppm and the level of chloride is less than 150 ppm.

A WARNING

The Citadel is **not** designed for the heating of swimming pool water.

Table 23: Operating Water Flow Rates

	Flow Rate (GPM)							
CTDW Model	Hardness level, 4-12 gpg	Hardness level, 12-15 gpg						
1250	99	132						
1500	110	147						

If system contains aluminum components, pH must be less than 8.5.

Table 24: Absolute Water Flow Rates

CTDW Model	Max Flow (GPM)	Min Flow (GPM)		
1250	450	44		
1500	450	53		

NOTICE: This table represents the absolute max and min flow rates allowed and shall **not** be used to design the system or size the circulator.

- 6. Before connecting the appliance, insure the system is free of impurities, grease, sediment, construction dust, and any other contaminants.
 - a. Flush the system thoroughly and repeatedly, if needed.

Table 22: Water Quality Requirements

Quality Parameter	Minimum	Maximum
Water Hardness (ppm)	80	205
Total Dissolved Solids (ppm)	100	450
Chlorine (ppm)	-	5
Chloride (ppm)	-	150
pH (cold)	6.5	7.5

Notes:

The combined water hardness and TDS cannot exceed 450 ppm.

1 grain per gallon = 17.1 ppm

A CAUTION

Water temperatures over 140 °F (60 °C) greatly increase the affects of corrosive chemicals.

Chlorine and Chloride have different levels of corrosion effects on stainless steel. It is recommended for chlorine (Cl₂) levels to be below 5ppm and chloride (Cl⁻) levels to be below 150 ppm for 316 stainless steel.

F. Temperature Rise and Heat Exchanger Head Loss

- 1. The Citadel heat exchanger adds pressure drop to the system which must be accounted for in the design of the piping configuration and pump selection.
- 2. The system should be designed to maintain the operating water flow rate shown in Table 23 while never exceeding the range of absolute flow rates shown in Table 24. Exceeding the maximum water flow rates can cause pipe erosion, damage the flow switch, and allow unsafe operation.
 - a. Maintaining sufficient flow through the heat exchanger will help prevent the buildup of scale.

Table 25: Temperature rise, flow rate, and head loss

	Reco	Recommended Range														
	Delta	20 °F	F Delta 25 °F		Delta 30 °F Delta		Delta	35 °F Delta 40 °F		Delta 45 °F		Delta 50 °F		Delta 55 °F		
Model Model	GPM	Head Loss (ft)	GPM	Head Loss (ft)	GPM	Head Loss (ft)	GPM	Head Loss (ft)	GPM	Head Loss (ft)	GPM	Head Loss (ft)	GPM	Head Loss (ft)	GPM	Head Loss (ft)
1250	123	16.1	98	11.3	82	8.5	70	6.6	61	5.4	54	4.5	49	3.8	45	3.3
1500	147	15.6	118	10.9	98	8.2	84	6.4	74	5.2	65	4.3	59	3.7	53	3.1

Required Flow = Output×1000/(500× Δ T), where flow rate is in GPM, output is in MBH, and Δ T is in ${}^{\circ}$ F, Outputs are shown in Table 1.

This water heater has a temperature rise limit of 55 °F

G. Pump Selection

A Circulation pump is a required component for complete installation of this appliance. Choosing the appropriate pump is critical for the functionality, safe operation, and longevity of the appliance. Pumps should be sized for each particular installation based on the required flow rate, water hardness, and total pressure drop in the primary loop between the tank and the water heater.

- 1. Sizing a sufficient pump will ensure the desired temperature rise and meet the minimum flow rate requirements. Lower flow rates will allow build up of scale and cause more stress on the heat exchanger.
 - a. If the flow rate is too high and the temperature rise is too low, the flow rate can be decreased by adding a restriction in the loop.
 - i. Install a ball valve or globe valve (recommended) in the outlet side of the primary piping.
 - ii. With the water heater at its maximum input rate (high fire), slowly adjust the globe valve until the temperature rise is within the recommended range shown in Table 25.
 - iii. Water velocities too high may cause erosion within the tubes of the heat exchanger or the primary piping. Failure to adjust the flow rate to the specified values or use the appropriate pipe size can cause non-warrantable damage.
- 2. The wetted materials of the pump must be suitable for potable water. Look for bronze or stainless steel pump housings.

Table 26: Pumps, Pipe Size, and Total Head Loss

CTDW Model	Nominal Pipe Size (in)	Water Hardness (gpg)	Flow Rate (GPM)	Heat Ex. loss (ft of head)	Total Loss (ft of head)	Optional Grundfos* Pump (TS #)	Temperature Rise (°F)
1050	3	4-12	99	11	17	109695-02	24
1250	4	12-15	132	18	21	109695-04	18
1500	3	4-12	110	10	17	109695-02	26
1500	4	12-15	147	16	20	109695-04	20


NOTE: The total loss includes 50 ft of pipe, 8 elbows, and 4 Valves.

*Grundfos MAGNA1 pumps

NOTICE

It is the installer's or system designer's responsibility to account for differences in the circulation loop. Length, pipe diameter, elbows, and valves all contribute to the total pressure drop in the loop.


Figure 13: Single Water Heater; Single Tank





- 1. These are suggested piping configurations. It is the installer's responsibility to conform to local codes and ordinances for additional requirements.
- 2. Pressure relief valve rating shall not exceed pressure rating of any component in the system.
- 3. Some piping components cannot be supported by the pipping. Refer to the manufactures' installation instructions.
- 4. It is the installers responsibility to select boiler piping configurations that provide the proper flow rates and performance for the boiler and indirect water heater.


Figure 14: Two Temperatures, Single Water Heater, Single Tank





- 1. These are suggested piping configurations. It is the installer's responsibility to conform to local codes and ordinances for additional requirements.
- 2. Pressure relief valve rating shall not exceed pressure rating of any component in the system.
- 3. Some piping components cannot be supported by the pipping. Refer to the manufactures' installation instructions.
- 4. It is the installers responsibility to select boiler piping configurations that provide the proper flow rates and performance for the boiler and indirect water heater.

Figure 15: Single Water Heater, Two Tanks





- 1. These are suggested piping configurations. It is the installer's responsibility to conform to local codes and ordinances for additional requirements.
- 2. Pressure relief valve rating shall not exceed pressure rating of any component in the system.
- 3. Some piping components cannot be supported by the pipping. Refer to the manufactures' installation instructions.
- 4. It is the installers responsibility to select boiler piping configurations that provide the proper flow rates and performance for the boiler and indirect water heater.

Figure 16: Two Water Heaters, Single Tank





Table 27: Required Common Piping Sizes for Multiple Appliances

CTDW	TDW Number of Appliances									
Model	2	3	4	5	6					
1250	5"	6"	8"	8"	10"					
1500	6"	6"	8"	8"	10"					
Note: Nom	Note: Nominal pipe sizes are noted. Based on type L copper pipe									



- 1. These are suggested piping configurations. It is the installer's responsibility to conform to local codes and ordinances for additional requirements.
- 2. Pressure relief valve rating shall not exceed pressure rating of any component in the system.
- 3. Some piping components cannot be supported by the pipping. Refer to the manufactures' installation instructions.
- 4. It is the installers responsibility to select boiler piping configurations that provide the proper flow rates and performance for the boiler and indirect water heater.
- 5. Erosion could occur if common piping is undersized.

Figure 17: Two Water Heaters, Two Tanks



Required Common Piping Sizes for Multiple Appliances

CTDW	Number of Appliances										
Model	2	3	4	5	6						
1250	5"	6"	8"	8"	10"						
1500	1500 6" 6" 8" 8" 10"										
Note: Non	ninal pipe sizes are	noted. Based on typ	e L copper pipe.								



- 1. These are suggested piping configurations. It is the installer's responsibility to conform to local codes and ordinances for additional requirements.
- 2. Pressure relief valve rating shall not exceed pressure rating of any component in the system.
- 3. Some piping components cannot be supported by the pipping. Refer to the manufactures' installation instructions.
- 4. It is the installers responsibility to select boiler piping configurations that provide the proper flow rates and performance for the boiler and indirect water heater.
- 5. Erosion could occur if common piping is undersized.

This page is intentionally left blank.

XI. Gas Piping

A. Guidelines and Requirements

All installation must conform to the *National Fuel Gas Code ANSI Z223.1/NFPA54*, and/or local codes. In Canada, installation must conform to the latest edition of *CSA B149.1 National Gas and Propane Gas Installation Code*, and/or local codes.

Safe operation of the appliance requires properly sized gas supply piping. Design gas piping system to provide adequate gas supply to the appliance. Account for existing and expected future gas utilization equipments such as boilers and cooking equipment.

- 1. First verify that the appliance is supplied with the type of gas specified on the rating plate.
- Account for pressure drop from the point of delivery to the appliance. The maximum allowable system pressure is ½ psig (14 in. wc). Refer to Table 31 for model specific gas pressures and gas connection sizes.
- 3. If the gas supply pressure is higher than 14 in. wc, An additional field supplied pressure regulator will be required.
- 4. For length of piping and number of fittings refer to and Table 28 for maximum capacity of Schedule 40 pipe. Table 29 lists equivalent pipe length for standard fittings.
- 5. Gas piping systems for gas specific gravity of 0.60 can be sized directly from Table 28 unless authority having jurisdiction specifies a gravity factor be applied. For other specific gravities, apply gravity factor from Table 30. If exact specific gravity is not shown choose next higher value.
- 6. A sediment trap must be provided upstream of the main gas valve.
- 7. All threaded joints should be coated with piping compound resistant to action of liquefied petroleum gas.
- 8. The appliance and its gas connection must be leak tested before placing it in operation.
- 9. To protect the gas valve when testing over 1/2 psig (3.4 kPa), the appliance and its individual shutoff valve must be disconnected from gas supply piping. For testing at 1/2 psig (3.4 kPa) or less, isolate the appliance from gas supply piping by closing the manual shutoff valve on the appliance.
- Locate leaks using approved combustible gas noncorrosive leak detector solution.
- 11. The incoming gas pressure can be measured at the pressure tapping on the manual ball valve.
- 12. If the high or low gas pressure switch tripped, it must be manually reset before the appliance can be restarted. (See Figure 19)

- 13. Gas piping shall be supported by fixed hangers or stands and not by the appliance.
- 14. Purge all air from gas lines.
- 15. Install manual shutoff valve in accordance with state and local requirements.




Figure 18: The Citadel Gas Train

NOTICE

Venting of Gas Train Components: The MBC (gas valve) has an internal factory installed vent limiter per ANSI Z21.18/ CSA 6.3. Venting is required unless otherwise accepted by the authority having jurisdiction.

The high and low gas pressure switches incorporate a vent limiter as per UL 353 and limits the escape of gas to less than 1.0 CFH at 7 PSI if the internal diaphragm ruptures.

Locate the field supplied gas pressure regulator a minimum of 10 ft from the appliance with no more than 1 elbow in-between.

Table 28: Maximum capacity of schedule 40 black pipe in CFH*

Natu	Natural Gas, Inlet Pressure 14.0 in wc (3.4 kPa)or less; 0.5 in wc (0.12 kPa) Pressure Drop											
Nominal	Inside		Length of Pipe (Ft)									
Pipe Size (In)	Diameter (In)	10	20	30	40	50	60	70	80	90	100	
1/2	0.622	172	118	95	81	72	65	60	56	52	50	
3/4	0.824	360	247	199	170	151	137	126	117	110	104	
1	1.049	678	466	374	320	284	257	237	220	207	195	
11/4	1.380	1390	957	768	657	583	528	486	452	424	400	
1½	1.610	2090	1430	1150	985	873	791	728	677	635	600	
2	2.067	4020	2760	2220	1900	1680	1520	1400	1300	1220	1160	
2½	2.469	6400	4400	3530	3020	2680	2430	2230	2080	1950	1840	
3	3.068	11300	7780	6250	5350	4740	4290	3950	3674	3450	3260	

^{*1} CFH of Natural Gas is approximately equal to 1 MBH; contact your gas suppliers for the actual heating value of your gas.

Р	Propane Gas, Inlet Pressure 11.0 in wc (2.7 kPa); 0.5 in wc (0.12 kPa) Pressure Drop											
Nominal	Inside		Length of Pipe (Ft)									
Pipe Size (In)	Diameter (In)	10	20	30	40	50	60	70	80	90	100	
1/2	0.622	116	80	64	55	48	44	40	38	35	33	
3/4	0.824	242	166	134	114	101	92	85	79	74	70	
1	1.049	456	314	252	215	191	173	159	148	139	131	
11⁄4	1.380	937	644	517	442	392	355	327	304	285	269	
1½	1.610	1403	964	775	663	588	532	490	456	427	404	
2	2.067	2703	1858	1492	1277	1131	1025	943	877	823	778	
21/2	2.469	4308	2961	2377	2035	1803	1634	1503	1399	1312	1239	
3	3.068	7615	5234	4203	3567	3188	2889	2658	2472	2320	2191	

^{*1} CFH of LP gas is approximately equal to 2.5 MBH; contact your gas supplier for the actual heating value of your gas.

Table 29: Equivalent Lengths of Standard Pipe Fittings & Valves (ft)

		Valves	S (Screw	ed) - Ful	ly Open	Screwed Fittings					
Nominal Pipe Size	Inside Diameter (in)	Gate	Globe	Angle	Swing Check	45° Elbow	90° Elbow	180 Close Return Bend	90 Tee Flow Through Run	90 Tee, Flow Through Branch	
1/2	0.622	0.4	17.3	8.7	4.3	0.7	1.6	3.5	1.6	3.1	
3/4	0.824	0.5	22.9	11.4	5.7	1.0	2.1	4.6	2.1	4.1	
1	1.049	0.6	29.1	14.6	7.3	1.2	2.6	5.8	2.6	5.2	
1¼	1.38	8.0	38.3	19.1	9.6	1.6	3.5	7.7	3.5	6.9	
1½	1.61	0.9	44.7	22.4	11.2	1.9	4.0	9.0	4.0	8.0	
2	2.067	1.2	57.4	28.7	14.4	2.4	5.2	11.5	5.2	10.3	
2½	2.469	1.4	68.5	34.3	17.1	2.9	6.2	13.7	6.2	12.3	
3	3.068	1.8	85.2	42.6	21.3	3.6	7.7	17.1	7.7	15.3	

Table 30: Specific Gravity Correction Factors

	-	-	
Specific Gravity	Correction Factor	Specific Gravity	Correction Factor
0.60	1.00	0.90	0.82
0.65	0.96	1.0	0.78
0.70	0.93	1.10	0.74
0.75	0.90	1.20	0.71
0.80	0.87	1.30	0.68
0.85	0.81	1.40	0.66

16. The gas pressure switches will trip if the incoming gas pressure passes the switches' set point. A tripped switch is indicated on the appliance display. A Manual reset is required to reset the switch and resume operation.




Figure 19: High/Low Gas Pressure Switch

A WARNING

Failure to properly pipe gas supply to appliance may result in improper operation and damage. Always assure gas piping is absolutely leak free and of the proper size and type for the connected load.

An additional gas pressure regulator may be needed. Consult gas supplier.

Failure to use proper thread compounds on all gas connections may result in leaks of flammable gas. Gas supply to appliance and system must be completely shut off prior to installing or servicing the gas piping.

Do not use matches, candles, or other open flame ignition source to check for leaks.

Use two wrenches when tightening gas piping at the appliance, use one wrench to prevent the gas train from turning.

Failure to support the connection pipe could damage safety components.

Ensure that the high gas pressure regulator is at least 10 feet (3 m) upstream of the appliance.

NOTICE

Use lock-up type gas pressure regulator when low and high gas pressure switches are installed. Older or non-lock-up type regulators may result in nuisance lockouts on gas pressure drops or spikes. The Citadel and all other appliances must be firing at maximum capacity to properly measure the inlet gas pressure.

Table 31: Inlet Gas Pressures and Pipe Size

CTDW Model	Inlet Size (In.)	Min. Gas Pres. Max. Gas (In. W.C.) (In. W			High Gas Pressure Switch ¹	Low Gas Pressure Switch ¹		
	(,	Natural	Propane	Natural	Propane	(In. W.C.)	(In. W.C.)	
1250	1	4	0	4.4	4.4	4	Natural: 3	
1500	1.25	4	8	14	14	1	LP: 7	

¹Factory default high and low gas pressure switch setpoint.

XII. Electrical

A. General.

Install wiring and electrically ground the appliance in accordance with authority having jurisdiction or, in the absence of such requirements, follow the *National Electrical Code*, NFPA 70, and/or *Canadian Electrical Code* Part 1, CSA C22.1.

 A separate electrical circuit must be run from the main electrical service with an over-current device/disconnect in the circuit. A service switch is recommended and may be required by some local jurisdictions. Install the service switch in the line voltage "Hot" leg of the power supply. Locate the service switch such that the appliance can be shut-off without exposing personnel to danger in the event of an emergency.

B. Power Requirements

 Nominal appliance current draw is provided in Table
 These values are for planning purposes only and represent the appliance's power consumption.

Table 32: Electrical Ratings

CTDW Model	Voltage	Phase	Hz	Appliance Amperage
	120			11
1250	208	1	60	7.4
	240			6.5
	120	1	60	13.5
	208			8.2
1500	240			7.7
1500	208			11
	240	3	60	9.9
	480			6.4

A DANGER

Electrical Shock Hazard: Ensure all electrical connections are disconnected before attempting installation or service of electrical components or connections of the appliance or building. Lockout all electrical boxes with padlock once power is turned off.

! WARNING

Electrical Shock Hazard: Failure to properly wire electrical connections on the appliance may result in serious physical harm.

Electrical power may be from more than one source. Make sure all power is off before attempting any electrical work.

Each appliance must be protected with a properly sized over-current device.

Never jump out or make inoperative any safety or operating controls.

The wiring diagrams contained in this manual are for reference purposes only. Each appliance is shipped with a wiring diagram attached to the front door. Refer to this diagram and the wiring diagram of any controls used. Read, understand and follow all wiring instructions supplied with the control.

NOTICE

All wires, wire nuts, controls etc. are installer supplied unless otherwise noted.

When making low voltage connections, make sure that no external power source is present in the thermostat or limit circuits. If such a power source is present, it could destroy the microprocessor control. One example of an external power source that could be inadvertently connected to the low voltage connections is a transformer with old thermostat wiring.

To obtain total system power consumption add all selected circulator and component current draws Label all wires prior to servicing controls. Wiring errors can cause improper and dangerous operation. Verify Proper operation after servicing.

C. Appliance Wiring

1. Connect to field wiring inside the control box. Inside the control box are five printed circuit boards (PCB's).

Table 33: Citadel PCB's

Printed Circuit Boards	Functions/Connection
PCB-01	Line Voltage
PCB-02	Field Device
PCB-03	Extra Limits (optional)
PCB-04	Sensors
PCB-05	EMS
PCB-06	Communications

- 2. 24VAC low voltage connections are located on PCB-02. Three fuses and one spare are provided.
- 3. 24VDC low voltage connections are located on the right side of PCB-01. One low voltage fuse and one spare is provided.

D. Line voltage connections

- 1. Connect 120 VAC power wiring to the line voltage terminal strip in the control box.
- 2. For 208 480 VAC, connect power wires to the line voltage terminals in the junction box.
- 3. Provide and install a fused disconnect or service switch as required by the code.

E. Low voltage connections

- 1. Route all low voltage wires through the junction box's knockouts in the rear of the appliance.
- 2. Wire the tank sensor to PCB-4 terminals 51 and 52 as noted on the wiring ladder diagram. See "Wire Diagram (continued)". Do **not** use the DHW switch location (terminals 53 and 54) for the tank sensor as these terminals are used for indirect water heating.
 - a. Avoid placing the senor near potential sources of electrical noise such as transformers, power lines, and fluorescent lighting. Wire the sensor to the appliance using 22 gauge or larger wire. As with the sensor, the sensor wiring should be routed away from sources of electrical noise. Where it is impossible to avoid such noise sources, wire the sensor using a 2 conductor, *UL Type CM, AWM Style 2092, 300 Volt 60 C* shielded.

F. System and Circulation Pump Wiring

1. The system pump can be wired to Contact A on PCB-02 as shown on the wire diagram.

2. The primary circulation pump can be wired to Contact B on PCB-02 as shown on the wire diagram.

A WARNING

Appliance must be electrically grounded as required by National Electrical Code ANSI/NFPA 70-latest edition.

Caution: Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation.




Figure 20: Single Phase Wire Diagram







Figure 21: Three Phase Wire Diagram







Wire Diagram (continued)

A. Check System Setup

- Verify that the venting, water piping, gas piping and electrical system are installed properly. Refer to installation instructions contained in this manual.
- Confirm all electrical, water, and gas supplies are turned off at the source and that venting is clear of obstructions.
- 3. Flush the system to remove sediment, flux, and other contaminants. This must be done with the appliance isolated from the system.
- 4. Fill the hot water system with treated water as specified in the water quality section of this manual.
 - a. Maintain at least 15 psi primary loop pressure.
- 5. Power the appliance. Turn on the electrical supply to the appliance and circulator at the fuse disconnect switch.
- 6. Power the circulator(s). Turn system circulator(s) on and purge air from the system.
- 7. Pressurize the fuel line.
 - a. Open the manual gas shut-off valves located upstream of the field supplied gas regulator.
 - b. Check gas piping for leaks and purge gas line of air.
 - c. Ensure the incoming gas pressure is within the min and max on the rating label. Also, ensure the setting for the high and low gas pressure switches are within the limits given in Table 31.
 - d. Reset high and low gas pressure switches by pressing the reset button.

B. Start the Citadel

Start the appliance using "Operating Instructions"in Figure 22.

- Allow the appliance to complete its standard startup sequence: pre-purge, pre-ignition, and drive light-off.
- 2. Refer to the Concert Control manual to select the desired control mode.
- 3. It may take a couple of ignition attempts before a flame is established. After the first ignition failure, the appliance goes into a hard lockout and a manual reset using the Concert Control is required to restart. If ignition is not achieved in three consecutive attempts, contact factory or a qualified heating service technician.
- 4. Begin commissioning the appliance. Visually inspect flame via sight glass window. On high fire the flame should be stable and mostly blue. Yellow tips should not be present; but, intermittent flecks of yellow and orange in the flame are normal.
- Test any other external limits or other controls in accordance with the manufacturer's instructions.

A DANGER

Do not use matches, candles, or other open flame ignition sources to check for leaks.

Make sure that the area around the appliance is clear and free from combustible materials, gasoline and other flammable vapors and liquids.

A WARNING

Start-up of this appliance should be undertaken only by trained and skilled personnel from a qualified service agency. Follow these instructions exactly. Improper installation, adjustment, service or maintenance can cause property damage, personal injury, or loss of life.

The maximum operating pressure of this appliance is 150psi (1034 kPa) with the factory installed temperature and pressure relief valve. Never exceed the maximum allowable working pressure on the heat exchanger ASME plate.

The outlet pressure for the gas valve has been factory set and requires no field adjustment. Attempting to adjust the outlet pressure may result in damage to the gas valve and cause property damage, personal injury or loss of life.

Each Citadel Series appliance is tested at the factory and adjustments to the air fuel mixture are normally not necessary. Improper gas valve or mixture adjustments could result in property damage, personal injury, or loss of life.

Any gas valve adjustments (throttle and/or offset) specified herein and subsequent combustion data (%O₂, %CO₂, CO air free ppm) collection must be performed using a calibrated combustion analyzer.

NOTICE

To reduce lime scale buildup and prolong the life of the appliance, closely monitor pH, chloride, total dissolved solids, and water hardness levels.

FOR YOUR SAFETY READ BEFORE OPERATING/POUR VOTRE SECÚRITE LISEZ AVANT DE METTRE EN MARCHE

WARNING: If you do not follow these instructions exactly, a fire or explosion may result causing property damage, personal injury or loss of life.

AVERTISSEMENT: Quiconque ne respecte pas à la lettre les instructions dans la présente notice risque de déclencher un incendie ou une explosion entraînant des dommages, des blessures ou la mort.

- A. This appliance does not have a pilot. It is equipped with an ignition device which automatically lights the burner. Do not try to light the burner by hand.
- B. BEFORE OPERATING smell all around the appliance area for gas. Be sure to smell next to the floor because some gas is heavier than air and will settle

WHAT TO DO IF YOU SMELL GAS:

- Do not try to light any appliance.
- Do not touch any electric switch; do not use any phone in your building.
- Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
- If you cannot reach your gas supplier, call the fire department.
- C. Use only your hand to turn the gas control knob. Never use tools. If the knob will not turn by hand, don't try to repair it, call a qualified service technician. Force or attempted repair may result in a fire or explosion.
- D. Do not use this appliance if any part has been under water. Immediately call a qualified service technician to inspect the appliance and to replace any part of the control system and any gas control which has been under water.

- A. Cet appareil ne comporte pas de veilleuse. Il est muni d'un dispositif d'allumage qui allume automatiquement le brûleur. Ne tentez pas d'allumer le brûleur manuellement.
- B. AVANT DE FAIRE FONCTIONNER, reniflez tout autour de l'appareil pour déceler une odeur de gaz. Reniflez près du plancher, car certains gaz sont plus lourds que l'air et peuvent s'accumuler au niveau du sol.

QUE FAIRE SI VOUS SENTEZ UNE ODEUR DE GAZ:

- Ne pas tenter d'allumer d'appareil.
- Ne touchez à aucun interrupteur ; ne pas vous servir des téléphones se trouvant dans le bâtiment.
- Appelez immédiatement votre fournisseur de gaz depuis un voisin. Suivez les instructions du fournisseur.
- Si vous ne pouvez rejoindre le fournisseur, appelez le service des incendies.
- C. Ne poussez ou tournez la manette d'admission du gaz qu'à la main ; ne jamais utiliser d'outil. Si la manette reste coincée, ne pas tenter de la réparer ; appelez un technicien qualifié. Le fait de forcer la manette ou de la réparer peut déclencher une explosion ou un incendie.
- D. N'utilisez pas cet appareil s'il a été plongé dans l'eau, même partiellement. Faites inspecter l'appareil par un technicien qualifié et remplacez toute partie du système de contrôle et toute commande qui ont été plongés dans l'eau.

OPERATING INSTRUCTIONS/ INSTRUCTIONS DE FONCTIONNEMENT

- 1. STOP! Read safety information above on this label.
- 2. Set the thermostat to lowest setting.
- 3. Turn off all electric power to the appliance.
- 4. This appliance is equipped with an ignition device which automatically lights the burner. Do <u>not</u> try to light the burner by hand.
- 5. Turn the external boiler manual gas valve handle clockwise to close the gas supply.
- 6. Wait five (5) minutes to clear out any gas. Then smell for gas, including near the floor. If you smell gas, STOP! Follow "B" in the safety information above on this label. If you don't smell gas, go to the next step.
- 7. Turn the external boiler manual gas valve handle counterclockwise to open the gas supply.

 8. Turn on all electric power to the appliance.
- 9. Set the thermostat to the desired setting.
- 10. If the appliance will not operate, follow the instructions "To Turn Off Gas To Appliance" and call your service technician or gas supplier.

- 1. ARRÊTEZ ! Lisez les instructions de sécurité sur la portion supérieure cette étiquette.
- 2. Réglez le thermostat à la température la plus basse.
- 3. Coupez l'alimentation électrique de l'appareil.
- 4. Cet appareil est équipé de l' dispositif d'allumage qui automobile allume maticallyle brûleur. Ne tentez pas d'allumer le brûleur manuellement.
- 5. Tourner la chaudière externe manuelle poignée 🕕 en clapet à gaz dans le sens des aiguilles d'une montre pour fermer l'offre de gaz.
- 6. Attendre cing (5) minutes pour laisser échapper tout le gaz. Reniflez tout autour de l'appareil, y compris près du plancher, pour déceler une odeur de gaz. Si vous seutez une odeur de gaz, ARRÊTEZ ! Passez à l'étape B des instructions de sécurité sur la portion supérieure de cette étiquette. S'il n'y a pas d'odeur de gaz, passez à l'étape suivante.
- 7. Tourner la chaudière externe manuelle compteur de poignée n clapet à gaz ouvrir dans le sens des aiguilles d'une montre le gaz approvisionnement.
- 8. Mettez l'appareil sous tension.
- 9. Réglez le thermostat à la température désirée.
- 10. Si l'appareil ne se met pas en marche, suivez les instructions intitulées « Comment couper l'admission de gaz de l'appareil » et appelez un technicien qualifié ou le fournisseur de gaz.

OPEN/OUVERT CLOSED/FERMÉ





TO TURN OFF GAS TO APPLIANCE/ COMMENT COUPER L'ADMISSION DE GAZ **DE L'APPAREIL**

- 1. Set the thermostat to lowest setting.
- 2. Turn off all electric power to the appliance if service is to be
- 3. Turn the external boiler manual gas valve handle clockwise to close gas supply.
- 1. Réglez le thermostat à la température la plus basse.
- 2. Coupez l'alimentation électrique de l'appareil s'il faut procéder à l'entretien.
- 3. Tourner la chaudière externe manuelle poignée 🔨 en clapet à gaz dans le sens des aiguilles d'une montre pour fermer l'offre de gaz.

101607-03

Figure 22: Operating Instructions

XIII. System Start-up(continued)

 Verify O₂ (or CO₂) and CO concentration are within limits specified in Table 34. Note: the values in this table are for sea level only. For high altitude installation, above 2000 ft. consult factory.




Figure 23: Gas Valve Air-to-Fuel Adjustment

Table 34: Combustion O₂/CO₂ Levels

	Natura	al Gas	LP Gas		
CTDW Model	CO ₂ %	O ₂ %	CO ₂ %	O ₂ %	
1250	8.4-9.5	4.0-6.0	9.8-11.1	4.0-6.0	
1500	8.4-9.5	4.0-6.0	9.8-11.1	4.0-6.0	

C. Combustion Air/Fuel Adjustment

- 1. For high fire adjustment
- a. Lock the appliance in high fire and allow fan speed and combustion analyzer reading to stabilize before taking combustion readings. To lock in high fire, select MAIN MENU >> OPERATION. Select lock symbol, type password and select ENTER. From the Operation screen, select Automatic / Manual Firing Rate Control >> Manual Modulation. Go back to Operation screen. Then select High Low >> High.
- b. Once high fire rate is reached, adjust the O₂ level at high fire with all the jackets, including the front cabinet door, closed.
- c. For appliances specified to be less than 20 ppm NOx adjust O₂ level to approximately 6.0% (Natural gas).
- d. If high fire O₂ is too high (CO₂ is too low), decrease O₂ (increase CO₂) by turning the throttle screw towards the "Plus (+)" sign in 1/4 turn increments and checking the O₂ (or CO₂) after each adjustment. Refer to Figure 23 for location of throttle screw. Verify CO air free is less than 200 ppm.

2. For low fire adjustment

- a. Lock appliance in low fire and allow fan speed and combustion analyzer reading to stabilize before taking combustion readings. To lock in low fire, select High Low >> Low.
- b. If low fire O_2 is too low (CO_2 is too high), increase O_2 (decrease CO_2) by turning the offset screw towards the "Minus (-)" sign in less than 1/8 turn increments and checking the O_2 (or CO_2) after each adjustment. Verify CO concentration is less than 200 ppm.
- c. If low fire O_2 is too high (CO_2 is too low), decrease O_2 (increase CO_2) by turning the offset screw towards the "Plus (+)" sign in 1/4 turn increments and check O_2 (or CO_2) after each adjustment. Verify CO air free is less than 200 ppm.
- d. Verify O₂ repeatability by modulating to high and low fire three times.
- e. Once the appliance is operating within the specified high and low fire ranges, record emissions, flue draft, and other important data.
- f. Compare emission data to the factory emissions report posted on the back of the front jacket panel.
- Return the appliance to Automatic Mode. From Operation screen, select Automatic / Manual Firing Rate Control >> Automatic Modulation. Select HOME to return to the Home Screen.

D. Field Conversion of Gas Type

This appliance is factory tested and set up for the gas type selected but can be field converted with the following steps.

- Connect the new gas supply to the appliance, check for leaks, and purge the gas line in accordance with the National Fuel Gas Code, ANSI Z223.1/NFPA 54 and/or Natural Gas and Propane Installation Code, CAN/CSA B149.1 or the requirements of the authority having jurisdiction.
- 2. Adjust the throttle screw towards negative (-) all the way to the closed position. Then, open the throttle with the number of turns for the gas type and model as given in Table 35.
- 3. Start the appliance using operating instructions in Figure 22. Even if the gas line has been completely purged of air, the burner may fail to ignite. If burner does not light, turn the throttle towards positive (+) in 1/4 turn increments, allowing at least three tries for ignition at each setting, until ignition is achieved.
- 4. Use a combustion analyzer and follow the Air/ Fuel adjustment instructions to set up high fire and low fire.
- 5. Fill out the gas conversion labels included with the appliance (Order part number 110301-01 if not included). Follow the instructions included with the label for placement.

A WARNING

Make sure that all adjustments at high fire are made with the throttle, not offset screw.

The offset screw has been factory set using precision instruments and must never be adjusted in the field unnecessarily.

Attempting to adjust the offset screw could result in damage to the gas valve and may cause property damage, personal injury or loss of life.

This appliance is tested at the factory and adjustments to the air fuel mixture are normally not necessary. Improper gas valve or mixture adjustments could result in property damage, personal injury or loss of life.

Table 35: Approximate Throttle Screw Position for Gas Types

CTDW	Number of turns from closed					
Model	Natural Gas	LP Gas				
1250	2	1				
1500	5	2.5				

E. Pump Control

Ensure the appropriate pump parameters are selected in the Pumps menu of the Concert control. Refer to the Concert Control manual for more information.

F. Check Thermostat Operation

Verify that the appliance starts and stops in response to calls for hot water. Make sure that the appropriate circulator(s) start and stop.

G. Adjust Supply Water Temperature

As shipped, the central heat and DHW setpoint is 180°F (82.2°C). If necessary, adjust this to the appropriate settings for the system to which this appliance is connected. For information on how to adjust the set point, refer to the "Setup and Tuning" section of the Concert™ Control manual.

1. For a hot water supply boiler supplying domestic hot water, at the factory setting, a mixing valve is required to control the supply water at a temperature that will not cause scalding.

H. Testing of Controls and Safety Devices

Prior to placing the appliance in operation, the installing contractor or other responsible personnel must perform safety and control device limit tests to ensure proper operation of the appliance. Refer to Table 36 for recommended method(s) of carrying out these safety limit devices tests.

Table 36: Safety Device Test

Component	Test Method(s)	After Lockout Annunciation	Actual Alarm Message
High Gas Pressure Switch	Close the manual gas valve between the gas valve and the blower. Cycle the power.	Manually reset the Concert Control and switch. Adjust the switch to its normal setting.	Hard Lockout. Gas Pressure Switch
Low Gas Pressure Switch	Increase the setting of the switch until the switch trips.	Manually reset the Concert Control and switch. Adjust the switch to its normal setting.	Hard Lockout. Gas Pressure Switch
Vestibule Thermal Fuse	Disconnect one wire of the thermal fuse. Cycle the power.	Re-connect wiring to the thermal fuse. Reset thermal fuse lockout.	Hard Lockout. Thermal Fuse
Blocked Condensate Switch	Disconnect one wire of the blocked condensate switch. Cycle the power.	Re-connect wire to the blocked condensate switch. Reset the blocked condensate switch lockout.	Hard Lockout. Blocked Condensate switch
Low Water Cutoff	While the appliance is running push and hold the LWCO test button until the control shuts down the main burner.	Manually reset the Concert Control and reset the LWCO by pressing the reset button.	Hard Lockout. Low Water Level.
Water Flow Switch	Reduce the water flow rate with a manual shutoff valve until the appliance shuts down.	Adjust manual valve to normal position.	Low Water Flow

IMPORTANT PRODUCT SAFETY INFORMATION REFRACTORY CERAMIC FIBER PRODUCT

A WARNING

The Repair Parts list designates parts that contain refractory ceramic fibers (RCF). RCF has been classified as a possible human carcinogen. When exposed to temperature above 1805 °F, such as during direct flame contact, RCF changes into crystaline silica, a know carcinogen. When disturbed as a result of servicing or repair, these substances became airborne and, if inhaled, may be hazardous to your health.

AVOID Breathing Fiber Particulates and Dust

Precautionary Measures:

Do not remove or replace RCF parts or attempt any service or repair work involving RCF without wearing the following protective gears:

- 1. A National Institute for Occupational Safety and Health (NIOSH) approved respirator
- 2. Long sleeved, loose fitting clothing
- 3. Gloves
- 4. Eve Protection
 - Take steps to assure adequate ventilation
 - Wash all exposed body area gently with soap and water after contact.
 - Wash work clothes separately from other laundry and rinse washing machine after use to avoid contaminating other clothing.
 - Discard used RCF components by sealing in an airtight plastic bag. RCF and crystalline silica are not classified as hazardous wastes in the United State and Canada.

First Aid Procedures:

- If contact with eyes: Flush with water for at least 15 minutes. Seek immediate medical attention if irritation persists.
- If contact with skin: Wash affected area gently with soap and water. Seek immediate medical attention if irritation persists.
- If breathing difficulty develops: Leave the area and move to a location with clean fresh air. Seek immediate medical attention if breathing difficulties persist.
- Ingestion: Do NOT induce vomiting. Drink plenty of water. Seek immediate medical attention.

A. General Maintenance

- 1. Keep the area around the appliance free from combustible materials. (Gasoline and other flammable vapors and liquids)
- 2. Keep the area around the combustion air inlet terminal free from contaminants.
- 3. Keep the boiler room ventilation orifices open and unobstructed.
- 4. Remove front jacket panel and check minimum and blocked vent switches for cracks and check pressure sensing line connections.
- 5. Vacuum any sediment and dust from the interior and components.

B. Monthly Inspection

- Inspect the vent piping and outside air intake piping to verify they are open, unobstructed, and free of leakage or deterioration. Check screens in vent and air intake terminations to verify they are clean and free of debris.
- 2. Inspect the condensate drain system to verify it is leak proof, open and unobstructed. Call the service technician if the condensate drain system requires maintenance.
- Inspect water and gas lines to verify they are free of leaks.

C. Annual Inspections and Service

In addition to the inspection listed above the following should be performed by a service technician once every year.

1. Water flow switch

- a. Test the flow switch by disabling the appliance's primary loop circulator. The appliance must not start when there is no flow of water.
- Remove flow switch and visually inspect paddle length. The markings on the flow switch should correspond to the model size to witch it is installed.

A WARNING

Read and understand the entire manual before attempting installation, start-up, operation, or service. Installation and service must be performed only by an experienced and skilled installer or service agency.

This appliance requires regular maintenance and service to operate safely. Follow the instructions contained in this manual. Improper installation, adjustment, alteration, service, or maintenance can cause property damage, personal injury or loss of life.

A clean and unobstructed venting system is necessary to allow noxious fumes that could cause injury or loss of life to vent safely, and will contribute toward maintaining the appliance's efficiency.

Installation is not complete unless a temperature and pressure relief valve is installed in the tapping located on the water manifold or supply piping. Refer to piping section of the manual.

If damage due to frozen pipes is a possibility, the piping system should be not left unattended in cold weather; or appropriate safeguards and alarms should be installed on the heating system to prevent damage if the appliance is inoperative. Do not unscrew any pipe fittings nor attempt to disconnect any components on this appliance without positively assuring the water is cool and has no pressure. Always wear protective clothing and equipment when installing, starting up, or servicing this appliance to prevent scald injuries.

A CAUTION

Caution: Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation.

Verify proper operation after servicing.

XIV. Service and Maintenance (continued)

2. Igniter Electrode

- a. Disconnect power to the unit and remove ignition electrode from the burner door.
- Visually inspect igniter assembly (ceramic insulators, bracket, and graphite gasket) for damage. Replace igniter assembly if the electrodes are deformed or ceramic insulators are cracked.




Figure 24: Igniter Electrode Assembly




Figure 25: Igniter Electrode Gap

- c. Remove any excess oxide deposits from the surface of the igniter with steel wool or emery cloth. Do not use sandpaper.
- d. Ensure there is a 0.17" (4.5 mm) gap between the tips of the electrode.
- e. Install igniter electrode in the orientation shown in Figure 24; otherwise, the unit will not light.
- f. After reinstalling the igniter, make sure there is a ¾ inch gap between the igniter and the burner surface.
- g. Inspect ultra-violet (uv) scanner lens and remove any debris with soft cloth and make sure the hole is clear from scanner to burner.

A DANGER

This appliance uses flammable gas, high voltage electricity, moving parts, and very hot water under high pressure. Ensure that all gas and electric power supplies are off and that the water temperature is cool before attempting any disassembly or service. Do not attempt any service work if gas is present in the air around the appliance. Never modify, remove or tamper with any control device.

A WARNING

This appliance contains components that become very hot when the operating. Do not touch any components unless they are cool.

This appliance contains materials of construction, products of combustion and the fuel contain alumina, silica, heavy metals, carbon monoxide, nitrogen oxides, aldehyde and/or other toxic or harmful substances which can cause death or serious injury and which are known to the state of California to cause cancer, birth defects and other reproductive harm. Always use proper safety clothing, respirators, and other safety equipment when servicing or working near the appliance.

Failure to follow all instructions in the proper order can cause personal injury or death. Read all instructions, including all those contained in component manufacturers manuals which are provided with the appliance before installing, starting up, operating, maintaining, or servicing.

All cover plates, enclosures and guards must be in place at all times.

If any controls are replaced, they must be replaced with identical models.

If any electrical wires are disconnected during service, clearly label the wires and assure that the wires are reconnected properly.

Never jump out or bypass any safety or operating control or component.

Interior of the venting system must be inspected and clean before the initial startup and should be inspected periodically for any obstructions.

XIV. Service and Maintenance (continued)

3. UV Scanner/ Flame Sensor

a. Inspect ultra-violet (uv) scanner lens and remove any debris with a soft cloth. If condensate or fog is observed on the glass, the gaskets may need to be replaced.




Figure 26: UV Scanner Assembly

4. Burner and Combustion Chamber

- a. To gain access to burner and combustion chamber, first remove front jacket panel and then disconnect gas inlet pipe from the gas valve at the union connection.
- b. Remove the front left side jacket panel.
- c. Remove all eight bolts (M10 x 40) used to fasten the burner door to the heat exchanger.
- d. This unit is equipped with a sliding mechanism shown in Figure 27. Position (1) the burner assembly slides out of the combustion chamber, (2) rotate away from the combustion chamber and (3) sliding back to allow full access to the combustion chamber for inspection and service.
- Gently blow compressed air over the burner surface and door insulation to remove lint and debris. Replace burner if the surface shows any signs of damage due to improper handling or gas valve combustion settings.
- f. Do not use acid or alkali products or metallic brush to clean the heat exchanger coils. Follow these guidelines to clean the heat exchanger:
 - i. Spray the heat exchanger coils with white vinegar (acetic acid) and then flush it with clean water after 20 minutes.

A DANGER

Failure to properly secure the burner/blower/gas valve assembly to the heat exchanger could lead to property damage, personal injury or loss of life.

Read, understand and follow all the instructions and warnings contained in ALL of the component instruction manuals.

Assure that all limits and operating controls and components are operating properly before placing the appliance back in service.

Annually inspect all vent gaskets and replace any exhibiting damage or deterioration.

NOTICE

This appliance has a limited warranty, a copy of which is included in shipping. It is the Responsibility of the installing contractor to see that all controls are correctly installed and are operating properly when the installation is complete.

Warranty does not cover damage or malfunction if the steps mentioned in this manual are not performed at the intervals specified.

Water leaks can cause severe corrosion damage immediately repair any leaks found.




Figure 27: Burner Door Opening

ii. Do not spray burner, combustion chamber divider, or burner door insulations .

5. Flue outlet connection

a. Visually inspect flue outlet gasket for damage or deterioration, replace if necessary.

XIV. Service and Maintenance (continued)

- b. Any accumulation of soot or debris should be thoroughly cleaned out.
- 6. Combustion air filter with air box
 - a. Undo the latches on the filter box to lift the lid and access the filter.
 - b. Clean the filter of dust and debris using compress air or water.
 - Replace filter if it appears damaged or deteriorated.
 - d. Reinstall filter and lid.
- 7. Combustion air filter without air box
 - a. Remove air intake pipe to gain access to the filter. Blow compressed air though the filter to remove dust and debris.
 - b. Replace filter if it appears damaged or deteriorated.
 - c. Reinstall air filter and intake pipe.
- 8. Insulations and gaskets
 - a. Visually inspect the following gaskets: flue outlet, blower, burner, and burner door.

D. Restarting after Prolong Shutdown

After prolonged shutdown, it is recommended that the steps in "System Start-up" and "Service and Maintenance" in this manual be performed.

E. Troubleshooting

Refer to the troubleshooting section in the Concert[™] Control manual on how to navigate the Limit String Status screen which shows an active safety limit status and for an in-depth guide to all the possible lockouts as well as recommended corrective actions to restore operation.

APPENDIX A: Tables

I.	Hazard	Definitions	4
II.	Read B	efore Proceeding	5
III	. Produ	ct Rating, Specifications, and Dimensiona	<u> </u>
Da	ıta		7
	Table 1:	Citadel Water Heater Ratings	7
	Table 2:	Citadel Water Heater Specifications	7
	Table 3:	Product Dimensions	8
IV.	Citade	l Water Heater Component Identification	<u>10</u>
V.	Unpack	ing The Citadel	13
VI	. Pre-In	stallation and Mounting	<u>14</u>
	Table 4:	Corrosive Combustion Air Contaminants	15
	Table 5:	Clearances for Serviceability	16
VI	I. Venti	ng	17
	Table 6:	Vent and Combustion Air Pipe Diameters and	
	Maximum		18
	Table 7:	Equivalent lengths of Vent and Combustion Air	
	Compone		19
	Table 8:	Vent and Combustion Air Equivalent Length in Worksheet	19
	Table 9:	Flue Gas and Combustion Air Flow Rates	19
	Table 10:	Approved Vent Manufacturers and Materials	
	Table 11:	Stainless Steel and CPVC Vent Adapters	20
	Table 12:	Polypropylene Vent Adapters	20
	Table 13:	Stainless Steel Vent and Intake Terminations	20
	Table 14:	Polypropylene Vent and Intake Terminations	20
	Table 15:	Recommended Venting Configurations and	
	Material (21
	Table 16:	Direct Vent Terminal Clearances	23
	Table 17:	Other than Direct Vent Terminal Clearances	24
	Table 18:	Table of Acceptable Terminations	25
VI	II. Cond	lensate Disposal	35
	Table 19:	Maximum Condensate Flow	35
	Table 20:	Condensate Neutralizer Kit	36
IX		Piping	37
	Table 21:	Approximate Time for Scalding	39
	Table 22:	Water Quality Requirements	40
	Table 23:	Operating Water Flow Rates	40
	Table 24:	Absolute Water Flow Rates	40
	Table 25:	Temperature rise, flow rate, and head loss	41
	Table 26:	Pumps, Pipe Size, and Total Head Loss	42
X.	Water I	Piping Diagrams	43
	Table 27:	Required Common Piping Sizes for Multiple	
	Appliance	S S	46
XI	. Gas Pi	ping	49
	Table 28:	Maximum capacity of schedule 40 black pipe	
	CFH*		50
	Table 29:	Equivalent Lengths of Standard Pipe Fittings	
_	Valves (ft)		50
	Table 30:	Specific Gravity Correction Factors	51

Table 31:	Inlet Gas Pressures and Pipe Size	51
XII. Electr	ical	52
Table 32:	Electrical Ratings	52
Table 33:	Citadel PCB's	53
XIII. System	m Start-up	58
Table 34:	Combustion O ₂ /CO ₂ Levels	60
Table 35:	Approximate Throttle Screw Position for G	ias
Types		61
Table 36:	Safety Device Test	62
XIV. Service	ce and Maintenance	63

APPENDIX	B: F	igures
----------	------	--------

I. Hazard Definitions	4
II. Read Before Proceeding	5
III. Product Rating, Specifications, and Dimensional Data	7
Figure 1: Citadel water heater dimensions	9
IV. Citadel Water Heater Component Identification	10
Figure 2: Component Identification	11
Figure 3: Component Identification	12
V. Unpacking The Citadel	13
Figure 4: Lifting Lugs	13
VI. Pre-Installation and Mounting	14
VII. Venting	17
Figure 5: Vent Terminal Clearances	22
Figure 6: Horizontal Sidewall Termination	27
Figure 8: Flat Roof Vent Terminations	27
Figure 7: Slopped Roof Termination	27
Figure 9: Multiple Appliance Direct Vent Termination	29
Figure 10: Flexible Vent in Masonry Chimney with Separate Combustion Air Intake	31
VIII. Condensate Disposal	35
Figure 11: Condensate Trap Assembly	35
IX. Water Piping	37
Figure 12: Hot Water Outlet Manifold	37
Figure 13: Heat exchanger water pressure loss	41
X. Water Piping Diagrams	43
Figure 14: Single Water Heater, Single Tank	43
Figure 15: Two Temperatures, Single Water Heater, Single Tank	44
Figure 16: Single Water Heater, Two Tanks	45
Figure 17: Two Water Heaters, Single Tank	46
Figure 18: Two Water Heaters, Two Tanks	47
XI. Gas Piping	49
Figure 19: The Citadel Gas Train	49
Figure 20: High/Low Gas Pressure Switch	51
XII. Electrical	52
Figure 21: Single Phase Wire Diagram	54
Figure 22: Three Phase Wire Diagram	55
XIII. System Start-up	58
Figure 23: Operating Instructions	59
Figure 24: Gas Valve Air-to-Fuel Adjustment	60
XIV. Service and Maintenance	63
Figure 25: Igniter Electrode Assembly	65
Figure 26: Igniter Electrode Gap	65
Figure 27: UV Scanner Assembly	66
Figure 28: Burner Door Opening	66

APPENDIX C: Default Light-off and Modulation Rates

Parameter	CTDW Model			
Faianietei	1250	1500		
Max Power MBTU	1250	1500		
CH/DHW Max. Modulation Rate (RPM) ¹	7600	4600		
Minimum Modulation Rate (RPM)	2000	1250		
Light-off (RPM) ¹	2400	1900		
Maximum Light-off (RPM)	2500	2000		
Minimum Light-off (RPM)	2300	1800		

¹ Factory Default RPM NOTE: To maintain rate in maximum vent length application, contact factory for assistance.

LIMITED WARRANTY FOR CTDW COMMERCIAL CONDENSING WATER HEATERS

Stainless Steel Heat Exchangers and Parts/Accessories

Subject to the terms and conditions set forth below, U.S. Boiler Company, Lancaster, Pennsylvania hereby extends the following limited warranties to the original owner of a commercial grade water heater or U.S. Boiler Company supplied parts and/or accessories manufactured and shipped on or after June 1, 2019:

One Year Limited Warranty On Commercial Water Heaters and Parts / Accessories Supplied by U.S. Boiler Company

U.S. Boiler Company warrants to the original owner that its commercial grade stainless steel water heaters and parts/accessories comply at the time of manufacture with recognized hydronic industry standards and requirements then in effect and will be free of defects in material and workmanship under normal usage for a period of one year from the date shipment. If any part of a commercial grade heater or any part or accessory provided by U.S. Boiler Company is found to be defective in material or workmanship during this one year period, U.S. Boiler Company will, at its option, repair or replace the defective part (not including labor).

Ten Year Heat Exchanger Warranty

U.S. Boiler Company warrants to the original owner that the heat exchanger of its commercial grade stainless steel water heaters will remain free from defects in material, workmanship and thermal shock under normal usage per the product's installation and operation manual for the time period specified in the chart below to the original owner at the original place of installation. If a claim is made under this warranty during the "No Charge" period from the date of shipment, U.S. Boiler Company will, at its option, repair or replace the heat exchanger (not including labor). If a claim is made under this warranty after the expiration of the "No Charge" period from the date of shipment, U.S. Boiler Company will, at its option and upon payment of the pro-rated service charge set forth below, repair or replace the heat exchanger. The service charge applicable to a heat exchanger warranty claim is based upon the number of years the heat exchanger has been in service and will be determined as a percentage of the retail price of the heat exchanger model involved at the time the warranty claim is made as follows:

NOTE: If the heat exchanger involved is no longer available due to product obsolescence or redesign, the value used to establish the retail price will be the published price as set forth in U.S. Boiler Company Repair Parts Pricing where the heat exchanger last appeared or the current retail price of the then nearest equivalent heat exchanger, whichever is greater.

Ten Year Pressure Vessel Shell Warranty

U.S. Boiler Company warrants to the original owner that the pressure vessel shell assembly of its commercial grade stainless steel water heaters will remain free from defects in material and workmanship under normal usage for the time period specified in the chart below to the original owner at the original place of installation. If a claim is made under this warranty during the "No Charge" period from the date of shipment, U.S. Boiler Company will, at its option, repair or replace the pressure vessel (not including labor). If a claim is made under this warranty after the expiration of the "No Charge" period from the date of shipment, U.S. Boiler Company will, at its option, repair or replace the pressure vessel.

NOTE: If the pressure vessel involved is no longer available due to product obsolescence or redesign, the value used to establish the retail price will be the published price as set forth in U.S. Boiler Company Repair Parts Pricing where the heat exchanger last appeared or the current retail price of the then nearest equivalent heat exchanger, whichever is greater.

Service Charge as a % of Retail Price								
Years of Service 1 2 3 4 5 6 7 8 9 10								
Heat Exchanger	NO CHARGE 20 40 60 80 100							
Pressure Vessel Shell		NO CHARGE						

ADDITIONAL TERMS AND CONDITIONS

- 1. Applicability: The limited warranties set forth above are extended only to the original owner at the original place of installation within the United States and Canada. These warranties are applicable only to water heaters, parts, or accessories designated as commercial grade by U.S. Boiler Company and installed and used exclusively for purposes of commercial space heating or domestic hot water generation through a heat exchanger (or a combination for such purposes) and do not apply to residential grade products or industrial uses.
- 2. Components Manufactured by Others: Upon expiration of the one year limited warranty on commercial grade water heaters, all water heater components other than heat exchangers manufactured by others but furnished by U.S. Boiler Company (such as circulator and controls) will be subject only to the manufacturer's warranty, if any.
- 3. Proper Installation: The warranties extended by U.S. Boiler Company are conditioned upon the installation of the commercial grade water heater, parts, and accessories in strict compliance with U.S. Boiler Company installation instructions. U.S. Boiler Company specifically disclaims liability of any kind caused by or relating to improper installation.
- 4. Proper Use and Maintenance: The warranties extended by U.S. Boiler Company conditioned upon the use of the commercial grade water heater, parts, and accessories for its intended purposes and its maintenance accordance with U.S. Boiler Company recommendations and hydronics industry standards. For proper installation, use and maintenance, see all applicable sections of the Installation and Operating, and Service Instructions Manual furnished with the unit.
- 5. This warranty does not cover the following:
- a. Expenses for removal or re-installation. The owner will be responsible for the cost of removing and reinstalling the alleged defective part or its replacement and all labor and material connected therewith.
- a. Expenses for shipping and handling. The owner will be responsible for the cost of transportation and handling to and from U.S. Boiler Company. Alleged defective part must be returned to factory for warranty determination unless authorized in writing otherwise.
- b. Components that are part of the heating system but were not furnished by U.S. Boiler Company as part of the commercial water heater.
- c. Improper burner set-up or adjustment, control settings, care or maintenance.
- d. This warranty cannot be considered as a guarantee of workmanship of an installer connected with the installation of the U.S. Boiler Company water heater, or as imposing on U.S. Boiler Company liability of any nature for unsatisfactory performance as a result of faulty workmanship in the installation, which liability is expressly disclaimed.
- e. Water heaters, parts, or accessories installed outside the 48 contiguous United States, the State of Alaska and Canada.
- f. Damage to the water heater and/or property due to installation or operation of the water heater that is not in accordance with the water heater installation and operating instruction manual.
- i. Any damage or failure of the water heater resulting from hard water, scale buildup or corrosion the heat exchanger. Any damage caused by improper fuels, fuel additives or contaminated combustion air that may cause fireside corrosion and/or c logging of the burner or heat exchanger.
- j. Any damage resulting from combustion air contaminated with particulate which cause clogging of the burner or combustion chamber including but not limited to sheetrock or plasterboard particles, dirt, and dust particulate. Any damage, defects or malfunctions resulting from improper operation, maintenance, misuse, abuse, accident, negligence including but not limited to operation with insufficient water flow, improper water level, improper water chemistry, or damage from freezing.
- k. Any damage caused by water side clogging due to dirty systems, corrosion products from the system, or improperly maintained water conditions.



U.S. Boiler Company, LLC P.O. Box 3020 Lancaster, PA 17604 1-888-432-8887 www.usboiler.net