

Contents

WHAT ARE QUICK-COOK VOICE PRESETS?.....	2
REHEAT	3
BEVERAGES/SOUPS.....	3
REFRIGERATED FOOD.....	4
COOK.....	5
DEFROST	7

Last Updated: November 16, 2018

WHAT ARE QUICK-COOK VOICE PRESETS?

Quick-cook voice presets are microwave settings to reheat, cook or defrost food items. With the AmazonBasics Microwave and an Echo device, you can use presets with simple voice commands instead of pressing multiple buttons on the keypad.

Notes:

- AmazonBasics Microwave does not have built-in sensors to detect the weight or volume of what you would like to cook. For best results when using presets for liquids, specify the volume (for example, “1 cup of coffee”). For best results when using presets for solids, specify the quantity or weight (for example, “1 potato,” or “6 ounces of rice”).
- As with all microwaves, cooking output of presets may vary due to various factors such as input voltage, ambient conditions, starting temperature, humidity levels, etc.
- You can also always use basic voice commands to cook for a specific time or power level, as well as, stop, pause and resume the microwave (for example, “Alexa, microwave for 2 minutes”, “Alexa, microwave for 5 minutes on medium power”, “Alexa, reheat for 3 minutes”, “Alexa, defrost for 5 minutes”, “Alexa, stop the microwave”).
- Additional information about cooking safely with your microwave oven can be found in the [User Manual](#) that came with your microwave (also available at www.amazon.com/devicesupport) or at www.foodsafety.gov.



REHEAT

BEVERAGES/SOUPS

Directions: Place the food item in a microwaveable cup. Use a voice command to start the microwave. Once the microwave stops, let stand for 30 seconds to 1 minute. Carefully remove and stir before consuming.

Quantity range: 0.5 - 3 cups (or 4 – 24 fluid ounces)

Food Item	Voice Command
Coffee	Alexa, Reheat 1 cup of coffee Or press the Ask Alexa button and say: 1 cup of coffee
Water	Alexa, Reheat 1 cup of water Or press the Ask Alexa button and say: 1 cup of water
Milk	Alexa, Reheat 1 cup of milk Or press the Ask Alexa button and say: 1 cup of milk
Hot Chocolate	Alexa, Reheat 1 cup of hot chocolate Or press the Ask Alexa button and say: 1 cup of hot chocolate
Apple Cider	Alexa, Reheat 1 cup of apple cider Or press the Ask Alexa button and say: 1 cup of apple cider
Soup	Alexa, Reheat 1 cup of soup Or press the Ask Alexa button and say: 1 cup of soup
Noodle Soup	Alexa, Reheat 1 cup of noodle soup Or press the Ask Alexa button and say: 1 cup of noodle soup

AMAZONBASICS MICROWAVE QUICK-COOK VOICE PRESETS GUIDE

REFRIGERATED FOOD

Directions: Place the food item in a microwaveable container with vented cover. Use a voice command to start the microwave. For best results, pause midway (e.g. Alexa, pause the microwave) to stir or flip and then resume (e.g. Alexa, resume the microwave). Once the microwave stops, let stand for 1-2 minutes. Carefully remove and stir before consuming as applicable.

Food item	Quantity Range	Voice Command
Rice	3 - 32 ounces	Alexa, Reheat 8 ounces of rice Or press the Ask Alexa button and say: 8 ounces of rice
Pasta	3 - 32 ounces	Alexa, Reheat 8 ounces of pasta Or press the Ask Alexa button and say: 8 ounces of pasta
Mashed Potatoes	3 - 32 ounces	Alexa, Reheat 8 ounces of mashed potatoes Or press the Ask Alexa button and say: 8 ounces of mashed potatoes
Casserole	3 - 32 ounces	Alexa, Reheat 8 ounces of casserole Or press the Ask Alexa button and say: 8 ounces of casserole
Frozen Food	3 - 32 ounces	Alexa, Reheat 8 ounces of frozen food Or press the Ask Alexa button and say: 8 ounces of frozen food
Dinner plate	Default = 1 plate (approx. 12 ounces of food)	Alexa, Reheat 1 dinner plate Or press the Ask Alexa button and say: Dinner plate
Burger	1 - 3 burgers (1 burger = approx. 4 ounces)	Alexa, Reheat 1 burger Or press the Ask Alexa button and say: 1 burger
Sandwich	1 - 2 sandwiches (1 sandwich = approx. 4 ounces)	Alexa, Reheat 1 sandwich Or press the Ask Alexa button and say: 1 sandwich

COOK

Directions: Place the food item in a microwaveable container. Use a voice command to start the microwave. Once the microwave stops, let the food item stand for 1-2 minutes. Carefully remove and stir before consuming as applicable.

Food Item	Quantity Range	Voice Command	Note
Popcorn	1 - 3 ounces	Alexa, Microwave 1.5 ounces of popcorn Or press the Ask Alexa button and say: 1.5 ounces of popcorn	Cook one bag at a time. For best results, fold the edges of the bag and place it at the center of the turntable so that the bag does not touch the inside wall. Remove the bag if the popping sound stops for more than 5-10 seconds or if you observe a burning smell.
Frozen Vegetables	3 - 32 ounces	Alexa, Microwave 6 ounces of frozen vegetables Or press the Ask Alexa button and say: 6 ounces of frozen vegetables	Put a vented cover or a cling film punctured with fork 3 times. Pause midway to stir and resume.
Broccoli	3 - 32 ounces	Alexa, Microwave 6 ounces of broccoli Or press the Ask Alexa button and say: 6 ounces of broccoli	Put a vented cover or a cling film punctured with fork 3 times. Add 1 tablespoon of water for every 6 ounces. Pause midway to stir and resume.
Oatmeal	3 - 12 ounces (represents total weight of dry oatmeal and water/milk)	Alexa, Microwave 6 ounces of oatmeal Or press the Ask Alexa button and say: 6 ounces of oatmeal	Put a vented cover or a cling film punctured with fork 3 times. Add water or milk per manufacturer's instructions. Pause midway to stir and resume. For reference, 1/3 cup of oatmeal and 2/3 cup of water = approx. 6 ounces.
Potato	1 - 4 potatoes (1 potato = approx. 8 ounces)	Alexa, Microwave 1 potato Or press the Ask Alexa button and say: 1 potato	Scrub the potato and prick 6 times with a fork. Pause midway to flip and resume.

AMAZONBASICS MICROWAVE QUICK-COOK VOICE PRESETS GUIDE

<p>Sweet Potato</p>	<p>1 - 4 sweet potatoes (1 sweet potato = approx. 6 ounces)</p>	<p>Alexa, Microwave 1 sweet potato</p> <p>Or press the Ask Alexa button and say: 1 sweet potato</p>	<p>Scrub the sweet potato and prick 6 times with a fork. Pause midway to flip and resume.</p>
<p>Hot dog</p>	<p>1 - 6 hot dogs (1 hot dog = approx. 2 ounces)</p>	<p>Alexa, Microwave 1 hot dog</p> <p>Or press the Ask Alexa button and say: 1 hot dog</p>	<p>Place it on a paper towel-lined plate. Cover with a plastic wrap or another paper towel.</p>
<p>Corn on the cob</p>	<p>1 - 2 corn on the cob (1 corn on the cob = approx. 9 ounces)</p>	<p>Alexa, Microwave 1 corn on the cob</p> <p>Or press the Ask Alexa button and say: 1 corn on the cob</p>	<p>Place it directly on the turntable. Pause midway to flip and resume.</p>

DEFROST

Directions: Place the food item in a microwaveable container. Use the voice command to start the microwave. For best results, pause midway to stir or flip and resume.

Food item	Quantity Range	Voice Command
Corn	3 - 70 ounces	Alexa, Defrost 8 ounces of corn Or press the Ask Alexa button and say: Defrost 8 ounces of corn
Peas	3 - 70 ounces	Alexa, Defrost 8 ounces of peas Or press the Ask Alexa button and say: Defrost 8 ounces of peas
Vegetables	3 - 70 ounces	Alexa, Defrost 8 ounces of vegetables Or press the Ask Alexa button and say: Defrost 8 ounces of vegetables
Broccoli	3 - 70 ounces	Alexa, Defrost 8 ounces of broccoli Or press the Ask Alexa button and say: Defrost 8 ounces of broccoli
Chicken	3 - 70 ounces	Alexa, Defrost 8 ounces of chicken Or press the Ask Alexa button and say: Defrost 8 ounces of chicken
Ground Beef	3 - 70 ounces	Alexa, Defrost 8 ounces of ground beef Or press the Ask Alexa button and say: Defrost 8 ounces of ground beef
Salmon Fillet	3 - 70 ounces	Alexa, Defrost 8 ounces of salmon fillet Or press the Ask Alexa button and say: Defrost 8 ounces of salmon fillet
Pork	3 - 70 ounces	Alexa, Defrost 8 ounces of pork Or press the Ask Alexa button and say: Defrost 8 ounces of pork
Sausage	1 - 6 sausages (1 sausage = approx. 2 ounces)	Alexa, Defrost 1 sausage Or press the Ask Alexa button and say: Defrost 1 sausage