



Worry-Free Guarantee

Your Amazon Fire Kids Edition Tablet ("Fire Tablet") and Amazon Kid-Proof Case ("Kid-Proof Case") are covered by a special Two-Year Limited Warranty in lieu of the standard Limited Warranty for Fire Tablets. Details are available at www.amazon.com/devicesupport.

Safety Information

Parents: Read and explain all instructions and safety information to your child before use.

! FAILURE TO FOLLOW THESE SAFETY INSTRUCTIONS COULD RESULT IN FIRE, ELECTRIC SHOCK, OR OTHER INJURY OR DAMAGE.

The Fire Tablet and its included accessories are not toys. Children should be supervised to ensure proper use.

Parents should also routinely check to confirm that the Fire Tablet shows no signs of damage or breakage and is in safe condition for use by children. The Fire Tablet is not suitable for children under age 3.

DO NOT GET WET. Do not permit anyone to use the Fire Tablet or its accessories in rain, or near sinks or other wet or highly humid locations. Take care to ensure that no food or liquid is spilled on the Fire Tablet or its accessories. If the device does get wet, unplug all cables, turn off the wireless (drag down the Quick Settings menu, tap Wireless & Networks, and turn off Wi-Fi) and let the screen revert to the screen saver. Additionally, ensure that Bluetooth is disabled by accessing the Quick Settings menu, tapping Wireless & Networks, tapping Bluetooth, and tapping Off. Wait for the device to dry completely before pressing the Power

button to wake again. No one should attempt to dry the Fire Tablet or its accessories with an external heat source, such as a microwave oven or hair dryer.

ALWAYS INSPECT FOR BREAKAGE AND USE WITH THE KID-PROOF CASE. The outside cover of the device's screen is made of glass. This glass could break if the device is dropped or receives a substantial impact. If the glass breaks, chips, or cracks, stop all use of the Fire Tablet and do not permit anyone to touch or attempt to remove the damaged glass. To protect against damage, children should always use the Fire Tablet with its Kid-Proof Case. If the device is dropped or impacted, parents should remove the Kid-Proof Case and inspect for damage before putting it back in the Kid-Proof Case and permitting a child to resume use.

AVOID PROLONGED LISTENING AT HIGH VOLUME. At full power, prolonged listening of the player can damage the ear of the user. To prevent possible hearing damage, users should not listen at high volume levels for long periods. Also, users should wear headphones that isolate the wanted audio from background noise. Parents should monitor duration of use and volume levels to ensure appropriate use by children.

WATCH FOR HEALTH RISKS FROM FLASHING LIGHTS OR LIGHT PATTERNS. A small percentage of people may be susceptible to blackouts or seizures (even if they have never had one before) when exposed to flashing lights or light patterns such as when playing games or watching video. If a user has experienced seizures or blackouts or has a family history of such occurrences, consult a physician before the user plays games or watches videos. If a user experiences headaches, blackouts, seizures, convulsions, eye or muscle twitching, loss of awareness, involuntary movement, disorientation, or other discomfort, discontinue that user's use of the device and consult a physician. To reduce the risk of these symptoms, ensure that the user avoids prolonged use, holds the device some distance from the eyes, and takes frequent breaks.

AVOID REPETITIVE USE. Engaging in repetitive motions such as pressing keys or playing some games may cause a user to experience occasional discomfort of the hands, arms, shoulders, neck, or other parts of the body.

! **CHOKING HAZARD – SMALL PARTS**
ALWAYS INSPECT FOR BREAKAGE AND USE WITH THE KID-PROOF CASE. Small parts, such as the door to the SD card slot, could break off and present a choking hazard. The outside cover of the device's screen is made of glass. This glass could break if the device is dropped or receives a substantial impact. If the glass breaks, chips, or cracks, stop all use of the Fire Tablet and do not permit anyone to touch or attempt to remove the damaged glass. To protect against damage and reduce the likelihood of small parts

becoming detached, children should always use the Fire Tablet with its Kid-Proof Case. If the device is dropped or impacted, parents should remove the Kid-Proof Case and inspect for damage before putting it back in the Kid-Proof Case and permitting a child to resume use.

USE CAUTION AROUND PACEMAKERS AND SIMILAR MEDICAL DEVICES. Personal medical devices, such as pacemakers, may be sensitive to magnetic and electromagnetic fields. Since the Fire Tablet contains magnets and emits electromagnetic fields, it should be kept at least 6 inches (approximately 15 cm) from any personal medical device. If any interference is observed, consult with a physician before resuming use.

Power Adapter Safety

EXERCISE CAUTION WHEN USING THE POWER ADAPTER. The Fire Tablet is shipped with an AC adapter. Parents should not permit children to connect or handle the AC Adapter or USB cable until they are old enough to do so safely. The Fire Tablet should only be charged using the AC adapter and USB cable included with the device, or another USB cable approved for use with the Fire Tablet, with a compatible USB charger or USB port that meets the following requirements: USB-IF Battery Charging Spec, Rev 1.2. To reduce the risk of fire or electric shock when using the AC adapter, carefully follow these instructions:

- Do not force the adapter into a power outlet.
- Do not expose adapter or cable to liquids.
- If the adapter or cable appears damaged, discontinue use immediately.

Power adapter designed only for use with Fire devices. The AC adapter with its included cable could present a strangulation hazard. Keep out of reach of young children.

Battery Safety

HANDLE WITH CARE. The Fire Tablet contains a rechargeable lithium polymer battery and should be replaced only by an authorized service provider. Do not disassemble or open, crush, bend or deform, puncture, or shred the battery. Do not modify or remanufacture the battery, attempt to insert foreign objects into the battery, or immerse or expose it to water or other liquids, fire, explosion, or hazard. Do not short circuit a battery or allow metallic conductive objects to contact battery terminals. Avoid dropping the device or battery. If the device or battery is dropped, especially on a hard surface, and the user suspects damage, take it to a service center for inspection.

More Information

Additional safety and other important information can be found in the Legal & Compliance section of the Settings menu on the Fire Tablet.

© 2015 Amazon.com, Inc. or its affiliates. All rights reserved.
Amazon and Fire are trademarks of Amazon.com, Inc. or its affiliates.

