

# PART LIST—Model No. DR705220

Rev. 1/93

Key No.	Qty.	Description	Key No.	Qty.	Description
1	1	Left Upper Body Arm w/Foam	43	1	Motor Pivot Bolt
2	1	Right Upper Body Arm w/Foam	44	1	Motor Mount Plate
3	1	Clothes Clip	45	4	Motor Mount Isolator
4	1	Pulse Earclip	46	1	Motor
5	1	Safety Key/Clip	47	1	Motor Ground Strap
6	21	Screw	48	1	Pulley/Flywheel/Fan
7	1	Console	49	2	Foot Rail
8	1	Speed Control Knob	50	2	Roller Spacer
9	1	Incline Lever	51	2	Incline Leg Bolt
10	1	Upright	52	1	Incline Leg
11	1	Lock Pin	53	1	Frame
12	1	Controller	54	1	Walking Platform
13	6	Hood Screw/Foot Rail Screw	55	6	Platform Screw
14	1	Motor Hood w/Decal	56	3	Roller Adjustment Washer
15	1	Resistance Control	57	1	Front Roller Adjustment Bolt
16	2	Friction Bracket	58	1	Front Roller/Pulley
17	2	Nylon Washer	59	1	Walking Belt
18	4	Hood Bracket Screw	60	8	Foot Rail Fastener
19	2	Friction Plate	61	1	Rear Leg Pad
20	1	Incline Cable	62	1	Right Endcap
21	3	Nut	63	5	Endcap Screw/Switch Screw
22	1	Tension Spring	64	2	Rear Roller Adjustment Bolt
23	2	Tension Washer	65	1	Wrench Clip
24	1	J-Bolt	66	1	Allen Wrench
25	4	Hood Bracket	67	1	Rear Roller
26	1	Circuit Breaker	68	3	Roller Guard
27	1	Grommet	69	2	Guard Screw
28	1	Ground Washer	70	2	Belt Guide
29	1	Choke	71	1	Left Endcap
30	1	Power Cord	72	1	Magnet
31	8	Motor Pan Screw	73	1	Reed Switch/Sensor Wire
32	1	Motor Pan	74	8	Motor Nut
33	3	Lock Nut	75	1	Belt
34	2	Front Wheel	76	6	Wire Clip
35	2	Wheel Bolt	77	1	Lock Knob
36	1	Shock Release	78	1	Lock Knob Washer
37	1	Shock Bracket	79	1	Friction Cover
38	1	E-Clip	80	1	Pivot Bolt
39	2	Shock Cushion	81	2	Upper Body Arm Foam Grip
40	1	Incline Shock	#	1	Owner's Manual
41	1	Shock Pin	#	1	Fitness Journal
42	1	Cotter Pin			

Note: "#" indicates a non-illustrated part. Specifications are subject to change without notice. See the back cover of this manual for information about ordering replacement parts.

# EXPLODED DRAWING—Model No. DR705220

Rev. 1/93

