

LifestylerTM


2600 VLP

- ▲ INTERACTIVE VIDEO TRACK
- ▲ 0-6 MPH/INCLINE LIFT ASSIST
- ▲ ONE HORSEPOWER DC MOTOR

Model No. 831.296600

Serial No. _____

Serial Number Decal



QUESTIONS?

As a manufacturer, we are committed to providing you complete customer satisfaction. If you have questions, or find there are missing or damaged parts, we will guarantee you complete satisfaction through direct assistance from our factory. TO AVOID UNNECESSARY DELAYS, PLEASE CALL DIRECT TO OUR TOLL-FREE CUSTOMER HOT LINE. The trained technicians on our Customer Hot Line will provide immediate assistance, free of charge to you.

CUSTOMER HOT LINE:

1-800-999-3756

Mon.-Fri., 6 a.m.-6 p.m. MST.

CAUTION:

Read all safety precautions and instructions in this manual carefully before using this equipment. Save this manual for future reference.

OWNER'S MANUAL



SEARS[®]

SOLD BY SEARS, ROEBUCK AND CO., CHICAGO, IL 60684

FULL 90 DAY WARRANTY ON PARTS

For 90 days from the date of purchase, when proper assembly and maintenance procedures detailed in the Owner's Manual are followed, Sears will, free of charge, repair or replace and install a replacement part for any defective part, when the Treadmill is used in a normal manner.

This warranty does not apply when the Treadmill is used for commercial or rental purposes.

SERVICE IS AVAILABLE SIMPLY BY CONTACTING YOUR NEAREST SEARS SERVICE CENTER/DEPARTMENT IN THE UNITED STATES.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

SEARS, ROEBUCK AND CO., DEPT. 731CR-W, CHICAGO, IL 60684

LifestylerTM

2600 VLP

- ▲ INTERACTIVE VIDEO TRACK
- ▲ 0-6 MPH / INCLINE LIFT ASSIST
- ▲ ONE HORSEPOWER DC MOTOR

TABLE OF CONTENTS

Warranty	2
Important Safety Precautions	4
Before You Begin	5
Assembly	6
Operation and Adjustment	6
Maintenance and Trouble-Shooting	10
Conditioning Guidelines	12
Part List	14
Exploded Drawing	15
Ordering Replacement Parts	Back Cover

WARNING: Before beginning this or any exercise program, consult your physician. This is especially important for individuals over the age of 35 or persons with pre-existing health problems. Read all instructions before using. Sears assumes no responsibility for personal injury or property damage sustained by or through the use of this product.

IMPORTANT SAFETY PRECAUTIONS

WARNING: To reduce the risk of burns, fire, electric shock or injury to persons, read the following important safety precautions and information before operating the treadmill.

1. Position the treadmill on a level surface, with at least 8 feet of clearance behind the treadmill. Do not place the treadmill on thick carpet, near water or outdoors. Do not operate where aerosol products are used or where oxygen is being administered.
2. Plug the power cord directly into a grounded circuit carrying 12 or more amps. No other appliance should be on the same circuit. (See the OPERATION AND ADJUSTMENT section of this manual for proper grounding instructions.) Keep the power cord away from heated surfaces. If an extension cord is required, use only a 14-gauge, general-purpose cord of six to ten feet in length with a three-wire conductor.
3. Never move the walking belt while the power is turned off. Do not operate the treadmill if the power cord or plug are damaged, or if the treadmill is not working properly. (Refer to the BEFORE YOU BEGIN section of this manual if the treadmill is not working properly.)
4. Wear appropriate exercise attire when using the treadmill. Do not wear loose clothing that could become caught in the treadmill. *Always wear running or aerobic shoes. Never use the treadmill with bare feet, wearing only stockings, or in sandals.* Athletic support clothes are recommended for both men and women.
5. Never start the treadmill while you are standing on the walking belt. Always hold the side rail when exercising on the treadmill.
6. Never allow more than one person on the treadmill at a time. Use the treadmill only as described in this manual.
7. Keep small children away from the treadmill during operation. Never leave the treadmill unattended while it is running. Always turn the power off when the treadmill is not in use.
8. Never drop or insert any object into any opening.
9. Always unplug the power cord before performing the maintenance and adjustment procedures described in this manual. Never remove the motor hood unless instructed to do so by an authorized service representative. Servicing other than the procedures described in this manual should be performed by an authorized service representative only.


SAVE THESE INSTRUCTIONS

BEFORE YOU BEGIN

Thank you for selecting the Sears Lifestyler 2600 VLP treadmill. The Lifestyler 2600 VLP combines advanced technology and innovative styling to offer you an excellent form of cardiovascular exercise in the convenience and privacy of your home. Your workouts on the Lifestyler 2600 VLP will be more enjoyable with such features as adjustable incline, electronic speed control and a state-of-the-art console with an interactive video track mode.

For your safety and benefit, **read this manual carefully before using this equipment.** If you have additional questions, please call our Customer Service Department toll-free at **1-800-999-3756**, Monday through Friday, 6 a.m. until 6 p.m. Mountain Time (excluding holidays). In all communications regarding this product, please refer to your product model number and serial number. The model number is printed on the front cover of this manual. The serial number is recorded on a decal affixed to the product (see the drawing on the front cover for the location).

Before reading further, please review the drawing below and familiarize yourself with the parts labeled.




ASSEMBLY

Set the treadmill in a cleared area and remove the packing materials. **Make sure that all parts are included before disposing of the packing materials.** Read each step carefully before beginning. Assembly can be completed using a standard screwdriver (not included).

1. Raise the Upright Post (13) to a vertical position. Insert the Lock Knob (25), with the Lock Knob Washer (24) into the Upright Post, and turn the Knob clockwise until almost tight. Leave a little play in the Upright Post for the following steps.
2. Insert the upper end of the Left Side Rail (1) into the opening in the left side of the Console (10). Insert the Short Side Rail Bolt (12) through the metal plate under the Console, and tighten the Bolt into the Left Side Rail. Repeat with the Right Side Rail (2). Note: If the Side Rails cannot be inserted into the Console far enough to reach the Bolts, roll back the Foam Grips (3) slightly.
3. Align the hole in the lower end of the Right Side Rail (2) with the hole in the Frame (47). Insert the Long Side Rail Bolt (14) through the Right Side Rail and Frame. Reach under the Frame and thread the Flange Nut (67) onto the end of the Bolt. Repeat with the Left Side Rail (not shown). Tighten the Lock Knob (see step 1).
4. Slide the Cable Clamp (78) onto the VCR Cable (76). Attach the Cable Clamp to the underside of the Console (10) with a Screw (11). Plug the VCR Cable into the jack on the underside of the Console.

Make sure that all parts are tightened securely before using the treadmill.




OPERATION AND ADJUSTMENT

GROUNDING INSTRUCTIONS

This product must be grounded. If it should malfunction or break down, grounding provides a path of least resistance for electric current to reduce the risk of electric shock. This product is equipped with a cord having an equipment-grounding conductor and a grounding plug. **The plug must be plugged into an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances.**


DANGER: Improper connection of the equipment-grounding conductor can result in a risk of electric shock. Check with a qualified electrician or serviceman if you are in doubt as to whether the product is properly grounded. Do not modify the plug provided with the product - if it will not fit the outlet, have a proper outlet installed by a qualified electrician.

This product is for use on a nominal 120-volt circuit, and has a grounding plug that looks like the plug illustrated in Drawing 1. A temporary adapter that looks like the adapter illustrated in Drawing 2 may be used to connect this plug to a 2-pole receptacle as shown in Drawing 2 if a properly grounded outlet is not available. The temporary adapter should be used only until a properly grounded outlet (Drawing 1) can be installed by a qualified electrician. The green colored rigid ear, lug, or the like extending from the adapter **must be** connected to a permanent ground such as a properly grounded outlet box cover. Whenever the adapter is used it **must be** held in place by a metal screw. **Some 2-pole receptacle outlet box covers are not grounded. Contact a qualified electrician to determine if the outlet box cover is grounded before using an adapter.**




SILICONE APPLICATION

To reduce the friction of the walking belt, and lessen wear, a non-oil, non-petroleum based silicone lubricant should be applied generously to the walking platform. Silicone lubricant is available at most hardware and automotive stores. **It is very important to apply silicone lubricant before initial use of the treadmill.** It should be re-applied after every 10 hours of use, or whenever a decrease in performance is noticed. **TURN THE POWER OFF**, lift each side of the walking belt and apply the silicone lubricant generously to the area indicated.



INCLINE ADJUSTMENT

1. **TURN THE POWER OFF.** Remove the hitch pins from the left and right incline legs. Note: The hitch pins have been inserted from the inside for shipping purposes.
2. Grasp the lock knob, and raise or lower the treadmill to the height desired.
3. Insert the hitch pins through the incline legs from the outside as shown. The pins must be in the same holes in both legs.




CONNECTING THE VCR CABLE

In order to use the video track mode of the console, you must have a television, and a video cassette player with a standard "audio out" jack. One end of the VCR cable must be plugged into the jack on the underside of the console. Plug the other end of the VCR cable into the "audio out" jack on your video cassette player.

DIAGRAM OF THE CONSOLE

Read all instructions carefully before operating the console.



DESCRIPTION OF THE CONTROLS

VIDEO TRACK BUTTON- This button switches the console to the video track mode. The VCR indicator will light when the console is in the video track mode.

SET BUTTONS- These buttons are used to enter your weight into the console, and to set time and distance goals.

MODE BUTTON- This button is used to select monitor modes.

START/PAUSE BUTTON- This button starts and stops the console. The mode indicators will flash when the console is stopped.

SPEED DIAL- This dial is used to control the speed of the walking belt, and to select a fitness level for the video track mode.

TURNING ON THE POWER

Stand on the foot rails of the treadmill. **Do not stand on the walking belt.** Attach the clip on the safety key to your waistband. (Note: Always wear the clip when operating the treadmill. If you fall while exercising, the safety key will be pulled from the console, instantly turning off the power.) Insert the safety key into the slot in the front of the console. **After inserting the safety key, wait for 3 seconds before operating the console, or the walking belt cannot be started.**

MANUAL SPEED ADJUSTMENT MODE

When the power is turned on, the console will be in the manual mode, and the walking belt will be stationary. To start the walking belt, first turn the speed dial to the reset position. Next, turn the dial clockwise until the walking belt begins to move at slow speed. Step carefully onto the walking belt and begin exercising. As you exercise, the speed of the walking belt can be changed as desired by turning the dial. To stop the walking belt, turn the dial to the reset position. **Note: Each time the walking belt is stopped, the speed dial must be turned to the reset position before the walking belt can be started.**

The walking belt can also be stopped by pressing the START/PAUSE button. This will stop the console. To start the walking belt after the console has been stopped, turn the speed dial to the reset position, press the START/PAUSE button, and then turn the dial clockwise until the walking belt begins to move.

VIDEO TRACK MODE

In the video track mode, a video program will guide your workout, controlling the speed of the walking belt automatically to simulate changing terrain. As you exercise, the video program will take you on a scenic tour of majestic Canyonlands in Southern Utah, accompanied by an original music soundtrack. (Additional video cassettes featuring other locations are available for purchase.)

Turn on your television and video cassette player, and start the video cassette. The video program consists of three parts: a 4-minute warm-up, a 20-minute workout, and a 3-minute cool-down. After you have completed the 4 minute warm-up, step onto the foot rails of the treadmill and attach the clip on the safety key to your waistband. Be sure the console power is turned on. Press the VIDEO TRACK button, turn the speed dial to the reset position, and then press the START/PAUSE button. Next, turn the speed dial clockwise to select a "fitness level" for the 20-minute workout. The farther the dial is turned, the more challenging the workout will be. When the workout starts, the walking belt will begin to move. Step carefully onto the walking belt and begin exercising. A graph will appear on the upper left of your television screen. As you exercise, a colored line will move along the graph, showing your progress. When the colored line rises, the speed of the walking belt will increase. When the colored line drops, the speed will decrease. An audible tone will sound to prepare you each time the speed is about to change. After 20 minutes, the colored line will reach the right end of the graph, and the workout will end. The workout will be followed by the 3 minute cool-down.

If you need to stop the walking belt before the workout has ended, press the START/PAUSE button and then stop the video cassette. To restart the workout, start the video cassette, turn the speed dial to the reset position, press the START/PAUSE button, and then turn the speed dial to the desired fitness level.

The console can be switched back to the manual mode by pressing the VIDEO TRACK button.

SELECTING MONITOR MODES

The console features seven monitor modes to give you instant feedback as you exercise. When the power is turned on, the SCAN mode will be selected automatically. In the SCAN mode, the TIME/SET, DISTANCE/SET, SPEED, CALORIES and PULSE modes will all be displayed in a repeating cycle. (Note: The PULSE mode will be displayed only if the pulse earclip is worn [see PULSE below].) Individual modes can be selected by pressing the MODE button. Mode indicators will light to show which mode you have selected. The display can be reset to zero, if desired, by removing the safety key and then re-inserting it. The seven modes are described below:

SCAN: This mode automatically displays all other modes, except WEIGHT, in a repeating cycle.

Note: The PULSE mode will be displayed only if the pulse earclip is worn.

WEIGHT: Before selecting the CALORIES mode, your weight should be entered into the console. Select the WEIGHT mode, and then press the SET buttons to enter your weight, in pounds. Each time one of the buttons is pressed, the weight displayed will change by 5 pounds. The buttons can be held down to enter your weight quickly.

TIME/SET: This mode displays the elapsed time. This mode also allows a time goal to be set. To set a time goal, first select the TIME/SET mode. (A goal cannot be set while the SCAN mode is selected.) Press the SET buttons to set the length of time you plan to exercise. Each time one of the buttons is pressed, the time displayed will change by 10 seconds. The buttons can be held down to set the length of time quickly. When the console is started, the time will be counted down. When no time remains, the console and the walking belt will stop. Note: Do not set time goals when the console is in the video track mode. The console will be controlled by a separate timer in the video track mode.

DISTANCE/SET: This mode displays the distance you have traveled. This mode also allows a distance goal to be set. To set a distance goal, first select the DISTANCE/SET mode. (A goal cannot be set while the SCAN mode is selected.) Press the SET buttons to set the distance you plan to travel. Each time one of the buttons is pressed, the distance displayed will change by 0.1 mile. The buttons can be held down to set the distance quickly. The distance will be counted down as you exercise. When the goal is completed, the console and the walking belt will stop. Note: Set distance goals only when the console is in the manual mode.

SPEED: This mode displays the speed of the walking belt.

CALORIES: This mode displays the number of Calories you have burned. For an accurate count, first select the WEIGHT mode, and enter your weight into the console.

PULSE: This mode displays your heart rate as you exercise (your heart rate must be higher than 70 beats per minute to be displayed). Plug the pulse earclip into the jack on the console, and attach the earclip to your left ear lobe. Slide the clothes clip onto your collar to prevent excessive movement of the earclip wire. If your heart rate is not displayed after a few seconds, try rubbing your ear lobe and repositioning the earclip.

TURNING OFF THE POWER


Stand on the foot rails. Remove the safety key from the console. **WARNING: Always remove the safety key when you finish exercising.**

MAINTENANCE AND TROUBLE-SHOOTING

WALKING BELT ADJUSTMENT

The walking belt should always be kept centered on the walking platform. If the belt shifts to the right or left sides of the platform, the belt may be damaged by the roller guard screws. The belt can be adjusted using the rear roller adjustment bolts and the allen wrench included. **CAUTION: ALWAYS TURN THE POWER OFF BEFORE ADJUSTING THE WALKING BELT.**

IF THE WALKING BELT HAS SHIFTED TO THE LEFT:
TURN THE POWER OFF. Turn the left adjustment bolt clockwise, and the right adjustment bolt counterclockwise, 1/4 of a turn each. Turn the power on. Repeat as necessary until the belt is centered.



IF THE WALKING BELT HAS SHIFTED TO THE RIGHT: TURN THE POWER OFF. Turn the left adjustment bolt counterclockwise, and the right adjustment bolt clockwise, 1/4 of a turn each. Turn the power on. Repeat as necessary until the belt is centered.

IF THE WALKING BELT SLIPS DURING USE: TURN THE POWER OFF. Turn both adjustment bolts clockwise 1/4 of a turn. Turn the power on. Repeat as necessary until the belt does not slip. Be careful not to overtighten the bolts. Overtightening can stretch the belt, cause excessive roller noise, and reduce motor performance.

To check the walking belt for proper tension, **TURN THE POWER OFF**, and lift the edges of the walking belt. You should be able to lift each edge 2-3 inches off the walking platform. The center of the belt should remain just at the surface of the platform.

The allen wrench can be stored conveniently on the self-adhesive wrench clip.

ROLLER GUARD ADJUSTMENT

The rear edge of the roller guards should be 1/8 inch from touching the rear roller. To adjust the roller guards, loosen the screws in the roller guards, slide the roller guards forward or backward, and retighten the screws.

CIRCUIT BREAKER


If the treadmill stops or will not start, check the circuit breaker located on the front of the frame near the power cord. The circuit breaker is designed to protect the electrical system. If the circuit breaker has tripped, the switch will protrude as shown. To reset the circuit breaker, allow the treadmill to cool for a few minutes and then push the switch back in.

PULSE EARCLIP

If the pulse earclip does not function properly, the earclip should be cleaned. Press the earclip open, and wipe the small, clear circles inside using a cotton swab saturated with denatured alcohol.

STORAGE

Always unplug the power cord when the treadmill is not in use. To convert the treadmill to the storage position, first remove the bolts and nuts from the lower and upper ends of the side rails. Store the bolts and nuts in a secure location. Loosen the lock knob and lay the upright post on the treadmill. Lay the side rails on the treadmill.



CONDITIONING GUIDELINES

The following guidelines will help you to plan and regulate your personal fitness program. Remember that adequate rest and good nutrition are essential to the success of any fitness program. **Before beginning this or any exercise program, consult your physician.**

EXERCISE INTENSITY

To maximize the benefits of exercising, your level of exertion must exceed mild demands while falling short of causing breathlessness and fatigue. The proper level of exertion can be determined using the heart rate as a guide. For effective aerobic exercise, your heart rate must be maintained at a level between 70% and 85% of your maximum heart rate. This is your "training zone." You can determine your training zone by consulting the table below. Training zones are listed for both conditioned and unconditioned persons according to age. Use the column that is appropriate for you.

AGE	UNCONDITIONED TRAINING ZONE (BEATS/MIN)	CONDITIONED TRAINING ZONE (BEATS/MIN)	AGE	UNCONDITIONED TRAINING ZONE (BEATS/MIN)	CONDITIONED TRAINING ZONE (BEATS/MIN)
20	138-167	133-162	55	127-155	122-149
25	136-166	132-160	60	126-153	121-147
30	135-164	130-158	65	125-151	119-145
35	134-162	129-156	70	123-150	118-144
40	132-161	127-155	75	122-147	117-142
45	131-159	125-153	80	120-146	115-140
50	129-156	124-150	85	118-144	114-139

During the first few weeks of your exercise program, you should keep your heart rate near the low end of your training zone. Over the course of a few months, gradually increase your heart rate until it reaches the high end of your training zone. You can measure your heart rate and find the proper level of exercise intensity using the treadmill console. Exercise for at least four minutes, and then measure your heart rate using the pulse mode. If your heart rate is above your training zone, decrease your level of exertion. If your heart rate is too low, increase your level of exertion.

WORKOUT PATTERN

Each workout should consist of three basic parts: a warm-up, 20-30 minutes of training zone exercise, and a cool-down. Warming up prepares the body for strenuous exercise by increasing circulation, delivering more oxygen to the muscles and increasing the body temperature. 5-10 minutes of stretching or light calisthenics will provide a good warm-up. After warming up, exercise at a light pace for a few minutes. Then increase the intensity of your exercise to raise your heart rate to your training zone for 20-30 minutes. Always end your workouts with 5-10 minutes of stretching to cool down. This will help to offset muscle contractions and other problems caused when you stop exercising suddenly.

EXERCISE FREQUENCY

To maintain or improve your condition, you must work out 2-3 times per week following the pattern described above. A day of rest between workouts is recommended. After several months of exercise, the number of workouts can be increased to 4-5 per week. The key to a successful program is **REGULAR** exercise.


SUGGESTED STRETCHES

The following stretches provide a good warm-up, or cool-down. Move slowly as you stretch-never bounce.

HAMSTRING STRETCH

Sit with one leg extended. Bring the sole of the opposite foot toward you, resting it against the extended leg's inner thigh. Stretch toward your toe as far as possible, hold for 15 counts, then relax. Repeat three times for both legs.

Stretches: Hamstrings, lower back and groin.



INNER THIGH STRETCH

Sit with the soles of your feet together and knees outward. Pull your feet as close into the groin area as possible. Hold for 15 counts, then relax. Repeat three times.


Stretches: Quadriceps, hip muscles.



TOE TOUCHES

Standing with your knees bent slightly, slowly bend forward from the hips. Allow your back and shoulders to relax as you stretch toward your toes. Go as far as you can and hold for 15 counts, then relax. Repeat three times.


Stretches: Hamstrings, back of knees, back.



QUADRICEPS STRETCH

With one hand against a wall for balance, reach behind you and grasp your foot. Bring your heel as close to your buttocks as possible. Hold for 15 counts, then relax. Repeat three times for both legs.

Stretches: Quadriceps, hip muscles.



CALF/ACHILLES STRETCH

With one leg in front of the other, and arms forward, lean against a wall. Keep your back leg straight and back foot flat on the floor. Bend your front leg and lean forward, moving your hips toward the wall. Hold for 15 counts, then repeat on the other side. To cause further stretching of the achilles tendons, bend back leg as well.

Stretches: Calves, achilles tendons, and ankles.

PART LIST- Model No. 831.296600

Rev. 8/91


Key No.	Reorder No.	Qty.	Description	Key No.	Reorder No.	Qty.	Description
1	106284	1	Left Side Rail/Foam	41	014127	3	Adjustment Washer
2	106285	1	Right Side Rail/Foam	42	104624	2	Swivel Shaft Bolt
3	105002	2	Foam Grip	43	100298	2	Hitch Pin
4	054013	1	Clothes Clip	44	041043	4	Hood Cushion
5	101508	1	Pulse Earclip	45	010175	2	Foot Rail
6	013423	5	Small Screw	46	104531	1	Safety Cover
7	104514	1	Motor Tension Spring	47	NSP	1	Frame
8	014041	1	Motor Tension Washer	48	100691	6	Large Screw
9	105666	1	Safety Key/Clip	49	031238	1	Choke
10	106890	1	Console	50	101757	1	Controller
11	104626	6	Screw	51	013300	4	Pad Screw
12	104634	2	Short Side Rail Bolt	52	102599	1	Front Roller/Pulley
13	105597	1	Upright Post	53	025058	1	Walking Belt
14	105476	2	Long Side Rail Bolt	54	005040	2	Rubber Pad
15	100147	1	Pulley/Flywheel/Fan	55	101360	1	Right Roller Bracket
16	009126	1	Motor Hood/Decal	56	013206	2	Rear Roller Adj. Bolt
17	101629	1	Motor	57	070084	1	Rear Roller
18	012082	5	Motor Nut	58	101743	1	Sensor Wire/Reed Switch
19	101630	4	Motor Washer	59	010206	2	Roller Guard
20	013445	4	Motor Bolt	60	045010	1	Allen Wrench
21	102087	1	Swivel Shaft	61	016028	1	Wrench Clip
22	104925	1	Hinge Bolt	62	101359	1	Left Roller Bracket
23	014087	2	Hinge Washer	63	053025	1	Walking Platform
24	014156	1	Lock Knob Washer	64	104621	4	Motor Hood Screw
25	017088	1	Lock Knob	65	033066	1	Sensor Magnet
26	012108	1	Hinge Nut	66	013141	2	Roller Guard Screw
27	101754	1	Right Incline Leg	67	105477	2	Flange Nut
28	106278	1	Power Supply Board	68	102789	1	Belt
29	031036	1	Circuit Breaker	69	103855	1	J- Bolt
30	019084	1	Grommet	70	016055	4	Sensor Wire Clip
31	104623	12	Plastic Fastener	71	101644	1	Leg Shaft
32	014157	1	Star Washer	72	101753	1	Left Incline Leg
33	031229	1	Power Cord	73	106261	1	Power Supply Plate
34	015047	1	Shock Pin	74	015071	4	Plastic Clip
35	012133	2	Push Nut	75	013162	4	Mounting Screw
36	054016	2	E-Clip	76	105617	1	VCR Cable
37	101140	1	Incline Shock	77	105616	1	Video Tape
38	101605	2	Shaft Spacer	78	106562	1	Cable Clamp
39	016026	2	Adjustable Clamp	79	106835	1	Speed Dial
40	013275	1	Front Roller Adj. Bolt	#	105615	1	Owner's Manual

Note: "#" indicates a non-illustrated part. Specifications are subject to change without notice. See the back cover for information about ordering replacements parts.

EXPLODED DRAWING- Model No. 831.296600

Rev. 8/91

Specifications are subject to change without notice.



SEARS® SERVICE is at YOUR SERVICE

ORDERING REPLACEMENT PARTS

Each TREADMILL has its own MODEL NUMBER. Always mention this MODEL NUMBER when requesting service or repair parts for your TREADMILL.

All parts listed herein may be ordered through SEARS, ROEBUCK AND CO. SERVICE CENTERS and most SEARS RETAIL STORES.

If parts you need are not stocked locally, your order will be electronically transmitted to a SEARS PARTS DISTRIBUTION CENTER for expedited handling.

WHEN ORDERING REPAIR PARTS, ALWAYS GIVE THE FOLLOWING INFORMATION:

1. The MODEL NUMBER of the product (831.296600).
2. The NAME of the product (Sears Lifestyler 2600 VLP treadmill).
3. The REORDER NUMBER of the part(s), from page 14 of this manual.
4. The DESCRIPTION of the part(s), from page 14 of this manual.

Your Sears merchandise has added value when you consider that Sears has service units nationwide staffed with Sears trained technicians specifically trained on Sears products, having the parts, tools and the equipment to insure that we meet our pledge to you: we service what we sell.