


FREEMOTION®

i11.9 INCLINE TRAINER

Model No. FMTK74817-INT.0

Serial No. _____

Write the serial number in the space above for reference.



USER'S MANUAL

QUESTIONS?

If you have questions, or if parts are damaged or missing, please see **HOW TO CONTACT CUSTOMER CARE** on the back cover of this manual.

⚠ CAUTION

Read all precautions and instructions in this manual before using this equipment. Keep this manual for future reference.




TABLE OF CONTENTS

IMPORTANT PRECAUTIONS.....	3
WARNING DECAL PLACEMENT	5
BEFORE YOU BEGIN.....	6
PART IDENTIFICATION CHART.....	7
ASSEMBLY	8
HOW TO MOVE THE INCLINE TRAINER	16
HOW TO CONNECT THE INCLINE TRAINER.....	17
HOW TO UPGRADE THE CONSOLE	18
HOW TO USE THE CONSOLE	19
PREVENTIVE MAINTENANCE	32
PREVENTIVE MAINTENANCE RECORD	36
TROUBLESHOOTING	37
EXERCISE GUIDELINES	39
PART LIST.....	41
EXPLODED DRAWING	43
HOW TO CONTACT CUSTOMER CARE.....	Back Cover
LIMITED WARRANTY.....	Back Cover

IMPORTANT PRECAUTIONS

⚠️ WARNING: To reduce the risk of burns, fire, electric shock, or injury to persons, read all important precautions and instructions in this manual and all warnings on your incline trainer before using your incline trainer. FreeMotion Fitness assumes no responsibility for personal injury or property damage sustained by or through the use of this product.

1. It is the responsibility of the owner to ensure that all users of the incline trainer are adequately informed of all warnings and precautions.
2. Before beginning any exercise program, consult your physician. This is especially important for persons over age 35 or persons with pre-existing health problems.
3. The incline trainer is not intended for use by persons with reduced physical, sensory, or mental capabilities or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the incline trainer by someone responsible for their safety.
4. Use the incline trainer only as described in this manual.
5. Keep the incline trainer indoors, away from moisture and dust. Do not place the incline trainer in a garage or covered patio, or near water.
6. Place the incline trainer on a level surface, with at least 2.4 m (8 ft.) of clearance behind it and 0.6 m (2 ft.) on each side. Do not place the incline trainer on a surface that blocks any air openings. To protect the floor or carpet from damage, place a mat under the incline trainer.
7. Do not operate the incline trainer where aerosol products are used or where oxygen is being administered.
8. Do not operate the incline trainer until it is properly and fully assembled (see **ASSEMBLY** on page 8).
9. Inspect and tighten all parts of the incline trainer each time the incline trainer is used.
10. Keep children under age 13 and pets away from the incline trainer at all times.
11. The incline trainer should not be used by persons weighing more than 400 lbs. (181 kg).
12. Never allow more than one person on the incline trainer at a time.
13. Wear appropriate exercise clothes while using the incline trainer. Do not wear loose clothes that could become caught in the incline trainer. Athletic support clothes are recommended for both men and women. *Always wear athletic shoes. Never use the incline trainer with bare feet, wearing only stockings, or in sandals.*
14. When connecting the power cord, follow the instructions on page 17. No other appliance should be on the same circuit as the incline trainer. Do not use an extension cord.
15. Keep the power cord away from heated surfaces.
16. Never move the walking belt while the power is turned off. Do not operate the incline trainer if the power cord or plug is damaged or if the incline trainer is not working properly. (See **TROUBLESHOOTING** on page 37 if the incline trainer is not working properly.)
17. Read, understand, and test the emergency stop procedure before using the incline trainer (see **HOW TO TURN ON THE POWER** on page 20). Always wear the clip while using the incline trainer.
18. Always stand on the foot rails when starting or stopping the walking belt. Always hold the handrails while using the incline trainer.
19. When a person is walking on the incline trainer, the noise level of the incline trainer will increase.

20. Keep fingers, hair, and clothing away from the moving walking belt.
21. The incline trainer is capable of high speeds. Adjust the speed in small increments to avoid sudden jumps in speed.
22. The heart rate monitor is not a medical device. Various factors, including the user's movement, may affect the accuracy of heart rate readings. The heart rate monitor is intended only as an exercise aid in determining heart rate trends in general.
23. Never leave the incline trainer unattended while it is running.
24. Do not change the incline of the incline trainer by placing objects under it.
25. Never insert or drop any object into any opening on the incline trainer.
26. Make sure to perform all maintenance procedures outlined in this manual. Failure to do so will void the warranty and may result in damage to the incline trainer.
27. **DANGER:** Always unplug the power cord before cleaning the incline trainer and before performing the maintenance and adjustment procedures described in this manual. Servicing other than the procedures in this manual should be performed by an authorized service representative only.
28. Over exercising may result in serious injury or death. If you feel faint, if you become short of breath, or if you experience pain while exercising, stop immediately and cool down.

SAVE THESE INSTRUCTIONS

WARNING DECAL PLACEMENT


These drawings show the location(s) of the warning decal(s). **If a decal is missing or illegible, see the back cover of this manual and request a free replacement decal. Apply the decal in the location shown.**

Note: The decal(s) may not be shown at actual size.

⚠ WARNING: Protect yourself and others from risk of serious injury. Read the user's manual or obtain proper instruction before use and:		
• Stand only on side rails when starting or stopping treadmill. • Change speed in small increments. • Hold handrails to prevent falling, and always wear the safety clip while operating treadmill. • Stop if you feel faint, dizzy, or short of breath.	• Never allow children on or around treadmill. • Remove key when not in use.	• Keep clothing, fingers, and hair away from moving belt. • Never try to adjust or fix the belt while it is moving. • Always wear athletic shoes while operating treadmill.


	⚠ WARNING • Hazardous Voltage • Risk of Electric Shock • Unplug Treadmill before Assembly/ Disassembly
	⚠ ATTENTION • Tension Dangereuse • Risque de Choc Électrique • Débranchez le tapis roulant Avant l'Assemblage/Désassemblage

⚠ CAUTION: HIGH VOLTAGE
Disconnect line cord from outlet before servicing.



⚠ CAUTION	⚠ ATTENTION
KEEP HANDS AND FEET AWAY FROM THIS AREA WHILE THE TREADMILL IS IN OPERATION.	GARDEZ VOS PIEDS ET VOS MAINS ÉLOIGNÉS DE CET ENDROIT QUAND LE TAPIS ROULANT EST EN MARCHÉ.

Note: There is one decal on each side



⚠ CAUTION: HIGH VOLTAGE
Disconnect line cord from outlet before servicing.


BEFORE YOU BEGIN

Thank you for selecting the revolutionary FREEMOTION® i11.9 INCLINE TRAINER. The i11.9 INCLINE TRAINER provides an impressive selection of features designed to make your workouts more effective and enjoyable.

For your benefit, read this manual carefully before you use the incline trainer. If you have questions










after reading this manual, please see the back cover of this manual. To help us assist you, note the product model number and serial number before contacting us. The model number and the location of the serial number decal are shown on the front cover of this manual.

Before reading further, please familiarize yourself with the parts that are labeled in the drawing below.



PART IDENTIFICATION CHART

Use the drawings below to identify small parts used for assembly. The number in parentheses below each drawing is the key number of the part, from the PART LIST near the end of this manual. The number following the key number is the quantity used for assembly. **Note: If a part is not in the hardware kit, check to see whether it is preattached. Extra hardware may be included.**

				
3/8" Star Washer (14)–4	5/16" Star Washer (61)–12	3/8" Jam Nut (58)–2	#10 x 1/2" Screw (35)–2	#8 x 3/4" Screw (16)–30
				
5/16" x 3/4" Screw (57)–4	1/4" x 1" Screw (8)–2	5/16" x 1" Screw (51)–10	5/16" x 1 1/4" Screw (34)–4	
				
	3/8" x 2 3/4" Screw (50)–4			

ASSEMBLY

- Assembly requires two persons.
- Place all parts in a cleared area and remove the packing materials. Do not dispose of the packing materials until you finish all assembly steps.
- To identify small parts, see page 7.

- Assembly requires the following tools:


one 3/8" hex key



one 7/32" hex key




one Phillips screwdriver



To avoid damaging parts, do not use power tools.

1. With the help of a second person, slide the Left Upright (149) onto the Base Frame (56). Next, insert the Upright Coaxial Cable (125) through the two holes (A) in the side of the Base Frame. **Do not pinch the Upright Coaxial Cable.**


Next, insert the Upright Coaxial Cable (125) into the hole (B) in the front of the Base Frame (56). Then, tighten two 3/8" Jam Nuts (58) onto the Upright Coaxial Cable.



2. Partially tighten two 5/16" x 3/4" Screws (57) with two 5/16" Star Washers (61) into the Left Upright (149). **Do not fully tighten the Screws yet.**

Next, partially tighten two 5/16" x 1" Screws (51) with one 5/16" Star Washer (61) as shown into the Left Upright (149).


Then, press a Base Cap (115) into the Base Frame (56).



3. With the help of a second person, slide the Right Upright (150) onto the Base Frame (56). Next, connect the Upright Wire Harness (116) to the Frame Wire Harness (129). **See the inset drawing. The connectors should slide together easily and snap into place. If they do not, turn one connector and then try again. IF THE CONNECTORS ARE NOT CONNECTED PROPERLY, THE CONSOLE MAY BE DAMAGED WHEN THE POWER IS TURNED ON.**


Do not pinch the Upright Wire Harness (116) or the Frame Wire Harness (129).

Insert the Wire Harnesses (116, 129) into the Base Frame (56). Then, press the other Base Cap (115) into the Base Frame (56).




4. Partially tighten two 5/16" x 3/4" Screws (57) with two 5/16" Star Washers (61) into the Right Upright (150). **Do not fully tighten the Screws yet.**

Then, partially tighten two 5/16" x 1" Screws (51) with one 5/16" Star Washer (61) as shown into the Right Upright (150).



5. Place the handrail assembly (C) upside down. Remove and discard the four indicated screws (D).

Then, separate the Handrail Base Top Cover (153) and the Handrail Base Bottom Cover (155), and remove the Handrail Base (154).




6. With the help of a second person, set the Handrail Base (154) on the Uprights (149, 150). **See the inset drawing.** The 5/16" x 3/4" Screws (88) need to fit into the holes (E) in the bottom of the Handrail Base. Then, slide the Handrail Base forward. The 5/16" x 3/4" Screws will keep the Handrail Base in place.


Attach the Handrail Base (154) with four 3/8" x 2 3/4" Screws (50) and four 3/8" Star Washers (14); **start all four Screws, and then torque them to 31 pound-feet (42 Newton-meters).**

Then, connect the Upright Wire Harness (116) to the Handrail Wire (146), and connect the Upright Coaxial Cable (125) to the Coaxial Extension Cable (161).


IMPORTANT: See steps 2 and 4. Torque the 5/16" x 1" Screws (51) to 17 pound-feet (23 Newton-meters), and torque the 5/16" x 3/4" Screws (57) to 12 pound-feet (16 Newton-meters).



7. Set the Handrail Base Top Cover (153) on the Handrail Base (154). **Make sure that no wires or cables (F) are inside the Handrail Base Top Cover.**



8. Attach the Handrail Base Bottom Cover (155) with fourteen #8 x 3/4" Screws (16); **start all fourteen Screws, and then tighten them. Do not overtighten the Screws.**




9. Set the Right Handrail Assembly (113) on the right side of the Handrail Base (154). Attach the Right Handrail Assembly with two 5/16" x 1 1/4" Screws (34) and a 5/16" x 1" Screw (51) with a 5/16" Star Washer (61).

Torque the 5/16" x 1" Screw (51) to 17 pound-feet (23 Newton-meters), and torque the 5/16" x 1 1/4" Screws (34) to 12 pound-feet (16 Newton-meters).

Next, connect the Handrail Wire (146) to the Handrail Extension Wire (160).

Then, attach an Upright Cap (148) with a #10 x 1/2" Screw (35).


Attach the Left Handrail (not shown) and the other Upright Cap (not shown) as described above.




10. Attach the Right Outer Cover (143) with three #8 x 3/4" Screws (16); **do not overtighten the Screws.**

Next, attach the Right Inner Cover (145) with a 1/4" x 1" Screw (8); **do not overtighten the Screw.**


Attach the Left Outer Cover (not shown) and the Left Inner Cover (not shown) as described above.




11. Set the console assembly (G) onto the Handrail Base (154). Connect the wires (H) from the console assembly to the corresponding wires (I) from the Handrail Base.



12. Attach the console assembly (G) with four 5/16" x 1" Screws (51) and four 5/16" Star Washers (61). **Torque the Screws to 17 pound-feet (23 Newton-meters).**




13. Attach the Console Back (5) to the console assembly (G) with four #8 x 3/4" Screws (16); **start all four Screws, and then tighten them. Do not overtighten the Screws.**



14. Attach the Left Upright Cover (151) to the Left Upright (149) with three #8 x 3/4" Screws (16); **start all three Screws, and then tighten them. Do not overtighten the Screws.**

After the incline trainer is placed in the location where it will be used (see HOW TO MOVE THE INCLINE TRAINER on page 16), make sure that both Leveling Feet (38) rest firmly on the floor. If the incline trainer rocks even slightly, turn one of the Leveling Feet clockwise or counterclockwise until the rocking motion is eliminated.

Attach the Right Upright Cover (not shown) to the Right Upright (not shown) as described above.



15. **Make sure that all parts are properly tightened before you use the incline trainer.** To protect the floor or carpet, place a mat beneath the incline trainer.


If you purchased the optional MYE receiver to set up a wall of TVs, follow the step below to install the receiver. To order the optional MYE receiver, see the back cover of this manual.

16. Remove the four #8 x 1/2" Cover Screws (108), and then remove the Console Access Cover (92).

Next, plug the cable (J) from the console assembly (G) into the "In" port on the receiver (K).

Next, peel the backing (L) off the receiver (K), and press the receiver onto the Console Access Cover (92) in the location shown by the dashed line.

Then, reattach the Console Access Cover (92) with the four #8 x 1/2" Cover Screws (108).




HOW TO MOVE THE INCLINE TRAINER

Before moving the incline trainer, unplug the power cord. Note: It may be necessary to disconnect a CATV cable and a network wire from the incline trainer, depending on how far the incline trainer will be moved.

Due to the size and weight of the incline trainer, moving it may require two or three people. To lower the casters (A), use a hex key to turn each of the indicated screws (B) clockwise until the casters raise the incline trainer. Then, roll the incline trainer to the desired location. **CAUTION: To reduce the risk of injury, use extreme caution while moving the incline trainer. Do not attempt to move the incline trainer over uneven surfaces.**

Once the incline trainer is in the desired location, turn the screws (B) counterclockwise until the incline trainer is resting evenly on the leveling feet.



HOW TO CONNECT THE INCLINE TRAINER

⚠ DANGER: Improper connection of the equipment-grounding conductor increases the risk of electric shock. Check with a qualified electrician or serviceman if you are unsure whether the product is properly earthed. Do not modify the plug—if it will not fit the outlet, have a proper outlet installed by a qualified electrician. Do not use an adapter to connect the plug to an improper receptacle.


To purchase a power cord, please contact the store where you purchased this product or see the back cover of this manual.

HOW TO CONNECT THE POWER CORD IN THE UK

This product must be earthed. If it should malfunction or break down, earthing provides a path of least resistance for electric current to reduce the risk of electric shock.

This product is for use on a dedicated, 10-amp, 240-volt circuit. No other appliance should be on the same circuit.

Plug the earthing plug into a receptacle as shown at the right. Do not modify the plug or the receptacle. Do not use an adapter or an extension cord. The receptacle must be earthed.




HOW TO CONNECT A CATV CABLE

If your incline trainer has the digital TV, a CATV cable must be connected to the incline trainer for cable TV stations to be viewed.

Locate the cable jack on the front of the incline trainer. Connect the CATV cable to the Upright Coaxial Cable (125) (see the drawing at the right).

Route the cable so that it will not be pinched or crushed by the incline trainer.



A satellite receiver, VCR, or DVD player can also be connected to the incline trainer. Connect a CATV cable from the coaxial output on your equipment (usually labeled TV OUT or RF OUT) to the cable jack on the front of the incline trainer.

Note: Audio/video equipment without coaxial outputs (some satellite receivers and DVD players) will require an RF modulator to work correctly. RF modulators are not available from FreeMotion Fitness, but are available at electronics stores. See the owner's manual for the equipment you wish to connect to determine if an RF modulator is needed, or contact your local audio/visual service provider.



WARRANTY INFORMATION

The warranty for this product does not cover damage or equipment failure caused by electric wiring not in compliance with electrical codes or the specifications in this manual, or failure to provide reasonable and necessary maintenance as outlined in this manual. Any failure or damage caused by unauthorized service; misuse; accident; negligence; improper assembly or installation; debris resulting from any destruction activities in the product's environment; rust or corrosion as a result of the product's location; alterations or modifications without written authorization; or failure on your part to use, operate, and maintain the product as set forth in this manual will void the warranty.


HOW TO UPGRADE THE CONSOLE

Your incline trainer's console has been preconfigured to operate with a digital TV (see the drawings below). To learn about the features of the console, see page 19. To learn about the features of the digital TV, see the user's manual included with the digital TV. **Note: The buttons at the top of the console function with the digital TV only.** The basic console has no television capabilities.

To upgrade your console whenever you choose, please see the back cover of this manual.



HOW TO USE THE CONSOLE



FEATURES OF THE CONSOLE

The incline trainer console offers a selection of features designed to make your workouts more effective and enjoyable. The console features revolutionary iFit technology that enables the incline trainer to communicate with your wireless network. With iFit technology, you can download personalized workouts, create your own workouts, track your workout results, and access many other features. **See iFit.com for complete information.**

In addition, the console features a selection of onboard workouts. Each workout automatically controls the speed and incline of the incline trainer as it guides you through an effective exercise session. In addition, you can set a time, distance, calorie, or pace goal.

When you use the manual mode, you can change the speed and incline of the incline trainer with the touch of a button.

As you exercise, the console will display instant exercise feedback. You can also measure your heart rate using the handgrip heart rate monitor or an optional Polar®-compatible chest heart rate monitor.

To turn on the power, see page 20. **To learn how to use the touch screen,** see page 20. **To set up the console,** see page 21.

Note: The console can display speed and distance in either miles or kilometers. To find which unit of measurement is selected, see step 4 on page 27.


HOW TO TURN ON THE POWER

1. Plug in the power cord.

See HOW TO CONNECT THE POWER CORD on page 17.

2. Press the power switch into the on position.

Locate the power switch on the incline trainer near the power cord. Press the power switch into the on position.




3. Insert the key into the console.

Note: The console can be set to be used without the key. See step 8 on page 27 for instructions. If the console has been set to be used without the key, this step does not apply.

Find the key and the clip on the console and attach the clip to the waistband of your clothes. Next, insert the key into the console.

IMPORTANT: In an emergency, the key can be pulled from the console, causing the walking belt to slow to a stop. Test the clip by carefully taking a few steps backward; if the key is not pulled from the console, adjust the position of the clip.



HOW TO USE THE TOUCH SCREEN

The console features a tablet with a full-color touch screen. The following information will help you become familiar with the tablet's advanced technology:

- The console functions similarly to other tablets. You can slide or flick your finger against the screen to move certain images on the screen, such as the displays in a workout (see step 5 on page 22). However, you cannot zoom in and out by sliding your fingers on the screen.
- The screen is not pressure sensitive. You do not need to press hard on the screen.
- To type information into a text box, touch the text box to view the keyboard. To use numbers or other characters on the keyboard, touch the ?123 button. To view more characters, touch the Alt button. Touch the Alt button again to return to the number keyboard. To return to the letter keyboard, touch the ABC button. To use a capital character, touch the button with an upward-facing arrow. To use multiple capital characters, touch the arrow button again. To return to the lowercase keyboard, touch the arrow button a third time. To clear the last character, touch the button with a backward-facing arrow and an X.

HOW TO SET UP THE CONSOLE

Before using the incline trainer for the first time, set up the console.

1. Connect to your wireless network.

To access the internet, download iFit workouts, and use other features of the console, you must be connected to a wireless network. See HOW TO USE THE WIRELESS NETWORK MODE on page 30 to connect the console to your wireless network.

2. Check for firmware updates.

First, see step 1 on page 27 and step 2 on page 29 and select the maintenance mode. Then, see step 3 on page 29 and check for firmware updates.

3. Calibrate the incline system.

See step 4 on page 29 and calibrate the incline system of the incline trainer.

4. Create an iFit account.

Touch the globe button near the lower-left corner of the screen and touch the iFit button.

For information about navigating in the browser, see page 31. The browser will open to the iFit.com home page. Touch the Register button in the upper-right corner of the screen.

The browser will open to the iFit.com registration page. Follow the prompts on the screen to create your iFit account.

To use the manual mode, see page 22. **To use an onboard workout**, see page 24. **To use a set-a-goal workout**, see page 25. **To use an iFit workout**, see page 26.

To use the equipment settings mode, see page 27. **To use the entertainment mode**, see page 28. **To use the maintenance mode**, see page 29. **To use the internet browser**, see page 31.

IMPORTANT: If there are sheets of plastic on the console, remove the plastic. To prevent damage to the walking platform, wear clean athletic shoes while using the incline trainer. The first time you use the incline trainer, observe the alignment of the walking belt, and center the walking belt if necessary (see pages 37 and 38).

HOW TO USE THE MANUAL MODE

1. Insert the key into the console.

See HOW TO TURN ON THE POWER on page 20. **Note: It may take a minute for the console to be ready for use.**

2. Select the main menu.

When you turn on the power, the main menu will appear after the console boots up. Touch the home button in the lower-left corner of the screen to return to the main menu at any time.

3. Start the walking belt and adjust the speed.

Touch the Start button on the screen or press the Start button on the console to start the walking belt. The walking belt will begin to move at 2 Km/H. As you exercise, change the speed of the walking belt as desired by pressing the Speed increase and decrease buttons. Each time you press one of the buttons, the speed setting will change in small increments.

If you press one of the numbered Speed buttons, the walking belt will gradually change speed until it reaches the selected speed setting.

To stop the walking belt, press the Stop button. To restart the walking belt, press the Start button.


4. Change the incline of the incline trainer as desired.

To change the incline of the incline trainer, press the Incline increase and decrease buttons or one of the numbered Quick % Grade buttons. Each time you press one of the buttons, the incline will gradually change until it reaches the selected incline setting.

Note: The first time you adjust the incline, you must first calibrate the incline system (see step 4 on page 29).

5. Monitor your progress.

The console offers several display modes. The display mode that you select will determine which workout information is shown. To select the desired display mode, simply flick or slide the screen. You can also view additional information by touching the red boxes on the screen.



As you walk or run on the incline trainer, the screen can show the following workout information:

- The incline level of the incline trainer
- The time elapsed
- The time left (the manual mode does not have a time left countdown)
- The approximate number of calories you have burned
- The approximate number of calories you are burning per hour
- The distance that you have walked or run
- The number of vertical meters you have climbed
- The speed of the walking belt
- A track representing 400 m (1/4 mile)
- Your pace in minutes per kilometer
- Your current lap number
- Your heart rate (see step 6)


If desired, adjust the volume by pressing the Vol increase and decrease buttons on the console.

To pause the workout, touch one of the menu buttons or press the Stop button on the console. To continue the workout, touch the Resume button or the Start button. To end the workout session, touch the End Workout button.

6. Measure your heart rate if desired.

Note: If you use the handgrip heart rate monitor and a chest heart rate monitor at the same time, the console will not display your heart rate accurately. For information about ordering an optional chest heart rate monitor, please see the back cover of this manual.

Before using the handgrip heart rate monitor, remove the sheets of plastic from the metal contacts (A). In addition, make sure that your hands are clean.



To measure your heart rate, **stand on the foot rails** and hold the contacts with your palms for approximately ten seconds; **avoid moving your hands or gripping the contacts (A) tightly**. When your pulse is detected, your heart rate will be shown. **For the most accurate heart rate reading, continue to hold the contacts for about 15 seconds.**

7. Turn on the fan if desired.

The fan features several speed settings. Press the fan buttons repeatedly to select a fan speed or to turn on or turn off the fan.

8. When you are finished exercising, remove the key from the console.

Step onto the walking platform and touch the home button or the back button on the screen or press the Stop button on the console. A workout summary will appear on the screen. After you view the workout summary, touch the Finish button to return to the main menu. You may also be able to either save or publish your results using one of the options on the screen. Then, remove the key from the console and put it in a secure place.

When you are finished using the incline trainer, press the power switch into the off position and unplug the power cord. **IMPORTANT: If you do not do this, the incline trainer's electrical components may wear prematurely.**

HOW TO USE AN ONBOARD WORKOUT

1. Insert the key into the console.

See HOW TO TURN ON THE POWER on page 20.

2. Select an onboard workout.

To select an onboard workout, touch the runner button in the lower-left corner of the screen.

In the Workouts menu, touch the Calorie Burn button, the High Intensity button, the Speed button, or the Incline button. Then, select the desired workout. The screen will show the name, duration, and distance of the workout. The screen will also show the approximate number of calories you will burn during the workout and a profile of the incline settings of the workout.

3. Start the workout.

Touch the Start Workout button to start the workout. A moment after you touch the button, the walking belt will begin to move. Hold the handrails and begin walking.

Each workout is divided into several segments. One speed setting and one incline setting are programmed for each segment. Note: The same speed setting and/or incline setting may be programmed for consecutive segments.

During the workout, the profile will show your progress. To view the profile, flick or slide the screen. The vertical colored line will indicate the current segment of the workout. The bottom profile represents the incline setting of the current segment. The top profile represents the speed setting of the current segment.

At the end of the first segment of the workout, the incline trainer will automatically adjust to the speed and/or incline settings for the next segment.

The workout will continue in this way until the last segment ends. The walking belt will then slow to a stop and a workout summary will appear on the screen. After you view the workout summary, touch the Finish button to return to the main menu. You may also be able to either save or publish your results using one of the options on the screen.

If the speed and/or incline settings are too high or too low at any time during the workout, you can override the settings by pressing the Speed or Incline buttons. **If you press a Speed button**, you can then manually control the speed (see step 3 on page 22). **If you press an Incline button**, you can then manually control the incline (see step 4 on page 22). **To return to the programmed speed and/or incline settings of the workout**, first, view the profile. Then, touch the Follow Workout button.

To pause the workout, touch either the back button or the home button in the lower-left corner of the screen, or press the Stop button on the console. To continue the workout, touch the Resume button or press the Start button on the console. To end the workout, touch the End Workout button.

Note: The calorie goal is an estimate of the number of calories that you will burn during the workout. The actual number of calories that you burn will depend on various factors such as your weight. In addition, if you manually change the speed or incline of the incline trainer during the workout, the number of calories you burn will be affected.

4. Monitor your progress.

See step 5 on page 22. The screen can also show a profile of the speed and incline settings of the workout.

5. Measure your heart rate if desired.

See step 6 on page 23.

6. Turn on the fan if desired.

See step 7 on page 23.

7. When you are finished exercising, remove the key from the console.

See step 8 on page 23.

HOW TO USE A SET-A-GOAL WORKOUT

1. Insert the key into the console.

See HOW TO TURN ON THE POWER on page 20.

2. Select the main menu.

See step 2 on page 22.


3. Select a set-a-goal workout.

To select a set-a-goal workout, touch the Set A Goal button on the screen or press the Set A Goal button on the console.

To set a time, distance, calorie, or pace goal, touch the Calories, Time, Distance, or Pace button.

Then, touch the increase and

decrease buttons on the screen to select a time, distance, calorie, or pace goal and to select the speed and incline for the workout. The screen will show the duration and distance of the workout, and the approximate number of calories you will burn during the workout.



4. Start the workout.

Touch the Start button to start the workout. A moment after you touch the button, the walking belt will begin to move. Hold the handrails and begin walking.

The workout will function in the same way as the manual mode (see pages 22 and 23).

The workout will continue until you reach the goal that you set. The walking belt will then slow to a stop, and a workout summary will appear on the screen. After you view the workout summary, touch the Finish button to return to the main menu. You may also be able to either save or publish your results using one of the options on the screen.

Note: The calorie goal is an estimate of the number of calories that you will burn during the workout. The actual number of calories that you burn will depend on various factors such as your weight.

5. Monitor your progress.

See step 5 on page 22.

6. Measure your heart rate if desired.

See step 6 on page 23.

7. Turn on the fan if desired.

See step 7 on page 23.

8. When you are finished exercising, remove the key from the console.

See step 8 on page 23.

HOW TO USE AN iFIT WORKOUT

Note: To use an iFit workout, you must have access to a wireless network (see HOW TO USE THE WIRELESS NETWORK MODE on page 30). An iFit account is also required.

1. Insert the key into the console.

See HOW TO TURN ON THE POWER on page 20.

2. Select the main menu.

See step 2 on page 22.

3. Log in to your iFit account.

If you have not already done so, touch the Login button to log in to your iFit account. The screen will ask for your iFit.com Username and Password. Enter them and touch the Login button. Touch the Cancel button to exit the login screen.

4. Select an iFit workout.

To download an iFit workout in your schedule, touch the Map, Train, Video, or Lose Weight button to download the next workout of that type in your schedule. Note: You may be able to access demo workouts through these options, even if you do not log in to an iFit account.

To compete in a race that you have previously scheduled, touch the Compete button. To view your Workout History, touch the Track button. To use a set-a-goal workout, touch the Set A Goal button (see page 25). Note: You can also press one of the iFit buttons on the console.

To switch users within the account, touch the Login button near the lower-right corner of the screen.

Before some workouts will download, you must add them to your schedule on iFit.com.

For more information about the iFit workouts, please see iFit.com.

When you select an iFit workout, the screen will show the name, duration, and distance of the workout. The screen will also show the approximate number of calories you will burn during the workout. If you select a competition workout, the display will count down to the beginning of the race.

5. Start the workout.

See step 3 on page 24.

During some workouts, an audio coach may guide you through your workout.

6. Monitor your progress.

See step 5 on pages 22 and 23. The screen may also show a map of the trail you are walking or running.

During a competition workout, the screen will show the speeds of the runners and the distances they have run. The screen will also show the numbers of seconds that the other runners are ahead of you or behind you.

7. Measure your heart rate if desired.

See step 6 on page 23.

8. Turn on the fan if desired.

See step 7 on page 23.

9. When you are finished exercising, remove the key from the console.

See step 8 on page 23.


For more information about the iFit mode, go to iFit.com.

HOW TO USE THE EQUIPMENT SETTINGS MODE

The console features an equipment settings mode that allows you to select a language and the unit of measurement, to turn on and turn off the display demo mode, set a reset timeout, and to enable or disable the key and/or a passcode.

1. Access the settings main menu.

Insert the key into the console (see HOW TO TURN ON THE POWER on page 20). Next, select the main menu (see step 2 on page 22). Then, draw a square clockwise on the screen to access the settings main menu (see the drawing above).



2. Select the equipment settings mode.

In the settings main menu, touch the Equipment Settings button.

3. Select a language.

To select a language, touch the Language button and select the desired language. Then, touch the back button on the screen to return to the equipment settings mode. Note: This feature may not be enabled.

4. Select the unit of measurement.

Touch the US/Metric button to view the selected unit of measurement. Change the unit of measurement, if desired. Then, touch the back button on the screen.

5. Select a timezone.

Touch the Timezone button. Select your local timezone to have the console sync to your local time. Then, touch the back button.

6. Select an automatic update time

You can set a time for the console to automatically check for firmware updates. You can always cancel these firmware updates by touching the Cancel button. However, it is strongly recommended that you allow the console to update frequently.

Touch the Update Time button. Select the time when the console will automatically check for an update. Then, touch the back button.

7. Turn on or turn off the display demo mode.

The console features a display demo mode, designed to be used if the incline trainer is displayed in a store. While the demo mode is turned on, the console will function normally when you plug in the power cord, press the power switch into the on position, and insert the key into the console. However, when you remove the key, the screen will show a demo presentation.

To turn on or turn off the display demo mode, first touch the Demo Mode button. Next, touch the On checkbox or the Off checkbox. Then, touch the back button on the screen.

8. Enable or disable the key.

You can disable the key so that the incline trainer does not require the use of the key. Touch the Safety Key button. To disable the key, touch the Disable checkbox. **CAUTION: Read the safety warning on the screen before disabling the key.** To enable the key again, touch the Enable checkbox.

9. Enable or disable the web browser.

You can disable the console's web browser, which will help to restrict the bandwidth used on your wireless network.

Touch the Browser button. To disable the browser, touch the Disable checkbox. The console will automatically restart, and the web browser will be disabled. To enable the browser again, return to the Browser option, and then touch the Enable checkbox. The console will automatically restart, and the web browser will be enabled again.

10. Enable or disable the street view.

You can disable the street view for maps workouts, which will help to restrict the bandwidth used on your wireless network.

Touch the Street View button. To disable the street view, touch the Disable checkbox. To enable the street view again, touch the Enable checkbox.

11. Set a time for the reset timeout.

The console features an automatic reset timeout; if no buttons are touched or pressed and the walking belt does not move for a set amount of time, the console will automatically reset.

To set the amount of time the console will wait before it automatically resets, touch the Reset Timeout button to view a list of times. Then, select the amount of time desired. Touch the back button on the screen.

12. Set a workout time limit.

You can set a time limit for workouts to help restrict the amount of time each user spends on the incline trainer.

Touch the Workout Time Limit button. To enable the workout time limit, touch the Enable checkbox. Then, touch the increase and decrease buttons to select the amount of time allowed for each user. Then, touch the back button on the screen.

During any workout, the screen will notify you when only ten seconds remain until the time limit. When the time limit is reached, the workout will automatically end.

13. Exit the equipment settings mode.

To exit the equipment settings mode, touch the back button on the screen.

HOW TO USE THE ENTERTAINMENT MODE

The console features an entertainment mode that allows you to connect the console to a remote TV. If you purchase the digital TV, please see the manual included with the digital TV to learn how to use the entertainment mode to set up your personal digital TV.

1. Access the settings main menu.

See step 1 on page 27.

2. Select the entertainment mode.

In the settings main menu, touch the Entertainment button to enter the entertainment mode.

3. Adjust volume and other settings for the TV.

Note: The controls on the screen affect TV setup only. They do not affect the settings on the console.

4. Exit the entertainment mode.

To exit the entertainment mode, touch the Close button on the screen.

HOW TO USE THE MAINTENANCE MODE


The console features a maintenance mode that allows you to update the console firmware, calibrate the incline of the incline trainer, calibrate the screen, view technical information, and view a button's keycode.

1. Access the settings main menu.

See step 1 on page 27.

2. Select the maintenance mode.

In the settings main menu, touch the Maintenance button to enter the maintenance mode.



The maintenance mode main screen will show information about the model and version of the incline trainer.

3. Update the console firmware.

For the best results, regularly check for firmware updates.

Touch the Firmware Update button to check for firmware updates using your wireless network. The update will begin automatically.

To avoid damaging the incline trainer, do not turn off the power or remove the key while the firmware is being updated.

The screen will show the progress of the update. When the update is complete, the incline trainer will turn off and then turn back on. If it does not, press the power switch into the off position. Wait for several seconds, and then press the power switch into the on position. Note: It may take a few minutes for the console to be ready for use.

Note: Occasionally, a firmware update may cause your console to function slightly differently. These updates are always designed to improve your exercise experience.

4. Calibrate the incline system of the incline trainer.

Touch the Calibrate Incline button. Then, touch the Begin button to calibrate the incline system. The incline trainer will automatically rise to the maximum incline level, lower to the minimum incline level, and then return to the starting position. This will calibrate the incline system. Press the Cancel button to return to the maintenance mode. When the incline system is calibrated, touch the Finish button.

IMPORTANT: Keep feet and other objects away from the incline trainer while the incline system is calibrating. In an emergency, pull the key from the console to stop the incline calibration.

5. View machine information.

Touch the Machine Info button to view information about your incline trainer. After you view the information, touch the back button on the screen.

6. Find keycodes.

The Keycodes button is intended to be used by service technicians to identify whether a certain button is working correctly.

7. Register the incline trainer on iFit.com.

This option is intended to be used by fitness club owners to view and track the usage history of the incline trainer on iFit.com.

Touch the Register Equipment button, enter your club token, and then touch the Submit button.

8. Exit the maintenance mode.

To exit the maintenance mode, press the back button on the console.

HOW TO USE THE WIRELESS NETWORK MODE

The console features a wireless network mode that allows you to set up a wireless network connection.

1. Access the settings main menu.

See step 1 on page 27.

2. Select the wireless network mode.

In the settings main menu, touch the Network Setup button to enter the wireless network mode.

3. Enable Wi-Fi.

Make sure that the Wi-Fi checkbox is marked with a green checkmark. If it is not, touch the Wi-Fi menu option once and wait for a few seconds. The console will search for available wireless networks.

4. Set up and manage a wireless network connection.

When Wi-Fi® is enabled, the screen will show a list of available networks. Note: It may take several seconds for the list of wireless networks to appear.

Make sure that the checkbox on the Network notification menu option is marked with a green checkmark to have the console notify you when a wireless network is within range and available.

Note: You must have your own wireless network and an 802.11b/g/n router with SSID broadcast enabled (hidden networks are not supported).

When a list of networks appears, touch the desired network. Note: You will need to know your network name (SSID). If your network has a password, you will also need to know the password.

An information box will ask if you want to connect to the wireless network. Touch the Connect to Wi-Fi button to connect to the network or touch the Cancel button to return to the list of networks. If the network has a password, touch the password entry box. A keyboard will appear on the screen. To view the password as you type it, touch the Show Password checkbox.

To use the keyboard, see HOW TO USE THE TOUCH SCREEN on page 20.

When the console is connected to your wireless network, the WiFi menu option at the top of the screen will display the word CONNECTED. Then, press the back button on the console to return to the wireless network mode.

To disconnect from a wireless network, select the wireless network and then touch the Forget button.

If you are having problems connecting to an encrypted network, make sure that your password is correct. Note: Passwords are case-sensitive.

Note: The iFit mode supports unsecured and secured (WEP, WPA™, and WPA2™) encryption. A broadband connection is recommended; performance depends on connection speed.

Note: If you have questions after following these instructions, go to support.iFit.com for assistance.

5. Exit the wireless network mode.

To exit the wireless network mode, press the back button on the console.

HOW TO USE THE INTERNET BROWSER

Note: To use the browser, you must have access to a wireless network including an 802.11b/g/n router with SSID broadcast enabled (hidden networks are not supported).

To open the browser, touch the globe button near the lower-left corner of the screen. Then, select a website.

To return to the previous web page, touch the Browser Back button. To exit the browser, touch the Return button.

To use the keyboard, see HOW TO USE THE TOUCH SCREEN on page 20.

To enter a different web address in the URL bar, first, slide your finger down the screen to view the URL bar, if necessary. Then, touch the URL bar, use the keyboard to enter the address, and touch the Go button.

Note: While you are using the browser, the speed, incline, fan, and volume buttons will still function, but the workout buttons will not function.

Note: If you have questions after following these instructions, go to support.iFit.com for assistance.

PREVENTIVE MAINTENANCE

Regular maintenance is necessary for optimal performance and long life of the incline trainer. Please read and follow all instructions below. If you have questions, see the back cover of this manual.

⚠ WARNING: If all maintenance procedures are not performed as described, components may wear excessively, the incline trainer may become damaged, a risk of injury or a risk of fire may result, and the warranty will be voided.


WEEKLY MAINTENANCE

1. **Unplug the power cord.** Inspect and properly tighten all external parts of the incline trainer.
2. Apply a mild multi-purpose cleaner to a 100 percent cotton cloth and remove any dust and grime from the handrails, uprights, foot rails, frame, and motor hood. In addition, wipe the walking platform along the sides of the walking belt. **Do not use cleaners under the walking belt.** Then, apply a small amount of the cleaner to a second cloth and wipe the console and the screen(s). **Do not spray cleaner directly onto the incline trainer or use ammonia or acid-based cleaners.**
3. Vacuum the area around the incline trainer.
4. Make sure that the walking belt is centered and properly tightened (see pages 37 and 38). If it is centered and runs smoothly, do not make any adjustments. If the walking belt needs to be adjusted, see pages 33 and 34.


MONTHLY MAINTENANCE

1. Turn on the incline trainer, and set the incline to 30%.

2. **Unplug the power cord.** Next, remove the 3/8" x 1 1/4" Screws (37), and lift off the Motor Hood (75).



3. Using a hand-held vacuum, clean the area that was under the motor hood. **Be careful to avoid touching any components.** Then, check the Drive Motor Belt (82) for wear, cracks, dust buildup, and proper tension. If the Drive Motor Belt needs to be replaced, please see the back cover of this manual.




4. Lift the edge of the walking belt and slide your hand between the walking belt and the walking board. If the underside of the walking belt is dry, you may need to apply more lubricant (see the back cover of this manual).
5. Plug in the power cord and insert the key into the console. Press the Start button. **Be careful to avoid injury; keep your hands away from moving parts and make sure that your clothes cannot become caught in moving parts.** While the walking belt is moving, check the incline trainer for unusual noises or odors. If any of these problems exists, please see the back cover of this manual. **Remove the key and unplug the power cord. See drawing 2 above.** Reattach the Motor Hood (75) with the 3/8" x 1 1/4" Screws (37).


REPLACING THE WALKING PLATFORM AND THE WALKING BELT

Inspect the walking platform periodically for wear. If there is any wood showing through the phenolic coating, or if the surface is damaged, the walking platform should be turned over or replaced. In addition, inspect the walking belt for wear. If the walking belt is cracking, tearing, or folding, it should be replaced. Follow the instructions below to turn over or replace the walking platform and/or to replace the walking belt. **As you remove screws, make sure to note which screws you remove from each part.**


1. Set the incline level to 0%. **Remove the key and unplug the power cord.** Remove the four #8 x 3/4" Screws (16), the two #8 x 1/2" Machine Screws (2), and the Front Cover (17). Next, remove the two 3/8" x 5 1/2" Screws (19) and the two 3/8" Star Washers (14) from the Front Roller (13). Then, lift the Front Roller and slide it out of the Walking Belt (18).



2. Remove the 3/8" x 1 1/4" Screws (37) and lift off the Motor Hood (75).



3. Remove the two indicated #8 x 3/4" Screws (16), the Right Rear Endcap (32), the two 3/8" x 3" Screws (30), the 3/8" x 2" Screw (84), and the 3/8" Black Washer (127). Next, slip off the Drive Motor Belt (82). Then, pull the left side of the Drive Roller (21) out of the Frame (22).



4. **See drawing 1 at the left.** Remove the four 3/8" x 1 3/4" Screws (10) and the two 3/8" x 1 1/2" Screws (20). **Note: Be very careful to avoid chipping or damaging the phenolic coating on the Walking Platform (23).** Next, lift the Walking Platform and the Walking Belt (18) to the position shown by the dotted lines.

If you are turning over or replacing the Walking Platform (23), go to step 5.


If you are replacing only the Walking Belt (18), remove the old Walking Belt and discard it. Next, slide the new Walking Belt onto the Walking Platform (23). Then, carefully follow steps 1–4 in reverse order. Turn both 3/8" x 3" Screws (30) clockwise **only four turns**. Make sure to align the Drive Motor Belt (82) so that it is straight on both pulleys. **Then, go to step 6.**

5. **See drawing 1 on page 33.** Remove the Walking Belt (18) and the Walking Platform (23) from the incline trainer.

Check to see whether both sides of the Walking Platform (23) are worn. If the underside has not previously been used, turn over the Walking Platform and continue to use it. If the Walking Platform has previously been turned over, discard the old Walking Platform. **Save all other parts.**

Using the new Walking Platform (23) or the old Walking Platform with the unworn side facing upward, carefully follow steps 1–5 in reverse order. If you are also replacing the Walking Belt (18), use the new Walking Belt. Turn both 3/8" x 3" Screws (30) clockwise **only four turns**. Make sure to align the Drive Motor Belt (82) so that it is straight on both pulleys.


6. Lift the right or left edge of the Walking Belt (18) and look for a small arrow printed on the underside of the Walking Belt; move the Walking Belt, if necessary, as you look for an arrow. **If you find an arrow, make sure that the arrow is pointing toward the rear of the incline trainer, as shown.** If it is not, remove the Walking Belt, turn it around, and slide it back onto the Walking Platform (23). Note: Your walking belt may not have an arrow. If it does not have an arrow, it can be turned either way.



Next, move the Walking Belt (18), if necessary, until the seam (not shown) across the Walking Belt is beneath the Walking Platform (23).

Then, locate the indicated marks on the left and right sides of the Walking Belt (18). The marks should be exactly 36" apart. **See drawing 3 on page 33.** If necessary, turn both 3/8" x 3" Screws (30) clockwise or counterclockwise until the marks are exactly 36" apart.

7. Center the Walking Belt (18), if necessary (see pages 37 and 38). Then, plug in the power cord, step onto the foot rails, insert the key into the console, and press the Start button. Hold the handrails and gently press one foot against the moving walking belt. If the Walking Belt stops moving, **remove the key from the console, unplug the power cord**, and turn both roller adjustment screws clockwise one turn. Continue to test the tension of the walking belt until the walking belt no longer slips. Make sure to keep the walking belt centered.



LUBRICATING THE WALKING BELT

Your incline trainer features a walking belt coated with high-performance lubricant. **IMPORTANT: Never apply silicone spray or other substances to the walking belt or the walking platform unless instructed to do so by an authorized service representative.**

PREVENTIVE MAINTENANCE RECORD

Photocopy this form and use it to record the preventive maintenance performed on the incline trainer. Each copy of the form can be used for six months (26 weeks). When maintenance is performed, write the date in the appropriate spaces. **IMPORTANT: Perform all maintenance procedures as described on pages 32 to 35. If all procedures are not performed as described, components may wear excessively, the incline trainer may become damaged, a risk of injury or a risk of fire may result, and the warranty will be voided.**

	Weekly Maintenance			Monthly Maintenance		
	Inspect and tighten all external parts of the incline trainer.	Clean the incline trainer, and vacuum the area around the incline trainer.	Check the walking belt for proper tension and alignment.	Remove the motor hood and vacuum the motor compartment.	Check the motor belt for wear, and check the walking belt for lubricant.	Check the motor for arcing, and check for noises or odors.
Week 1	/ /	/ /	/ /			
Week 2	/ /	/ /	/ /			
Week 3	/ /	/ /	/ /			
Week 4	/ /	/ /	/ /	/ /	/ /	/ /
Week 5	/ /	/ /	/ /			
Week 6	/ /	/ /	/ /			
Week 7	/ /	/ /	/ /			
Week 8	/ /	/ /	/ /	/ /	/ /	/ /
Week 9	/ /	/ /	/ /			
Week 10	/ /	/ /	/ /			
Week 11	/ /	/ /	/ /			
Week 12	/ /	/ /	/ /			
Week 13	/ /	/ /	/ /	/ /	/ /	/ /
Week 14	/ /	/ /	/ /			
Week 15	/ /	/ /	/ /			
Week 16	/ /	/ /	/ /			
Week 17	/ /	/ /	/ /	/ /	/ /	/ /
Week 18	/ /	/ /	/ /			
Week 19	/ /	/ /	/ /			
Week 20	/ /	/ /	/ /			
Week 21	/ /	/ /	/ /	/ /	/ /	/ /
Week 22	/ /	/ /	/ /			
Week 23	/ /	/ /	/ /			
Week 24	/ /	/ /	/ /			
Week 25	/ /	/ /	/ /			
Week 26	/ /	/ /	/ /	/ /	/ /	/ /

Walking Belt Replaced	/ /	Walking Platform Turned Over/Replaced	/ /
-----------------------	-----	---------------------------------------	-----

TROUBLESHOOTING

MAINTENANCE

Regular maintenance is important for optimal performance and to reduce wear. Inspect and properly tighten all parts each time the incline trainer is used. Replace any worn parts immediately.


Regularly clean the incline trainer and keep the walking belt clean and dry. First, **press the power switch into the off position and unplug the power cord.** Wipe exterior parts of the incline trainer with a damp cloth and a small amount of mild soap. **IMPORTANT: Do not spray liquids directly onto the incline trainer. To avoid damage to the console, keep liquids away from the console.** Then, thoroughly dry the incline trainer with a soft towel.

TROUBLESHOOTING

Most incline trainer problems can be solved by following the steps below. Find the symptom that applies, and follow the steps listed. If further assistance is needed, please see the back cover of this manual.

SYMPTOM: The power does not turn on

- Make sure that the power cord is plugged into a properly-earthed outlet (see page 17).
- Make sure that the key is inserted into the console.
- Check the power switch located on the incline trainer near the power cord. Make sure that the power switch is pressed into the on position.




SYMPTOM: The power turns off during use


- Check the power switch located on the incline trainer near the power cord (see drawing c at the left). Make sure that the power switch is pressed into the on position.
- Make sure that the power cord is plugged in.
- Remove the key from the console, and then reinsert it.
- Check the walking belt and the walking platform for excessive wear. Replace the walking belt or the walking platform if necessary (see pages 33 to 35).
- This may be a symptom of high amp draw. Lubricate the walking belt if necessary (see page 35).
- If the power still turns off during use, please see the back cover of this manual.

SYMPTOM: The walking belt is not centered between the foot rails


- IMPORTANT: If the walking belt rubs against the foot rails, the walking belt may become damaged. If the walking belt has shifted to the right: Remove the key and unplug the power cord.** Using a 7/32" hex key, turn the roller adjustment screws in the directions shown, 1/4 of a turn each. Be careful not to overtighten the walking belt. Then, plug in the power cord, insert the key, and walk on the incline trainer for a few minutes. Repeat until the walking belt is centered between the foot rails.



- b. **If the walking belt has shifted to the left:**
Remove the key and unplug the power cord. Using a 7/32" hex key, turn the roller adjustment screws in the directions shown, 1/4 of a turn each. Be careful not to overtighten the walking belt. Then, plug in the power cord, insert the key, and walk on the incline trainer for a few minutes. Repeat until the walking belt is centered between the foot rails.



- c. **If the walking belt slips when walked on, first remove the key and UNPLUG THE POWER CORD.** Using a 7/32" hex key, turn both roller adjustment screws clockwise, 1/4 of a turn. To properly tighten the walking belt, see step 7 on page 35. Be careful to keep the walking belt centered. Then, plug in the power cord, insert the key, and walk on the incline trainer for a few minutes. Repeat until the walking belt is properly tightened.



SYMPTOM: The walking belt stops or the incline cannot be adjusted even though the console remains lit

- a. This indicates that a controller error may have occurred. To correct the problem, turn the power switch off, wait 5 seconds, and then turn the power switch back on.
- b. This may be a symptom of high amp draw. Lubricate the walking belt if necessary (see page 35).

SYMPTOM: The incline system does not function properly or the incline system does not appear to be at the incline level shown in the display

- a. Calibrate the incline system (see step 4 on page 29).
- b. If the incline system still does not function properly, please see the back cover of this manual.

EXERCISE GUIDELINES

⚠ WARNING: Before beginning this or any exercise program, consult your physician. This is especially important for persons over age 35 or persons with pre-existing health problems.

The heart rate monitor is not a medical device. Various factors may affect the accuracy of heart rate readings. The heart rate monitor is intended only as an exercise aid in determining heart rate trends in general.

These guidelines will help you to plan your exercise program. For detailed exercise information, obtain a reputable book or consult your physician. Remember, proper nutrition and adequate rest are essential for successful results.

EXERCISE INTENSITY

Whether your goal is to burn fat or to strengthen your cardiovascular system, exercising at the proper intensity is the key to achieving results. You can use your heart rate as a guide to find the proper intensity level. The chart below shows recommended heart rates for fat burning and aerobic exercise.

165	155	145	140	130	125	115	♥♥
145	138	130	125	118	110	103	♥
125	120	115	110	105	95	90	♥
20	30	40	50	60	70	80	

To find the proper intensity level, find your age at the bottom of the chart (ages are rounded off to the nearest ten years). The three numbers listed above your age define your "training zone." The lowest number is the heart rate for fat burning, the middle number is the heart rate for maximum fat burning, and the highest number is the heart rate for aerobic exercise.

Burning Fat—To burn fat effectively, you must exercise at a low intensity level for a sustained period of time. During the first few minutes of exercise, your body uses carbohydrate calories for energy. Only after the first few minutes of exercise does your body begin to use stored fat calories for energy. If your goal is to burn fat, adjust the intensity of your exercise until your heart rate is near the lowest number in your training zone. For maximum fat burning, exercise with your heart rate near the middle number in your training zone.

Aerobic Exercise—If your goal is to strengthen your cardiovascular system, you must perform aerobic exercise, which is activity that requires large amounts of oxygen for prolonged periods of time. For aerobic exercise, adjust the intensity of your exercise until your heart rate is near the highest number in your training zone.

WORKOUT GUIDELINES

Warming Up—Start with 5 to 10 minutes of stretching and light exercise. A warm-up increases your body temperature, heart rate, and circulation in preparation for exercise.

Training Zone Exercise—Exercise for 20 to 30 minutes with your heart rate in your training zone. (During the first few weeks of your exercise program, do not keep your heart rate in your training zone for longer than 20 minutes.) Breathe regularly and deeply as you exercise; never hold your breath.

Cooling Down—Finish with 5 to 10 minutes of stretching. Stretching increases the flexibility of your muscles and helps to prevent post-exercise problems.

EXERCISE FREQUENCY

To maintain or improve your condition, complete three workouts each week, with at least one day of rest between workouts. After a few months of regular exercise, you may complete up to five workouts each week, if desired. Remember, the key to success is to make exercise a regular and enjoyable part of your everyday life.

SUGGESTED STRETCHES

The correct form for several basic stretches is shown at the right. Move slowly as you stretch—never bounce.

1. Toe Touch Stretch

Stand with your knees bent slightly and slowly bend forward from your hips. Allow your back and shoulders to relax as you reach down toward your toes as far as possible. Hold for 15 counts, then relax. Repeat 3 times. Stretches: Hamstrings, back of knees and back.

2. Hamstring Stretch

Sit with one leg extended. Bring the sole of the opposite foot toward you and rest it against the inner thigh of your extended leg. Reach toward your toes as far as possible. Hold for 15 counts, then relax. Repeat 3 times for each leg. Stretches: Hamstrings, lower back and groin.

3. Calf/Achilles Stretch


With one leg in front of the other, reach forward and place your hands against a wall. Keep your back leg straight and your back foot flat on the floor. Bend your front leg, lean forward and move your hips toward the wall. Hold for 15 counts, then relax. Repeat 3 times for each leg. To cause further stretching of the achilles tendons, bend your back leg as well. Stretches: Calves, achilles tendons and ankles.

4. Quadriceps Stretch

With one hand against a wall for balance, reach back and grasp one foot with your other hand. Bring your heel as close to your buttocks as possible. Hold for 15 counts, then relax. Repeat 3 times for each leg. Stretches: Quadriceps and hip muscles.

5. Inner Thigh Stretch

Sit with the soles of your feet together and your knees outward. Pull your feet toward your groin area as far as possible. Hold for 15 counts, then relax. Repeat 3 times. Stretches: Quadriceps and hip muscles.



PART LIST

Model No. FMTK74817-INT.0 R0218A


Key No.	Qty.	Description	Key No.	Qty.	Description
1	2	Side Cover	51	10	5/16" x 1" Screw
2	6	#8 x 1/2" Machine Screw	52	1	Drive Motor
3	4	Center Isolator	53	1	Drive Motor Isolator
4	9	3/8" Jam Nut	54	2	3/4" x 1/2" Screw
5	1	Console Back	55	2	Torsion Bar Bushing
6	4	1/4" x 1/2" Screw	56	1	Base Frame
7	1	Drive Roller Pulley	57	4	5/16" x 3/4" Screw
8	2	1/4" x 1" Screw	58	2	3/8" Jam Nut
9	2	Front Isolator	59	4	Incline Link Bushing
10	4	3/8" x 1 3/4" Screw	60	2	3/8" x 2 1/2" Shoulder Bolt
11	1	Left Foot Pad	61	12	5/16" Star Washer
12	1	Right Foot Pad	62	1	Torsion Bar
13	1	Front Roller	63	1	Power Switch
14	6	3/8" Star Washer	64	2	3/8" x 3" Screw
15	1	Controller Box	65	1	Receptacle
16	38	#8 x 3/4" Screw	66	2	#8 x 1/2" Screw
17	1	Front Cover	67	4	#4 x 1/2" Screw
18	1	Walking Belt	68	1	Electronics Bracket
19	2	3/8" x 5 1/2" Screw	69	1	Small Console Cover
20	2	3/8" x 1 1/2" Screw	70	1	Incline Link Bar
21	1	Drive Roller	71	1	2 3/8" Clevis Pin
22	1	Frame	72	4	Incline Motor Bushing
23	1	Walking Platform	73	1	Incline Motor
24	2	Plastic Platform Spacer	74	1	1 3/4" Clevis Pin
25	2	1/4" x 3/4" Flat Head Bolt	75	1	Motor Hood
26	2	Rear Roller Guard	76	1	Hood Support Bracket
27	2	Cage Nut	77	1	Right Hood Cover
28	1	Left Rear Endcap	78	8	1/4" x 1/2" Bolt
29	12	#6 x 1/4" Screw	79	2	3/8" x 2 1/2" Bolt
30	3	3/8" x 3" Screw	80	4	5/16" Nut
31	2	Torsion Bar Spacer	81	2	Wheel
32	1	Right Rear Endcap	82	1	Drive Motor Belt
33	1	3/8" x 2 1/2" Bolt	83	2	#10 x 1/2" Screw
34	4	5/16" x 1 1/4" Screw	84	1	3/8" x 2" Screw
35	2	#10 x 1/2" Screw	85	8	1/4" x 3/4" Screw
36	1	Resistor	86	1	#8 x 1 5/8" Bolt
37	4	3/8" x 1 1/4" Screw	87	8	1/4" x 1/2" Screw
38	2	Leveling Foot	88	2	5/16" x 3/4" Screw
39	1	Fan Airflow Adjuster	89	3	High Voltage Decal
40	2	1/4" x 3/4" Bolt	90	2	Incline Motor Spacer
41	1	5/8" x 1" Shoulder Bolt	91	2	1/4" x 2 3/8" Bolt
42	6	1/4" x 5/8" Screw	92	1	Console Access Cover
43	4	5/16" Flat Washer	93	2	5/16" x 2 1/2" Bolt
44	4	5/16" x 1" Screw	94	8	1/4" Lock Nut
45	1	Idler Pulley	95	3	#8 Nut
46	2	Hub	96	2	#8 Star Washer
47	2	Frame Pivot Bearing	97	2	Deck Maintenance Decal
48	2	Snap Ring	98	4	#8 x 3/4" Machine Screw
49	1	Idler Wheel	99	16	#4 x 5/16" Screw
50	4	3/8" x 2 3/4" Screw	100	1	Power Board

Key No.	Qty.	Description	Key No.	Qty.	Description
101	1	Filter	137	1	M3 x 8mm Bolt
102	2	#6 x 1/2" Screw	138	1	98°C Thermal Switch
103	2	1/2" Jam Nut	139	1	M3 Nut
104	2	#10 Nut	140	1	Switch Bracket
105	1	Key/Clip	141	1	Fan
106	2	Cotter Pin	142	1	Left Outer Cover
107	27	#8 x 3/4" Console Screw	143	1	Right Outer Cover
108	4	#8 x 1/2" Cover Screw	144	1	Left Inner Cover
109	1	Incline Motor Bracket	145	1	Right Inner Cover
110	2	Caster	146	2	Handrail Wire
111	2	Caster Bracket	147	2	Handrail Cap
112	1	Left Handrail Assembly	148	2	Upright Cap
113	1	Right Handrail Assembly	149	1	Left Upright
114	1	104°C Thermal Switch	150	1	Right Upright
115	2	Base Cap	151	1	Left Upright Cover
116	1	Upright Wire Harness	152	1	Right Upright Cover
117	1	Ferrite Clamp	153	1	Handrail Base Top Cover
118	1	Power Cord Bracket	154	1	Handrail Base
119	2	Metal Spacer	155	1	Handrail Base Bottom Cover
120	2	1/2" Jam Nut	156	1	Left Tray
121	2	Caution Decal	157	1	Right Tray
122	1	Hazard Warning Decal	158	1	12" Ground Wire
123	1	Warning Decal	159	1	14" Ground Wire
124	4	Motor Mount Bushing	160	2	Handrail Extension Wire
125	1	Upright Coaxial Cable	161	1	Coaxial Extension Cable
126	1	1/2" x 3 1/2" Shoulder Bolt	162	1	Upright Extension Wire
127	2	3/8" Black Washer	163	1	Console Base
128	1	Left Controller	164	1	Console
129	1	Frame Wire Harness	165	1	Small Console Cover
130	1	Right Controller	166	1	Console Cover
131	9	Standoff	167	1	Console Frame
132	2	Pulse Top	168	2	#8 x 3/4" Console Ground Screw
133	1	Outlet Plate	169	1	TV Board
134	2	Pulse Bottom	170	4	M4 x 16mm Screw
135	9	#8 x 1/2" Machine Screw	171	7	#8 x 3/4" Pan Head Screw
136	2	Frame Crossbar Cap	*	—	User's Manual

Note: Specifications are subject to change without notice. Please see the back cover of this manual for information about ordering replacement parts. *These parts are not illustrated.


EXPLODED DRAWING A

Model No. FMTK74817-INT.0 R0218A




EXPLODED DRAWING B

Model No. FMTK74817-INT.0 R0218A




EXPLODED DRAWING C

Model No. FMTK74817-INT.0 R0218A




EXPLODED DRAWING D

Model No. FMTK74817-INT.0 R0218A



EXPLODED DRAWING E

Model No. FMTK74817-INT.0 R0218A



HOW TO CONTACT CUSTOMER CARE

If you have questions after reading this manual, or if parts are damaged or missing, please contact Customer Care at one of the phone numbers or addresses listed below. **Please note the model number, serial number, and name of the product (see the front cover of this manual) before contacting Customer Care. If you are ordering replacement parts, please also note the key number and description of each part (see the PART LIST and the EXPLODED DRAWING near the end of this manual).**

In the United States

Call: 1-800-201-2109 Mon.–Fri. 6 a.m.–6 p.m. MT

Email: customercare@freemotionfitness.com

Write:

FreeMotion Fitness

1500 South 1000 West

Logan, UT 84321-9813

United States

Outside the United States

Call: 001-800-527-5417 or 001-435-786-3521

Mon.–Fri. 6 a.m.–3 p.m. USA Mountain Time

Email: intlcustomercare@freemotionfitness.com

LIMITED WARRANTY

WARRANTY PERIODS AND COVERAGE

FreeMotion Fitness warrants this product to be free from defects in workmanship and material under normal use and service conditions. Parts and labor are warranted for one (1) year, unless otherwise specified on the invoice.

The warranty period commences on the invoice date of purchase. Any parts repaired or replaced during this warranty period will be warranted for the remainder of the original warranty period.

CONDITIONS AND LIMITATIONS

The following will void the warranty on this product:

1. This warranty applies only to the original owner and is non-transferable.
2. The labor warranty applies only to products sold in the US and Canada. Contact your authorized FreeMotion Fitness dealer for details on labor coverage in your country.
3. Any misuse, abuse, or improper service.
4. Users who weigh more than the maximum user weight listed in this manual.
5. Damage caused by moving the product or improper storage including moving or storing the product on its side.
6. Use or storage of the product outdoors or in high-humidity environments including spa and pool areas.
7. Damage caused by improper wiring or insufficient electrical current. Note: This product may not have wiring.

This warranty shall not apply to the following:

1. Cosmetic items including grips, seats, decals, and labels.

2. Pick-up, delivery, or freight charges involved with a repair.
3. Any problem as a result of improper assembly or delivery.

WHAT TO DO IF SERVICE IS REQUIRED

FreeMotion Fitness warranty service may be obtained by contacting the authorized dealer from which you purchased this product. Make sure to retain your original invoice and serial number information. If this product experiences a failure under the warranty terms set forth, FreeMotion Fitness shall provide at their option either repair, replacement, or refund of the purchase price. FreeMotion Fitness compensates service providers for warranty trips within their service area. You may be charged additionally for service calls beyond this service area.

FreeMotion Fitness is not responsible or liable for indirect, special, or consequential damages arising out of or in connection with the use or performance of the product; damages with respect to any economic loss, loss of property, loss of revenues or profits, loss of enjoyment or use, or cost of removal or installation; or other consequential damages. Some regions do not allow the exclusion or limitation of consequential damages. Accordingly, the above limitation may not apply to you. This warranty gives you specific rights, and you may have other rights that vary from region to region.

TO CONTACT FREEMOTION FITNESS

See HOW TO CONTACT CUSTOMER CARE above.