


FREEMOTION E P I C LEG PRESS

OWNER'S MANUAL

Model No. GZFI8043.4

Serial No. _____

Write the serial number in the space above for future reference.




Serial Number
Decal (inside
tower)

QUESTIONS?

At FreeMotion Fitness, we are committed to providing complete customer satisfaction. If you have questions, see **HOW TO CONTACT CUSTOMER CARE** on the back cover of this manual.

CAUTION

Read all precautions and instructions in this manual before using this equipment. Save this manual for future reference.



Visit our website at

www.freemotionfitness.com

TABLE OF CONTENTS

IMPORTANT PRECAUTIONS 3

WARNING DECAL PLACEMENT4

BEFORE YOU BEGIN 5

ADJUSTMENTS6

MAINTENANCE7

CABLE DIAGRAM12

PART LIST13

EXPLODED DRAWING14

HOW TO CONTACT CUSTOMER CAREBack Cover

IMPORTANT PRECAUTIONS

⚠ WARNING: To reduce the risk of serious injury, read the following important precautions before using the strength equipment.

1. Read all instructions in this manual before using the strength equipment. Use the strength equipment only as described in this manual.
2. It is the owner's responsibility to ensure that there is enough space around the strength equipment for the intended exercise. Do not crowd the strength equipment.
3. Using the anchor strap to provide maximum stability, anchor the strength equipment to the floor where required or whenever possible.
4. Use the strength equipment only on a level surface. Cover the floor beneath the strength equipment to protect the floor.
5. It is the responsibility of the owner to ensure that all users of the strength equipment are adequately informed of all precautions, have read and understood all warning and caution labels, and are informed of how to use the strength equipment properly.
6. Keep children under 12 and pets away from the strength equipment at all times.
7. Always wear athletic shoes for foot protection while exercising.
8. Make sure the weight pin is completely inserted into one of the weight plates.
9. All users of the strength equipment should be instructed to report any injury or strength equipment irregularity to facility staff immediately.
10. Keep hands and feet away from moving parts. Do not lean on or rest your hands on the strength equipment when it is in use.
11. Check all cables, cable connections, and pulleys before each use of the strength equipment. Make sure all parts are properly tightened. Replace any worn parts immediately.
12. Make sure the cable remains on the pulleys at all times. If the cable binds while you are exercising, stop immediately and make sure the cable is on the pulleys and nothing is interfering with the cable or pulleys. Replace all cables at least every two years.
13. The strength equipment is designed to support a maximum user weight of 159 kg. (350 lbs.).
14. Keep the strength equipment indoors, away from moisture and dust. Do not put the strength equipment in a garage or covered patio, or near water.
15. If you feel pain or dizziness at any time while exercising, stop immediately and begin cooling down.

⚠ WARNING: Before beginning this or any exercise program, consult your physician. This is especially important for persons over the age of 35 or persons with pre-existing health problems. Read all instructions before using. ICON assumes no responsibility for personal injury or property damage sustained by or through the use of this product.

WARNING DECAL PLACEMENT

The decals shown below have been placed on the strength equipment in the indicated locations. If a decal is missing or illegible, see **HOW TO CONTACT CUSTOMER CARE** on the back cover of this manual, and order a free replacement decal. Apply the decal in the location shown.


 **WARNING**

- Obtain a medical exam before beginning an exercise program.
- Inspect the machine before use. Do not use if machine appears damaged or inoperable.
- Keep body and clothing free and clear of all moving parts.
- Be certain that the weight pin is completely inserted.
- NEVER pin the weight stack in an elevated position. NEVER use the machine if found in this condition.
- INSPECT all cables, straps and their connections. Do not use if any component is found to be worn or damaged.
- Do not use dumbbells or other means to incrementally increase the weight resistance, other than those provided by the manufacturer.
- Do not allow children on machines. Machine use by teenagers must be supervised by a knowledgeable adult.
- This equipment to be used only under qualified supervision.
- Do not remove this label. REPLACE IF DAMAGED.

 **CAUTION**



Weight selector pin must be fully inserted into the weight plate.



Decal 1
Shown at 70%
GZ7003

Decal 3

 **CAUTION**

Do not press yellow pedal while platform assembly is under load.

211883

Decal 2
GZ7026

Decal 4
Shown at 85%

 **CAUTION**

KEEP AWAY FROM MOVING PARTS. FAILURE TO DO SO COULD RESULT IN PERSONAL INJURY.

7005-1199


BEFORE YOU BEGIN

Thank you for selecting the FREEMOTION EPIC™ LEG PRESS strength equipment. The strength equipment's stylish ergonomic design and never-before-seen features improve upon traditional strength training. The innovative features and quality construction provide a reliable product for your club. And the advanced solutions to isolating individual muscle groups make the LEG PRESS strength equipment a key tool for members to reach their goals.

For your benefit, read this manual carefully before using the strength equipment. If you have questions

after reading this manual, see HOW TO CONTACT CUSTOMER CARE on the back cover of this manual. To help us assist you, please note the product model number and serial number before calling. The model number is GZFI8043.4. The serial number can be found on a decal attached to the strength equipment (see the front cover of this manual).

Before reading further, please review the drawing below and familiarize yourself with the parts that are labeled.




ADJUSTMENTS

This section explains how to adjust the strength equipment. Make sure all parts are properly tightened each time the strength equipment is used. Replace any worn parts immediately.

ADJUSTING THE RESISTANCE


To change the amount of resistance for your workout, insert the weight pin into the desired weight. Make sure that the weight pin is fully inserted into the weight stack.



ADJUSTING THE FOOT PLATE

To adjust the starting position of the foot plate forward, pull the red handle on the bottom of the foot plate toward the seat.

To adjust the starting position of the foot plate backward, depress the yellow foot pedal, push the foot plate to the desired position, and then release the foot pedal.




⚠ WARNING: Always make sure that the foot plate pin is fully engaged in the selector bracket before using the foot plate.

ADJUSTING THE BACKREST

To adjust the backrest forward, pull the backrest knob out and move the backrest to the desired position. Then, reengage the backrest knob.

To adjust the backrest backward, pull the backrest knob out and move the backrest to the desired position. Then, reengage the backrest knob.



MAINTENANCE

It is important for safe and trouble-free operation of your FREEMOTION EPIC strength equipment to perform routine preventive maintenance on a regular basis. Instruct all personnel to perform equipment inspection and maintenance requirements. Personnel must record and report any accident. To maintain the strength equipment's warranty, use only FREEMOTION EPIC parts for repair or replacement. If there are any questions or concerns, see HOW TO CONTACT CUSTOMER CARE on the back cover of this manual.

SCHEDULED MAINTENANCE

DAILY

1. Upholstery—General cleaning:

- Wipe using a soft cloth dampened with a light solution of mild soap and warm water.
- If necessary, use a soft bristle brush with the cleaning solution.
- Rinse thoroughly using a soft cloth dampened with clean water and dry thoroughly.

2. Upholstery—Difficult stains:

- Spray the stain with a non-abrasive household cleaner such as FORMULA 409® cleaner, SIMPLE GREEN®, or a similar product.
- Rub the area gently and let it sit for a few minutes.
- Rinse thoroughly using a soft cloth dampened with clean water and dry thoroughly.
- Repeat if necessary using a soft bristle brush.

Optional method for difficult stains:

- Rub the area gently using a soft cloth dampened with rubbing alcohol.
- Rinse thoroughly using a soft cloth dampened with clean water and dry thoroughly.

CAUTION: When using any cleaning product, try it first in an inconspicuous place to ensure that there is no damage to the material. Follow the directions and adhere to the safety precautions of the manufacturer of each cleaning product used. FreeMotion Fitness and its vendors cannot be held liable for damage or injuries resulting from the use or misuse of cleaning products.

3. Frames:

- Wipe using a soft cloth dampened with a light solution of mild soap and warm water. Rinse thoroughly using a soft cloth dampened with clean water and dry thoroughly.

Important: Do not use abrasive cleaners, because they may scratch the equipment. Strong cleaners and abrasives will damage decals. Use caution around decals. Do not use solvents such as lacquer thinner, kerosene, gasoline, or similar liquids.


WEEKLY

1. Hardware:

- Check all nuts and bolts. Tighten them as required. **Important:** All FREEMOTION EPIC cushions are fabricated using dense plywood with tee-nuts installed for bolting to the machine framework. Because these tee-nuts are held by the plywood, they will not withstand the torque that standard nuts and bolts will. Therefore, when tightening the cushion bolts, turn them only until they are snug and the cushion does not move or feel loose. Overtightening may strip the tee-nuts from the plywood and make it impossible to remove the cushion in the future.


2. Cables:

- Check the cable for proper tension.
- Check the entire length of the cable by pulling each handle individually to its fully extended position and inspecting the cable that is exposed on the exterior of the machine, as well as the cable inside of the cut stack tower.
- Run your fingers along the cable, paying close attention at the bends and attachment points.
- Watch for the following conditions, which may indicate a worn cable in need of replacement:
 - A. torn or split cable sheath that exposes the cable
 - B. kinked or severely bent cable
 - C. curled or twisted sheath
 - D. stretched cable sheath, showing a thinning cross-section



3. Belts:

- Run your fingers along the belt, paying close attention at the bends and attachment points.
- Watch for the following conditions, which may indicate a worn belt in need of replacement:
 - A. waves
 - B. stretched areas, showing a thinning cross-section
 - C. peeling skin
 - D. cracks or splits
 - E. strands hanging out or significant fraying



MONTHLY

1. Grips:

- Check and replace as needed.

YEARLY OR AS REQUIRED

1. Weight Stack Guide Rods:

- Clean and lubricate the full length by wiping using a soft cloth containing a lightweight motor oil, 10W-40 or 10W-30 weight. Only a light coating over the entire length is needed.


Note: Do not use TEFLON® or silicone-based lubricants.

CABLE TENSION CHECK

1. Insert the weight pin into the top weight plate.
2. Slowly raise and lower the top weight by normal machine use. The top weight should come to rest just on top of the second weight when the leg lever is returned to the resting position.
 - If there is too much tension on the cable, the top weight will not rest on the second weight, and it may be difficult to insert the weight pin into the weight plates.
 - If there is not enough tension on the cable, the top weight will not lift immediately when the leg lever is lifted. Ideally, the leg lever/cable should not move more than 1,3 cm (1/2 in.) from the resting position before the top weight begins to lift.
3. If there is too much or not enough tension on the cable, adjust the cable as described in CABLE ADJUSTMENTS on page 10.

CABLE GUARDS

Check for alignment periodically to ensure that cable guards are not rubbing on the cable and that they are performing their intended duty. If the alignment is not proper, loosen the bolt slightly, readjust the cable guard as necessary, and retighten the bolt.



CABLE ADJUSTMENTS


CAUTION: After making any cable adjustment, pull the leg lever using a light load and have someone make sure that the cable is not derailed from a pulley or rubbing on a guard (see CABLE GUARDS on page 9).

INITIAL ADJUSTMENT


Tower Pulley Adjustment—

Tools required: 5/16" hex key, 9/16" open end wrench

1. Lift the top weight off the weight stack and insert the weight pin into the third weight and the sixth hole from the top of the weight rod.



2. Loosen the locknut attaching the pulley to the bracket in the top of the tower.




3. Move the pulley to the appropriate location in the bracket:
 - If more slack is needed in the cable, move the pulley downward.
 - If less slack is needed in the cable, move the pulley upward.
4. Make sure that the pulley guard is properly oriented (see CABLE GUARDS on page 9) and retighten the locknut attaching the pulley to the bracket.
5. Lift the top weight and remove the weight pin. Lower the top weight onto the third weight.
6. Readjust as necessary.

ADDITIONAL ADJUSTMENT

Top Weight Adjustment—

Tools required: 5/32" hex key

1. If the cable needs to be shortened 2 cm (3/4 in.) or more, follow the instructions in step 1 in the left hand column on this page. Then, go to step 2 below.
2. See the drawing in step 2 in the left hand column on this page. Loosen the locknut and move the pulley to the bottom of the slot.
3. Lift the coupler cover from the top weight coupler. Loosen but do not remove the two set screws from each side of the weight coupler.




4. Pull the cable from the top weight coupler. Determine the amount the cable needs to be shortened and cut that much off the end of the cable. **The cable must be long enough to be held by the set screws without lifting the top two weights off the third weight.**
5. Cut the cable to the desired length and strip 2.5 cm (1 in.) of the vinyl sheathing from the cut end of the cable.
6. Insert the cable into the top weight coupler until all four set screws can be tightened against the cable. Tighten each set screw alternately until all four set screws have been tightened to 17 Newton-meters (150 inch/pounds).
7. Lower the coupler cover over the top weight coupler.

SERVICING THE WEIGHT STACK

Servicing the weight stack involves replacing the two guide bushings and weight insert in the top weight. To order these parts, see HOW TO CONTACT CUSTOMER CARE on the back cover of this manual.

1. Remove the wingnuts under the tower cap and remove the tower cap from the tower.
2. Remove the guide rod nuts and washers from the top of each guide rod.
3. Lift the coupler cover and loosen the four set screws—this will release the cable.
4. Lift the guide rods out of the top of the tower.
5. Remove the rod nut, rod star washer, and rod washer from the top of the weight tube. Lift and rotate the top weight, and remove it through the front opening of the tower.
6. Use a punch to drive the two existing guide bushings and weight insert out of the top weight.



7. To insert the new bushings and weight insert, hold a bushing square to the face of one of the holes in the top weight, place a protective piece of wood on top of the bushing, and lightly tap the bushing into place. The bushing should be flush with the surface. Repeat with the other bushing and weight insert.
8. Replace the top weight. Next, tighten the rod nut, rod star washer, and rod washer onto the weight tube.
9. Reattach the cable to the top weight coupler. Retighten the four set screws into the threaded

holes. Tighten the set screws equally until they contact the cable. Then, tighten each screw alternately 1/4 turn, until all are set to 17 Newton-meters (150 inch/pounds).

10. Clean and lubricate the guide rods by wiping them with a soft cloth containing a lightweight motor oil, 10W-40 or 10W-30 weight. Apply only a light coating over the entire length. **Note: Do not use TEFLON® or silicone-based lubricants.**
11. Reinsert the guide rods through the top of the tower and into the weight stack. **Note: If the weight stack has shifted, use a short bar to realign the holes in the weight plates. Hold the weight plates while inserting the guide rods.**



⚠ WARNING: Do not force the guide rods into the weights; doing so will damage the guide bushings and the weight inserts.

12. Reattach the guide rods to the top of the frame with the two guide rod nuts and washers.
13. Insert the weight pin in the top weight. Pull the handle, lifting the top weight all of the way to the top. Slowly return the handle to the resting position. If the top weight sticks, loosen one of the guide rod screws. Lift the top weight to the top again. Retighten the guide rod nut. Check the full travel again and readjust the guide screws as necessary.
14. While slowly pulling the handle, have someone check the cable guard on the top weight to ensure that it is not dragging or rubbing on the cable.
15. Replace the tower cap and retighten the wingnuts onto the bolts.

CABLE DIAGRAM

The diagrams show the proper route of the belt and the cable. Use the diagram to make sure that the belt, the cable, and the cable guards have been assembled correctly. If the belt or the cable has not been correctly routed, the strength equipment will not function properly and damage may occur. The numbers show the correct route of the belt and the cable.

Make sure that the cable guards do not touch or bind the cable.



PART LIST—Model No. GZFI8043.4

R0706A


If replacement parts are needed, or if parts are missing or damaged, see HOW TO CONTACT CUSTOMER CARE on the back cover of this manual.

Key No.	Qty.	Description	Key No.	Qty.	Description
1	1	Base	54	2	3/8" x 3/4" Button Screw
2	1	Tower	55	1	8" Pivot Rod
3	1	Tower Cover	56	6	1" Bearing
4	1	Foot Plate	57	1	Cam Belt
5	1	Cam	58	6	1" Snap Ring
6	1	Left Brace	59	6	Nylon Washer
7	1	Right Brace	60	6	3/8" x 2" Bolt
8	1	Selector Bracket	61	4	Cable Guard
9	1	Brace Tube	62	2	1/2" x 1 1/4" Screw
10	1	Counter Weight	63	4	3/8" x 1 1/4" Bolt
11	1	Foot Plate Bar	64	17	3/8" Nut
12	2	Weight Guide	65	1	Top Weight
13	2	Long Trim	66	1	Yellow Cover
14	24	Weight	67	2	Bushing
15	1	Seat	68	1	1/4" x 2 1/2" Flat Head Bolt
16	1	Backrest	69	9	3/8" x 1 3/4" Bolt
17	1	Backrest Frame	70	1	Threaded Spacer
18	1	Right Handle	71	3	5/16" Nut
19	1	Left Handle	72	1	Rounded Clamp End
20	2	Base Foot	73	2	1/2"-20 Nut
21	4	5/16" Washer	74	4	Rivet
22	4	Pulley	75	1	Clamp End
23	1	Threaded Clamp End	76	1	Threaded Tapered Pop-pin
24	1	Clamp Center	77	2	1/8" Roll-pin
25	1	Long Panel	78	4	5/16" X 5/16" Set Screw
26	1	Long Panel Frame	79	1	Anchor Strap
27	1	Cover	80	1	10 1/2" Pivot Rod
28	1	Long Clamp End	81	1	Shock
29	1	Bumper	82	1	Belt Pulley
30	1	Short Panel Frame	83	1	3 1/2" Pivot Rod
31	1	Short Panel	84	2	5/16" x 1" Bolt
32	4	Tower Foot	85	1	Selector Tab
33	49	Weight Insert	86	1	Seat Pivot Bar
34	2	Guide Bushing	87	1	Pedal Bracket
35	1	Weight Rod	88	1	1/2" Rod End
36	1	1" Washer	89	2	3/8" Serrated Washer
37	1	Star Washer	90	1	Weight Pin
38	1	1-14 UNF Nut	91	4	2 1/2" Snap Ring
39	1	Coupler Cover	92	1	3/8" x 3/4" Screw
40	1	Weight Cable	93	4	Guide Rod Washer
41	16	3/8" x 1/2" Button Bolt	94	4	Guide Rod Nut
42	2	Handle Grip	95	2	5/8" Snap Ring
43	1	Tapered Pop-pin	96	1	1/2" Nylon Locknut
44	1	Backrest Knob	97	1	1/2" x 1 3/4" Bolt
45	1	Long Base Foot	98	8	3/8" x 1" Screw
46	5	1/4" Locknut	99	3	1/4" x 3/4" Button Screw
47	1	Backrest Bracket	100	1	Ball Stud
48	6	3/8" x 1" Non-patch Bolt	101	2	Spring
49	2	1/4" x 1" Button Bolt	102	1	3/8" Rod End
50	5	Cone Bumper	103	1	Weight Tube Pin
51	2	Weight Bumper	104	2	Tube Pin Cap
52	2	Wingnut	#	1	Owner's Manual
53	1	Spacer			

Note: “#” indicates a non-illustrated part. Specifications are subject to change without notice.


EXPLODED DRAWING A—Model No. GZFI8043.4

R0706A



EXPLODED DRAWING B—Model No. GZFI8043.4

R0706A



HOW TO CONTACT CUSTOMER CARE

If you have questions after reading this manual, or if you require assistance, please contact Customer Care at the address and phone number listed below. Please be prepared to give the following information:

- The MODEL NUMBER of the product (GZFI8043.4).
- The NAME of the product (FREEMOTION EPIC LEG PRESS strength equipment).
- The SERIAL NUMBER of the product (see the front cover of this manual).
- When ordering replacement parts, please also give the KEY NUMBER and DESCRIPTION of the part(s) (see the PART LIST and the EXPLODED DRAWING on pages 13 to 15 of this manual).

Customer Care: 1-800-201-2109, Monday–Friday, 8 a.m.–5 p.m. Mountain Time
FreeMotion Fitness, Inc. • 1096 Elkton Dr., Suite 600 • Colorado Springs, CO 80907