

8 MPH PROGRAMMABLE SPEED 826•EXP™


1.25 HORSEPOWER DC MOTOR
POWER INCLINE
CUSHION DECK

PRO•FORM®

A Subsidiary of Weider Health and Fitness, Inc.

Model No. PF826010

Serial No. _____



QUESTIONS?

As a manufacturer, we are committed to providing you complete customer satisfaction. If you have questions, or find there are missing or damaged parts, we will guarantee you complete satisfaction through direct assistance from our factory. TO AVOID UNNECESSARY DELAYS, PLEASE CALL DIRECT TO OUR TOLL-FREE CUSTOMER HOT LINE. The trained technicians on our Customer Hot Line will provide immediate assistance, free of charge to you.


CUSTOMER HOT LINE:

1-800-999-3756

Mon.-Fri., 6 a.m.-6 p.m. MST

CAUTION:

Read all safety precautions and instructions in this manual carefully before using this equipment. Save this manual for future reference.



OWNER'S MANUAL

TABLE OF CONTENTS

Limited Warranty	2
Important Safety Precautions	3
Before You Begin	4
Assembly	5
Operation and Adjustment	5
Maintenance and Trouble-Shooting	11
Conditioning Guidelines	13
Part List	14
Exploded Drawing	15
Ordering Replacement Parts	Back Cover

LIMITED WARRANTY

PRO FORM Fitness Products, Inc. ("Pro Form"), warrants this product to be free from defects in workmanship and material, under normal use and service conditions, for a period of ninety (90) days from the date of purchase. This warranty extends only to the original purchaser. PRO-FORM's obligation under this warranty is limited to replacing or repairing, at PRO FORM's option, the product at one of its authorized service centers. All products for which warranty claim is made must be received by PRO FORM at one of its authorized service centers with all freight and other transportation charges prepaid, accompanied by sufficient proof of purchase. All returns must be pre-authorized by PRO FORM. This warranty does not extend to any product or damage to a product caused by or attributable to freight damage, abuse, misuse, improper or abnormal usage or repairs not provided by a PRO FORM authorized service center or for products used for commercial or rental purposes. No other warranty beyond that specifically set forth above is authorized by PRO FORM.

PRO FORM IS NOT RESPONSIBLE OR LIABLE FOR INDIRECT, SPECIAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THE PRODUCT OR OTHER DAMAGES WITH RESPECT TO ANY ECONOMIC LOSS, LOSS OF PROPERTY, LOSS OF REVENUES OR PROFITS, LOSS OF ENJOYMENT OR USE, COSTS OF REMOVAL, INSTALLATION OR OTHER CONSEQUENTIAL DAMAGES OF WHATSOEVER NATURE. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES. ACCORDINGLY, THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

THE WARRANTY EXTENDED HEREUNDER IS IN LIEU OF ANY AND ALL OTHER WARRANTIES AND ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE IS LIMITED IN ITS SCOPE AND DURATION TO THE TERMS SET FORTH HEREIN. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS. ACCORDINGLY, THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

This warranty gives you specific legal rights. You may also have other rights which vary from state to state.

PRO FORM FITNESS PRODUCTS, INC., 1500 S. 1000 W., Logan, UT 84321-9813

IMPORTANT SAFETY PRECAUTIONS

WARNING: To reduce the risk of burns, fire, electric shock or injury to persons, read the following important safety precautions and information before operating the treadmill.

1. Position the treadmill on a level surface, with at least 8 feet of clearance behind the treadmill. Do not place the treadmill on thick carpet, near water or outdoors. Do not operate where aerosol products are used or where oxygen is being administered.
2. Plug the power cord directly into a grounded circuit carrying 12 or more amps. No other appliance should be on the same circuit. (See the OPERATION AND ADJUSTMENT section of this manual for proper grounding instructions.) Keep the power cord away from heated surfaces. If an extension cord is required, use only a 14-gauge, general-purpose cord of approximately five feet in length with a three-wire conductor.
3. Never move the walking belt while the power is turned off. Do not operate the treadmill if the power cord or plug is damaged, or if the treadmill is not working properly. (Refer to the BEFORE YOU BEGIN section of this manual if the treadmill is not working properly.)
4. The roller guards must be 1/8 inch from the rear roller. Turn the power off and adjust the roller guards, if necessary.
5. Wear appropriate exercise attire when using the treadmill. Do not wear loose clothing that could become caught in the treadmill. *Always wear running shoes. Never use the treadmill with bare feet, wearing only stockings or in sandals.* Athletic support clothes are recommended for both men and women.
6. The pulse earclip is not a medical device. Various factors, including the user's movement while exercising, may affect the accuracy of heart rate readings. The earclip is intended only as an exercise aid in determining heart rate trends in general.
7. Never start the treadmill while you are standing on the walking belt. Always hold the handrail when exercising on the treadmill.
8. Never allow more than one person on the treadmill at a time. Use the treadmill only as described in this manual.
9. Keep small children away from the treadmill during operation. Never leave the treadmill unattended while it is running. Always turn the power off when the treadmill is not in use.
10. Never drop or insert any object into any opening.
11. Always unplug the power cord before performing the maintenance and adjustment procedures described in this manual. Never remove the motor hood unless instructed to do so by an authorized service representative. Servicing other than the procedures in this manual should be performed by an authorized service representative only.
12. This treadmill is capable of high speeds. Adjust the speed slowly to avoid sudden jumps in speed.

WARNING: Before beginning this or any exercise program, consult your physician. This is especially important for individuals over the age of 35 or persons with pre-existing health problems. Read all instructions before using. Pro Form assumes no responsibility for personal injury or property damage sustained by or through the use of this product.


SAVE THESE INSTRUCTIONS

BEFORE YOU BEGIN

Thank you for selecting the Pro Form 826 EXP treadmill. The 826 EXP combines state-of-the-art technology with innovative design to let you enjoy an excellent form of cardiovascular exercise in the convenience and privacy of your home. Your exercise on the 826 EXP will be enhanced by such features as a key-activated power switch, electronic speed and incline control and a programmable exercise computer.

For your safety and benefit, **read this manual carefully before using this equipment.** If you have additional questions, please call our Customer Service Department toll-free at **1-800-999-3756**, Monday through Friday, 6 a.m. until 6 p.m. Mountain Time (excluding holidays). In all communications regarding this product, please refer to your product model number and serial number. The model number is printed on the front cover of this manual. The serial number is recorded on a decal attached to the product (see the drawing on the front cover for the location).


Before reading further, please review the drawing below and familiarize yourself with the parts labeled.




ASSEMBLY

Set the treadmill in a cleared area and remove all packing materials. **Be sure that all parts are included before disposing of the packing materials.**


1. Insert the Lock Knob (33), with the Lock Knob Washer (32), into the Upright Post (9). Place the Upright Spacer (35) on the end of the Lock Knob. Hold the Spacer in place and raise the Upright Post to a vertical position. **Be careful not to pinch your fingers.** Turn the Knob clockwise until it is almost tight. Leave a little play in the Upright Post for the following steps.



2. Align the upper end of the Side Rail (1) with the left end of the Handrail (10). Turn the Handrail in the direction shown to thread the Handrail into the Side Rail. (Note: If the Handrail will not turn easily, loosen the Handrail Bolt [7] slightly.) Tighten the Handrail and the Handrail Bolt.



3. Align the lower end of the Side Rail (1) with the hole in the side of the treadmill Frame (56). Insert the Side Rail Bolt (82) through the Side Rail and Frame. Reach under the Frame and thread the Side Rail Nut (83) onto the end of the Bolt. Tighten the Lock Knob (see step 1).



Make sure that all parts are tightened securely before using the treadmill.


OPERATION AND ADJUSTMENT

GROUNDING INSTRUCTIONS

This product must be grounded. If it should malfunction or break down, grounding provides a path of least resistance for electric current to reduce the risk of electric shock. This product is equipped with a cord having an equipment-grounding conductor and a grounding plug. **The plug must be plugged into an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances.**

DANGER: Improper connection of the equipment-grounding conductor can result in a risk of electric shock. Check with a qualified electrician or serviceman if you are in doubt as to whether the product is properly grounded. Do not modify the plug provided with the product - if it will not fit the outlet, have a proper outlet installed by a qualified electrician.

This product is for use on a nominal 120-volt circuit, and has a grounding plug that looks like the plug illustrated in Drawing 1. A temporary adapter that looks like the adapter illustrated in Drawing 2 may be used to connect this plug to a 2-pole receptacle as shown in Drawing 2 if a properly grounded outlet is not available. The temporary adapter should be used only until a properly grounded outlet (Drawing 1) can be installed by a qualified electrician. The green colored rigid ear, lug, or the like extending from the adapter **must be** connected to a permanent ground such as a properly grounded outlet box cover. Whenever the adapter is used it **must be** held in place by a metal screw. **Some 2-pole receptacle outlet box covers are not grounded. Contact a qualified electrician to determine if the outlet box cover is grounded before using an adapter.**




MAINTENANCE-FREE WALKING PLATFORM

This treadmill features a walking platform with a specially designed hydrocarbon slip agent. **Do not apply silicone spray or any other substance to the walking platform or the walking belt.** Such substances will deteriorate the surface of the platform and cause excessive wear.

DIAGRAM OF THE TREADMILL CONSOLE

Please read all instructions carefully before operating the console. Refer to the diagram below and the treadmill console for clarification.



TURNING THE POWER ON

Stand on the foot rails of the treadmill. **CAUTION: Do not stand on the walking belt when turning the power on.**

There is a clip attached by a cord to the safety key. Slide the clip onto the waistband of your clothing. **CAUTION: Always wear the clip when operating the treadmill. If you fall while wearing the clip, the safety key will be pulled from the console, instantly turning the power off.**

Insert the safety key into the power switch. **IMPORTANT:** When the safety key is first inserted after the power cord is plugged in, the treadmill will perform an automatic incline test, rising to maximum incline, and then returning to minimum.

MANUAL TREADMILL OPERATION

When the power is turned on, the console will be in the manual mode. The walking belt will be stationary, and the incline of the treadmill will be 1.5%.

The console can display speed using two different units of measurement: miles per hour and minutes per mile. Select the unit desired by pressing the MILES PER HOUR or MINUTES PER MILE buttons beneath the MANUAL SPEED ADJUST display. Note: If you select MINUTES PER MILE, the speed of the walking belt must be at least 2.0 miles per hour to be displayed.

The speed of the walking belt can be controlled using the "+" and "-" buttons beside the MANUAL SPEED ADJUST display. Each time one of the buttons is pressed, the speed will increase or decrease by 0.1 mile per hour. The buttons can be held down to change the speed quickly. Press the "+" button until the walking belt begins to move at slow speed. Hold the handrail and step carefully onto the walking belt. As you exercise, the speed of the walking belt can be changed as desired by pressing the buttons. To stop the walking belt, hold down the "-" button. The walking belt can be stopped quickly, if necessary, by pressing the STOP button. **CAUTION: After the "+" or "-" buttons are pressed, it will take a few seconds for the walking belt to reach the selected speed setting. Adjust the speed gradually until you are familiar with the operation of the treadmill. As the "+" or "-" buttons are pressed, the display will show the selected speed setting. The display will then change to show the actual speed of the walking belt, until the belt reaches the selected speed setting.**

To vary the intensity of your exercise, the incline of the treadmill can be changed, from 1.5% to 10%. Press the "+" or "-" buttons beside the MANUAL INCLINE ADJUST display to change the incline. Each time one of the buttons is pressed, the incline will increase or decrease by 0.5%. The buttons can be held down to change the incline quickly.

PROGRAMMABLE TREADMILL OPERATION

In the programmable mode, the console will automatically control either the speed or the incline of the treadmill according to programs you select. Four different preset programs are offered. In addition, you can easily create an endless number of your own "user" programs. Up to four user programs can be stored simultaneously in the console's memory for future workouts.

CREATING A USER PROGRAM

Press one of the four USER buttons. Be sure that the walking belt is fully stopped before you continue.

Select whether you want the console to control the speed or the incline of the treadmill, by pressing the PROGRAM SPEED or PROGRAM INCLINE buttons.

If you selected speed, a speed range should be set for the program. Press the MAXIMUM SPEED (SET) button beneath the TIME/MAX SPEED SET display. The minimum speed the walking belt can move during a program is 1.5 miles per hour. The maximum speed the walking belt can move is preset at 3 miles per hour, as shown in the display. The maximum speed setting can be changed, if desired, by pressing the "+" or "-" buttons beneath the display. Each time one of the buttons is pressed, the setting will change by 0.1 mile per hour. The buttons can be held down to change the setting quickly. The maximum speed setting can be from 2 to 8 miles per hour.

If you selected incline, a speed range does not need to be set. Instead, press the "+" button beside the MANUAL SPEED ADJUST display until the display shows 2 miles per hour, or 30 minutes.

All programs are divided into eight equal time periods, called "segments." The speed or incline of the treadmill will change automatically at the beginning of each segment. The speed or incline settings should be programmed on the eight segments of the PROGRAM SEGMENTS display. The setting of each segment is shown by the number of bars lighted in the segment. If only one bar is lighted, the segment is set for 1.5 miles per hour, or 1.5% incline. If all eight bars are lighted, the segment is set for the maximum speed, or 10% incline. If a program has not previously been created, the same number of bars will be lighted in all segments.

The first segment of the PROGRAM SEGMENTS display will be flashing. To program the first segment, press the "+" or "-" buttons beneath the display until the desired number of bars is lighted. Each time the "+" button is pressed, a tone will sound and the setting will increase. Every few times the button is pressed, an additional bar will light. Each time the "-" button is pressed, a tone will sound and the setting will decrease. Every few times the button is pressed, a bar will darken. The buttons can be held down to program the segment quickly. After the first segment is programmed, press the segment right button beneath the display. The first segment will stop flashing, and the second segment will begin to flash. Program the second segment in the same manner as the first segment. (Segments can be programmed only when they are flashing.) Continue in this manner until all eight segments have been programmed. You may wish to program the first segment at a low setting to warm up, the middle segments at higher settings, and the final segment at a low setting to cool down. The segments can be programmed in an endless variety of "profiles" can be created.

The final step in creating a program is to set the length of time you want each program segment to last. (All program segments will last for the same length of time.) Press the SEGMENT TIME (SET) button beneath the TIME/MAX SPEED SET display. Each segment is preset to last for 150 seconds (2.5 minutes), as shown in the display. Since there are eight segments, the program will last for a total of 20 minutes. If you wish to change the length of time each segment will last, press the "+" or "-" buttons beneath the TIME/MAX SPEED SET display. Each time one of the buttons is pressed, the length of time displayed will change by 1.0 second. The buttons can be held down to change the length of time quickly.

When you are ready to start the program, press the START button. The first segment of the PROGRAM SEGMENTS display will begin to flash, and the speed or incline of the treadmill will automatically adjust to the setting of the first segment. Step carefully onto the walking belt and begin your workout. The time remaining in the first segment will be shown in the TIME/MAX SPEED SET display. When the time reaches zero, the second segment will begin to flash, and the speed or incline of the treadmill will adjust to the setting of the second segment. The program will continue in this manner until all eight segments have been completed. (If the console is controlling the speed of the treadmill, the incline can be controlled using the "+" and "-" buttons beside the MANUAL INCLINE ADJUST display. If the console is controlling the incline, the speed can be controlled using the "+" and "-" buttons beside the MANUAL SPEED ADJUST display. See MANUAL TREADMILL OPERATION above.) Note: The program settings can be changed while the program is running. **If you wish to stop the program before the program has ended, press the STOP button.** The console will then be in the same state as if the program had ended.

After the program has ended, a different program can be selected or the console can be switched to the manual mode by pressing the MANUAL button. The current program settings will be saved in the console's memory. (Speed or incline settings made using the manual buttons will not be saved.) The program settings will be saved as long as the power cord remains plugged in. If the power cord is unplugged, only the preset program settings will be saved.

SELECTING A PRESET PROGRAM

Press the RANDOM, INTERVAL or MOUNTAIN buttons. (The FITNESS TEST program will be explained later.) Be sure that the walking belt is fully stopped before you continue.

Select whether you want the console to control the speed or the incline of the treadmill, by pressing the PROGRAM SPEED or PROGRAM INCLINE buttons.

If you selected speed, a speed range should be set for the program. This should be done in the same manner as for a user program.

If you selected incline, a speed range does not need to be set. Instead, press the "+" button beside the MANUAL SPEED ADJUST display until the display shows 2 miles per hour, or 30 minutes.

The eight speed or incline settings of the selected program will be shown on the PROGRAM SEGMENTS display. If desired, the setting of any segment can be changed. Press the segment right or left buttons beneath the display until the segment you want to change begins to flash. Press the "+" or "-" buttons beneath the display to change the setting of the segment.

Next, set the length of time you want each program segment to last. This should be done in the same manner as for a user program.

When you are ready to start the program, press the START button. The program will run in exactly the same manner as a user program. After the program has ended, a different program can be selected or the console can be switched to the manual mode by pressing the MANUAL button. Although the settings of a preset program can be changed, any changes made to the settings of the segments will not be saved in the console's memory.

SELECTING THE FITNESS TEST PROGRAM

Press the FITNESS TEST button. When the FITNESS TEST program is selected, **the console will control both the speed and the incline of the treadmill.** The settings of this program are preset, and cannot be changed. The settings shown on the PROGRAM SEGMENTS display are both the speed and incline settings.

Press the WEIGHT SET button beneath the PULSE/CALORIES/FITNESS LEVEL SET display. Press the "+" or "-" buttons in the display to enter your weight, in pounds. Each time one of the buttons is pressed, the weight displayed will change by 1.0 pound. The buttons can be held down to enter your weight quickly.

Next, press the FITNESS LEVEL button. The display will show a zero until the program has started.

When you are ready to start the program, press the START button. When the walking belt begins to move, step carefully onto the walking belt and begin your workout. As you exercise, the speed and incline of the treadmill will gradually increase. When you are exercising as hard as you can **without discomfort**, press the STOP button. Your fitness level will be displayed in the PULSE/CALORIES/FITNESS LEVEL SET display.

EXERCISE MONITOR OPERATION

The console features an electronic exercise monitor, designed to provide you with instant feedback on your performance as you exercise. You can choose from nine different modes, and change modes at any time. Indicators on the mode buttons will show which modes are currently displayed. Modes can be selected in the following manner:

TIME: Press the TIME button beneath the TIME/DISTANCE SET display. As you exercise, the elapsed time will be displayed.

TIME GOAL: Press the TIME button beneath the TIME/DISTANCE SET display. Next, press the "+" button beside the display to set the length of time you plan to exercise. Each time the button is pressed, the time displayed will change by 10 seconds. The button can be held down to set the length of time quickly. As you exercise, the time will be counted down. When no time remains, a tone will sound. Note: The TIME and TIME GOAL modes cannot be selected at the same time. Set time goals only when the console is in the manual mode. When the console is in the programmable mode, a time goal will be set automatically.

DISTANCE: Press the DISTANCE button beneath the TIME/DISTANCE SET display. As you exercise, the distance you have traveled will be displayed.

DISTANCE GOAL: Press the DISTANCE button beneath the TIME/DISTANCE SET display. Next, press the "+" button beside the display to set the distance you plan to travel during your workout. Each time the button is pressed, the distance displayed will change by 0.1 mile. The button can be held down to set the distance quickly. As you exercise, the distance will be counted down. When the goal is completed, a tone will sound. Note: The DISTANCE and DISTANCE GOAL modes cannot be selected at the same time.

TIME/DISTANCE SCAN: Press the SCAN button beneath the TIME/DISTANCE SET display. As you exercise, the TIME (or TIME GOAL) and DISTANCE (or DISTANCE GOAL) modes will both be displayed in a repeating cycle.

PULSE: Press the PULSE button beneath the PULSE/CALORIES/FITNESS LEVEL SET display. Plug the pulse earclip into the jack on the left side of the console, and attach the earclip to your left ear lobe. Slide the clothes clip onto your collar to prevent excessive movement of the earclip wire. When your pulse is detected, the pulse indicator beside the display will flash on and off. After a few seconds, your heart rate will be displayed. Note: If your heart rate is not displayed, try rubbing your ear lobe and repositioning the earclip. It may be helpful to stop exercising briefly while you measure your pulse.

PULSE GOAL: Press the PULSE button beneath the PULSE/CALORIES/FITNESS LEVEL SET display. Press the "+" and "-" buttons beside the display to set the highest level you want your heart rate to reach during your workout. (See **CONDITIONING GUIDELINES** in this manual.) The heart rate can be set from 60 to 220 beats per minute. Each time one of the buttons is pressed, the heart rate displayed will change by 1 beat per minute. The buttons can be held down to set the heart rate quickly. The pulse earclip must be plugged into the jack on the left side of the console, and attached to your left ear lobe. The clothes clip should be attached to your collar to prevent excessive movement of the earclip wire. When your pulse is detected, the pulse indicator beside the display will flash on and off. After a few seconds, your heart rate will be displayed. If your heart rate rises above the heart rate level you set as you exercise, a warning tone will sound until your heart rate subsides. Note: If your heart rate is not displayed, try rubbing your ear lobe and repositioning the earclip.

CALORIES: For your Calorie expenditure to be measured accurately, your weight should be entered into the console. Press the WEIGHT SET button beneath the PULSE/CALORIES/FITNESS LEVEL SET display. Press the "+" or "-" buttons beside the display to enter your weight, in pounds. Each time

one of the buttons is pressed, the weight displayed will change by 1.0 pound. The buttons can be held down to enter your weight quickly. Next, press the CALORIES button beneath the display. As you exercise, the number of Calories you have expended will be displayed.

PULSE/CALORIES SCAN: Press the SCAN button beneath the PULSE/CALORIES/FITNESS LEVEL SET display. As you exercise, the PULSE (or PULSE GOAL) and CALORIES modes will both be displayed in a repeating cycle.

TURNING THE POWER OFF

Stand on the foot rails of the treadmill. Remove the safety key from the console. Always remove the safety key when you finish your workout. The key can be stored in a secure location to prevent unauthorized persons from turning the power on.

MAINTENANCE AND TROUBLE-SHOOTING

Check all parts periodically to ensure that they are tightened securely. Outside surfaces of the treadmill can be cleaned using a damp cloth and mild, non-abrasive detergent. Do not allow liquids to come in contact with the console.


WALKING BELT ADJUSTMENT

The walking belt should always be kept centered on the walking platform. If the belt shifts to the right or left sides of the platform, the belt may be damaged by the roller guard screws. The belt can be adjusted using the rear roller adjustment bolts and the allen wrench included. **CAUTION: ALWAYS TURN THE POWER OFF BEFORE ADJUSTING THE WALKING BELT.**

IF THE WALKING BELT HAS SHIFTED TO THE LEFT: TURN THE POWER OFF. Turn the left adjustment bolt clockwise, and the right adjustment bolt counterclockwise, 1/4 of a turn each. Turn the power on. Repeat as necessary until the belt is centered.

IF THE WALKING BELT HAS SHIFTED TO THE RIGHT: TURN THE POWER OFF. Turn the left adjustment bolt counterclockwise, and the right adjustment bolt clockwise, 1/4 of a turn each. Turn the power on. Repeat as necessary until the belt is centered.

IF THE WALKING BELT SLIPS DURING USE: TURN THE POWER OFF. Turn both adjustment bolts clockwise 1/4 of a turn. Turn the power on. Repeat as necessary until the belt does not slip. Be careful not to overtighten the bolts. Overtightening can stretch the belt, cause excessive roller noise, and reduce motor performance.



To check the walking belt for proper tension, **TURN THE POWER OFF**, and lift the edges of the walking belt. You should be able to lift each edge 3-4 inches off the walking platform. The center of the belt should remain just at the surface of the platform.

The allen wrench can be stored conveniently on the self-adhesive wrench clip.

ROLLER GUARD ADJUSTMENT

The rear edge of the roller guards should be 1/8 inch from touching the rear roller. To adjust the roller guards, loosen the screws in the roller guards, slide the roller guards forward or backward, and retighten the screws.

CIRCUIT BREAKER

If the treadmill stops or will not start, check the circuit breaker located on the front of the frame near the power cord. The circuit breaker is designed to protect the electrical system. If the circuit breaker has tripped, the switch will protrude as shown. To reset the circuit breaker, allow the treadmill to cool for a few minutes and then push the switch back in.

CONSOLE ERRORS


If a console malfunction occurs, an error code may appear on the console. Four backward E's on the MANUAL SPEED ADJUST display indicate a speed sensor error. Two backward E's or a PO on the MANUAL INCLINE ADJUST display indicate an incline sensor error or a power error. If an error code appears, try removing and then reinserting the safety key to solve the problem. If the error code appears again, call our Customer Service Department, toll-free, at 1-800-999-3756, Monday through Friday, 6 a.m. until 6 p.m. Mountain Time. Do not operate the treadmill until the problem is corrected.

PULSE EARCLIP

If the pulse earclip does not function properly, the earclip should be cleaned. Press the earclip open, and wipe the small, clear circles inside using a cotton swab saturated with denatured alcohol.

STORAGE

Unplug the power cord. Remove the bolt and nut from the lower end of the side rail, and disconnect the side rail. Loosen the lock knob, and lay the upright post on the walking belt.



CONDITIONING GUIDELINES

The following guidelines will help you to outline a personal fitness program. Remember that adequate rest and good nutrition are essential to the success of any fitness program. **Before beginning this or any exercise program, consult your physician.**

EXERCISE INTENSITY

To maximize the benefits of exercising, it is important to exercise with the proper intensity. The proper intensity level can be found using the heart rate as a guide. For effective aerobic exercise, your heart rate should be maintained at a level between 70% and 85% of your maximum heart rate as you exercise. This is called your "training zone." You can find your training zone by consulting the table below. Training zones are listed for both conditioned and unconditioned persons, according to age. Find the column that is appropriate for you.

AGE	UNCONDITIONED TRAINING ZONE (BEATS/MIN)	CONDITIONED TRAINING ZONE (BEATS/MIN)	AGE	UNCONDITIONED TRAINING ZONE (BEATS/MIN)	CONDITIONED TRAINING ZONE (BEATS/MIN)
20	138-167	133-162	55	127-155	122-149
25	136-166	132-160	60	126-153	121-147
30	135-164	130-158	65	125-151	119-145
35	134-162	129-156	70	123-150	118-144
40	132-161	127-155	75	122-147	117-142
45	131-159	125-153	80	120-146	115-140
50	129-156	124-150	85	118-144	114-139

During the first few weeks of your exercise program, keep your heart rate near the low end of your training zone. Over the course of a few months, gradually increase your heart rate until it is near the high end of your training zone. You can find your heart rate using the pulse mode of the console. Exercise for at least four minutes, and then measure your heart rate immediately. If your heart rate is above your training zone, decrease the intensity of your exercise. If your heart rate is too low, increase the intensity.

WORKOUT GUIDELINES

Each workout should consist of three basic parts: a warm-up, 20-30 minutes of training zone exercise, and a cool-down. Warming up prepares the body for strenuous exercise by increasing circulation, delivering more oxygen to the muscles and raising the body temperature. 5-10 minutes of stretching or light calisthenics will provide a good warm-up. After warming up, begin exercising at a light pace. After a few minutes, increase the intensity of your exercise to raise your heart rate to your training zone for 20-30 minutes. Always end your workouts with 5-10 minutes of stretching to cool down. This will help to offset muscle contractions and other problems caused when you stop exercising suddenly.

To maintain or improve your condition, you must work out 2-3 times per week following the pattern described above. A day of rest between workouts is recommended. After several months of exercise, the number of workouts can be increased to 4-5 per week. The key to success is **CONSISTENCY**.

PART LIST- Model No. PF826010

Rev.12/91

Key No.	Qty.	Description	Key No.	Qty.	Description
1	1	Side Rail	46	2	Swivel Shaft Bolt
2	1	Console	47	1	Speed Encoder
3	15	Screw	48	3	Adjustment Washer
4	1	Clothes Clip	49	1	Front Roller Adjustment Bolt
5	1	Pulse Earclip	50	4	Hood Mount Anchor
6	1	Safety Key/Clip	51	1	Safety Cover
7	1	Handrail Bolt	52	1	Front Roller/Pulley
8	2	Flat Washer	53	1	Walking Belt
9	1	Upright Post	54	1	Walking Platform
10	1	Handrail	55	2	High Density Foam
11	15	Small Screw	56	1	Frame
12	4	Plastic Stand-off	57	1	Right Foot Rail
13	1	Power Supply Bracket	58	1	Controller Bracket
14	1	Power Supply	59	1	Controller
15	1	Incline Motor	60	1	Incline Ladder
16	1	Cotter Pin	61	1	Ladder Pin
17	1	Lower Incline Pin	62	1	Incline Switch Bracket
18	2	E-Clip	63	2	Small Bolt
19	1	Upper Incline Pin	64	2	Incline Switch
20	4	Motor Mount Washer	65	2	Small Nut
21	5	Motor Mount Nut	66	1	Speed Switch Bracket
22	1	Motor	67	2	Rear Leg Endcap
23	1	Pulley/Flywheel/Fan	68	4	Endcap/Guard Screw
24	4	Motor Mount Bolt	69	6	Platform Screw
25	1	Motor Mount Swivel Shaft	70	6	Platform Clamp
26	1	J-Bolt	71	6	Platform Clamp Bushing
27	1	Tension Washer	72	6	Small Bushing
28	1	Tension Spring	73	1	Right Endcap
29	2	Rear Roller Spacer	74	1	Allen Wrench
30	3	Locknut	75	1	Wrench Clip
31	1	Wire Harness	76	2	Rear Roller Adjustment Bolt
32	1	Lock Knob Washer	77	1	Rear Roller
33	1	Lock Knob	78	2	Roller Guard
34	1	Pivot Bolt	79	1	Left Endcap
35	1	Upright Spacer	80	1	Left Foot Rail
36	2	Ground Washer	81	1	Motor Hood/Decal
37	1	Grommet	82	1	Side Rail Bolt
38	1	Power Cord	83	1	Side Rail Nut
39	1	Circuit Breaker	84	6	Hood Screw
40	12	Plastic Fastener	85	1	Front Roller Insert
41	2	Front Wheel	86	1	Belt
42	2	Wheel Bolt	87	1	Interface Board
43	1	Incline Leg	88	1	Interface Bracket
44	2	Incline Leg Bolt	#	1	Owner's Manual
45	2	U-Nut			

Note: "#" indicates a non-illustrated part. Specifications are subject to change without notice. See the back cover for information about ordering replacements parts.

ORDERING REPLACEMENT PARTS

Replacement parts can be ordered conveniently by calling our Customer Service Department toll-free at 1-800-999-3756, during our business hours: Monday - Friday, 6 a.m. - 6 p.m. Mountain Time. When ordering parts, please be prepared to give the following information:

1. The MODEL NUMBER of the product (PF826010).
2. The NAME of the product (Pro Form 826 EXP treadmill).
3. The SERIAL NUMBER of the product (see the front cover of this manual).
4. The KEY NUMBER of the part(s) from page 14 of this manual.
5. The DESCRIPTION of the part(s) from page 14 of this manual.

If possible, place the treadmill near your telephone for easy reference when calling.

116878
motor mount
bks.
~~116878~~