


# WESLO® ★ cardioWALK™

Model No. QVTL15050

Serial No. \_\_\_\_\_

Serial Number Decal



## QUESTIONS?

As a manufacturer, we are committed to providing complete customer satisfaction. If you have questions, or find that there are missing or damaged parts, we will guarantee you complete satisfaction through direct assistance from our factory.

TO AVOID UNNECESSARY DELAYS, PLEASE CALL DIRECT TO OUR TOLL-FREE CUSTOMER HOT LINE. The trained technicians on our customer hot line will provide immediate assistance, free of charge to you.

CUSTOMER HOT LINE:

**1-800-999-3756**


Mon.-Fri., 6 a.m.-6 p.m. MST

## ⚠ CAUTION!

Read all precautions and instructions in this manual before using this equipment. Save this manual for future reference.

US PATENT 5,102,380

US PATENT 5,282,776



## USER'S MANUAL

# TABLE OF CONTENTS

|                            |            |
|----------------------------|------------|
| IMPORTANT PRECAUTIONS      | 2          |
| BEFORE YOU BEGIN           | 3          |
| ASSEMBLY                   | 4          |
| TREADMILL OPERATION        | 5          |
| TROUBLE-SHOOTING           | 7          |
| CONDITIONING GUIDELINES    | 9          |
| PART LIST                  | 10         |
| EXPLODED DRAWING           | 11         |
| ORDERING REPLACEMENT PARTS | Back Cover |
| LIMITED WARRANTY           | Back Cover |



## IMPORTANT PRECAUTIONS

**⚠ WARNING:** To reduce the risk of serious injury, read the following Important precautions before using the CARDIO WALK.

1. It is the responsibility of the owner to ensure that all users of this treadmill are adequately informed of all warnings and precautions.
2. Place the CARDIO WALK on a level surface, with at least 8 feet of clearance behind it. To protect the floor or carpet from damage, place a mat under the CARDIO WALK.
3. Keep small children and pets away from the CARDIO WALK at all times.
4. The CARDIO WALK should be used only by persons weighing 250 pounds or less. Never allow more than one person on the CARDIO WALK at a time.
5. Wear appropriate clothing when exercising. Never wear loose clothing that could become caught in the CARDIO WALK. *Always wear athletic shoes; never use the CARDIO WALK with bare feet, wearing only stockings, or in sandals.* Athletic support clothes are recommended for both men and women.
6. Inspect and tighten all parts regularly. Replace any worn parts immediately.
7. Do not use the CARDIO WALK if it is not working properly.
8. Do not place hands or feet under the CARDIO WALK while it is in use.
9. Always hold the upper body arms when exercising on the CARDIO WALK.
10. If you feel pain or dizziness at any time while exercising, stop immediately and begin cooling down.
11. Use the CARDIO WALK only as described in this manual.

## SAVE THESE INSTRUCTIONS

**⚠ WARNING:** Before beginning this or any exercise program, consult your physician. This is especially important for persons over the age of 35 or persons with pre-existing health problems. Read all instructions before using this product. ICON assumes no responsibility for personal injury or property damage sustained by or through the use of this product.


## BEFORE YOU BEGIN

Thank you for selecting the WESLO® CARDIO WALK Dual Motion Manual Treadmill. The natural motion and versatility of treadmills have made them the most popular way to get an effective cardiovascular workout. With the dual motion design of the CARDIO WALK, you can get both an upper- and lower-body workout as well.

To help you stay motivated as you exercise, the CARDIO WALK features an electronic console that provides continuous feedback of speed, elapsed time, total distance, and the approximate number of Calories you have burned. And the adjustability of the CARDIO WALK allows you to work at your own level, whether you are just beginning or already exercise regularly.

For your benefit, read this manual carefully before using the CARDIO WALK. If you have additional questions, please call our Customer Service Department toll-free at 1-800-999-3756, Monday through Friday, 6 a.m. until 6 p.m. Mountain Time (excluding holidays). To help us assist you, please note the product model number and serial number before calling. The model number is QVTL15050. The serial number can be found on a decal attached to the CARDIO WALK (see the front cover of this manual to find the location of the decal).


Before reading further, please review the drawing below and familiarize yourself with the parts that are labeled.



# ASSEMBLY


Set the CARDIO WALK in a cleared area and remove all packing materials. Do not dispose of the packing materials until assembly is completed. **Assembly requires the included allen wrench**

1. Raise the Upright (10) to the vertical position. Slide the Upright Flat Washer (25) onto the Upright Bolt (24). Tighten the Upright Bolt into the Upright with the Allen Wrench (53).




2. Insert an Incline Leg (9) into one of the adjustment posts on the Frame (37). Align one of the holes in the Incline Leg with the hole in the adjustment post. Insert an Incline Pin (26) through the adjustment post and the Incline Leg.


Assemble the other Incline Leg (9) in the same manner. Make sure that both Incline Legs are at the same height.



3. Attach the Abdominal Pad Bracket (72) to the Upright (10) with the Pad Knob (52) and Washer (61). (The three holes in the Upright are for height adjustment. Select the height that is the most comfortable.) Be sure that the Abdominal Pad (33) is oriented as shown.



4. Remove the paper backing from the Wrench Clip (50). Attach the Wrench Clip to the underside of the Frame (37) as shown. Slide the Allen Wrench (53) into the Wrench Clip.



Because there are moving parts on the underside of the treadmill, it is recommended that you cover the floor beneath the treadmill. The walking platform is pre-lubricated with **PERFORMANT LUBE™** high performance lubricant. During the first few hours of use, it is normal for a white powder to collect on the floor under the treadmill and on the sides of the walking belt. This powder is excess lubricant.

# TREADMILL OPERATION

## CONSOLE MODES

The console features a selection of modes designed to provide you with continuous exercise feedback. The five modes are described below:

**SPEED**—Displays your current speed, in miles per hour.


**TIME**—Displays the elapsed time. Note: If the walking belt stops for ten seconds or longer, the TIME mode will pause until you resume walking.

**DISTANCE**—Displays the total distance that you have walked, in miles.

**CALORIE**—Displays the total number of nutritional calories you have burned. Note: The number displayed is an approximate figure. The actual number may vary slightly depending on the incline of the treadmill and the resistance settings.

**SCAN**—Displays all of the above modes, for five seconds each, in a repeating cycle.

### CONSOLE DIAGRAM



- A. LCD display.
- B. Mode indicators—Show which mode is currently selected.
- C. Mode button—Selects modes.
- D. On/off button—Turns the power on and off.

## OPERATING THE CONSOLE

1. If there is a thin piece of clear plastic on the console, remove it before operating the console. To turn on the power, press the on/off button or

simply begin walking. The entire display will appear for two seconds; the console will then be ready for operation.

2. Select one of the five modes:

**SCAN mode**—When the power is turned on, the SCAN mode will be selected automatically. One mode indicator will show that the SCAN mode has been selected, and a second mode indicator will show which mode is currently displayed. The SCAN mode can also be selected by repeatedly pressing the mode button.

**SPEED, TIME, DISTANCE or CALORIE mode**—These modes can be selected by repeatedly pressing the mode button. A mode indicator will show which mode has been selected. The modes are selected in the following order: SPEED, TIME, DISTANCE, CALORIE, and SCAN.

3. To reset the modes, turn the power off and then on again by pressing the on/off button twice.
4. To turn off the power, press the on/off button. Note: If the walking belt is not moved and the console buttons are not pressed for four minutes, the power will turn off automatically in order to conserve the batteries.

## HOW TO WALK ON THE TREADMILL


Stand on the walking belt, hold the upper body arms, and lean on the abdominal pad. (See HOW TO USE THE UPPER BODY ARMS on page 6). Slowly begin walking on the treadmill. Use the upper body arms for balance and lean on the abdominal pad to “push off” when you begin walking. **Always hold the upper body arms when getting on and off the treadmill, and when exercising on the treadmill.**

Because the CARDIO WALK is a manual treadmill, you can set your own exercise pace. There are three ways that you can change the intensity of your workout:

- You can change the resistance on the walking belt. (See HOW TO USE THE SPEED CONTROL on page 6.)
- You can increase the resistance of the upper body arms. (See HOW TO USE THE UPPER BODY ARMS on page 6.)
- You can increase the incline of the treadmill. (See HOW TO CHANGE THE INCLINE on page 6.)

## HOW TO USE THE SPEED CONTROL


As you exercise on the **CARDIO WALK**, the resistance on the walking belt can be changed by turning the Speed Control (57) on the Console (7). As the



Speed Control is turned clockwise, the resistance on the walking belt will increase and your walking speed will decrease. As the Speed Control is turned counterclockwise, the resistance will decrease and the walking belt will move more freely.

Adjusting the resistance from the minimum setting to the maximum setting requires several rotations of the speed control. **Stop turning the speed control when rotation becomes difficult, or the speed control may be damaged.**

## HOW TO USE THE UPPER BODY ARMS



The Upper Body Arms (1, 2) can be used in either the stationary position or the dual motion position. To use the Upper Body Arms in the stationary position, insert the Lock Pin (11) through the Upper Body Arms and the Upright (10). **Important: If it is difficult to insert the Lock Pin, do not hit the end of the Lock Pin; twist the Upper Body Arms slightly in order to align the holes. Do not twist the Upper Body Arms too far or the treadmill may be damaged.** Insert the Hairpin Cotter (3) into the end of the Lock Pin. Tighten the Arm Resistance Control (15).


**CAUTION:** Always secure the Lock Pin (11) with the Hairpin Cotter (3). If the Hairpin Cotter is not attached as instructed, the Lock Pin may slip out, resulting in injury to the user.

To use the Upper Body Arms (1, 2) in the dual motion position, first make sure that the Arm Resistance Control (15) is tightened (see the drawing above).

Remove the Lock Pin (11) from the Upper Body Arms (1, 2) and the Upright (10). In the dual motion position, you can move the Upper Body Arms forward and back as you walk, exercising your arms, back and shoulders for a total body workout. To tailor the intensity of your exercise, the resistance of the Upper Body Arms can be changed. To increase the resistance, turn the Arm Resistance Control (15) clockwise; to decrease the resistance, turn the Arm Resistance Control counterclockwise.

## HOW TO CHANGE THE INCLINE


To change the incline, first lift the front of the treadmill slightly and remove the Incline Pin (26) from one Incline Leg (9) (see the drawing below).



Position the Incline Leg (9) at the desired height, align one of the holes in the Incline Leg with the hole in the adjustment post, and insert the Incline Pin (26) through the adjustment post and the Incline Leg. Adjust the other Incline Leg in the same manner. **Make sure that the Incline Pins are fully inserted and that both Incline Legs are at the same height.**

## HOW TO ADJUST THE ABDOMINAL PAD


For your comfort, the height of the Abdominal Pad (33) can be adjusted (see the drawing below). There are three height settings. To change the height setting, first remove the Pad Knob (52) and Washer (61). Align the hole in the Abdominal Pad Extension (72) with the desired hole in the Upright (10). Secure the Abdominal Pad Bracket with the Pad Knob and Washer.





## BATTERY REPLACEMENT


The Console (7) requires two "LR44" watch batteries. To replace the batteries, first remove three of the screws that attach the Console to the Upright (10). Loosen the fourth screw. Pivot the Console until the batteries are visible (see the drawing below).



Using a small screwdriver, push the batteries out of the Console (7). Be sure to note which way the batteries were turned. Insert two new batteries. Re-attach the Console to the Upright (10).

## HOW TO STORE THE TREADMILL

To convert the treadmill to the storage position, first turn the Arm Resistance Control (15) counter-clockwise until it turns freely (see the drawing below). Failure to do so will result in damage to the treadmill.



Next, remove the Upright Bolt (24) and Upright Flat Washer (25) from the Upright (10). Lay the Upright and the Upper Body Arms (1, 2) on the Walking Belt (45). Be careful not to pinch the sensor wire in the Upright. Replace the Upright Bolt and Upright Flat Washer for storage.


## TROUBLE-SHOOTING

Most problems can be solved by following the simple steps below. Find the symptom that applies, and follow the steps listed. If further assistance is needed, call our Customer Service Department toll-free at 1-800-999-3756, Monday through Friday, 6 a.m. until 6 p.m. Mountain Time (excluding holidays).

### 1. SYMPTOM: THE CONSOLE DOES NOT FUNCTION PROPERLY


- Replace the batteries. (See BATTERY REPLACEMENT at the top of this page.)
- The console, like most electronics, is susceptible to static electricity build-up, caused by certain types of clothing or machine operation. If the console blanks out or gives false readings, an anti-static spray should be applied to the upper body arms and the upright, especially the base of the upright. Anti-static spray is available where laundry supplies are sold.
- Carefully tip the treadmill on its left side. Refer to the drawing at the right and locate the Reed Switch (29). Turn the Front Roller (27) until the Magnet (51) is aligned with the Reed Switch.

Loosen the Screw (5). Adjust the Reed Switch so that there is a 1/8" gap between the Reed Switch and the Magnet. Retighten the Screw.



## 2. SYMPTOM: THE WALKING BELT DOES NOT MOVE SMOOTHLY


- a. If the Walking Belt (45) is overtightened, performance may be reduced and the Walking Belt may be permanently damaged. Turn the speed control fully counterclockwise. Using the included



allen wrench, turn both Rear Roller Adjustment Bolts (42) counterclockwise 1/4 of a turn. When the tension of the Walking Belt is correct, you should be able to lift each side of the walking belt 2 to 3 inches; the center of the Walking Belt should just touch the surface of the walking platform. Walk on the treadmill for a few minutes. Repeat until the Walking Belt is properly tightened. Be careful to keep the Walking Belt centered.

## 3. SYMPTOM: THE WALKING BELT SLIPS OR IS OFF-CENTER


- a. If the Walking Belt (45) slips when walked on, use the allen wrench to turn both Rear Roller Adjustment



Bolts (42) clockwise, 1/4 of a turn. When the


Walking Belt is correctly tightened, you should be able to lift each side of the Walking Belt 2 to 3 inches off the walking platform. The center of the Walking Belt should just touch the walking platform. Walk on the treadmill for a few minutes. Repeat until the Walking Belt is properly tightened. Be careful to keep the Walking Belt centered.

- b. If the Walking Belt (45) has shifted to the left side, use the allen wrench to turn the left Rear



Roller Adjustment Bolt (42) clockwise, and the right Bolt counterclockwise, 1/4 of a turn each. Be careful not to overtighten the Walking Belt. Walk on the treadmill for a few minutes. Repeat until the Walking Belt is centered.

- c. If the Walking Belt (45) has shifted to the right side, use the allen wrench to turn the left Rear Roller




Adjustment Bolt (42) counterclockwise, and the right Bolt clockwise, 1/4 of a turn each. Be careful not to overtighten the Walking Belt. Walk on the treadmill for a few minutes. Repeat until the Walking Belt is centered.

## 4. SYMPTOM: THE RESISTANCE ON THE WALKING BELT DOES NOT INCREASE WHEN THE SPEED KNOB IS TURNED

- a. If the resistance on the walking belt does not increase when the speed knob is turned clockwise, the resistance belt should be tightened.

To tighten the resistance belt, first turn the speed control counterclockwise as far as it will turn.



Next, remove the four screws attaching the Hood (14). Remove the Hood and locate the Resistance Belt (67) and the Resistance Clamp (60). Open the Resistance Clamp, pull the Resistance Belt slightly tighter, and firmly close the Resistance Clamp. Reattach the Hood.



# CONDITIONING GUIDELINES

The following guidelines will help you to plan your exercise program. Remember that proper nutrition and adequate rest are essential for successful results.

**⚠ WARNING:** Before beginning this or any exercise program, consult your physician. This is especially important for individuals over the age of 35 or individuals with pre-existing health problems.

## WHY EXERCISE?

Exercise has proven essential for good health and general well-being. Regular participation in a well-rounded exercise program also results in a stronger and more efficient heart, improved respiratory function, increased stamina and endurance, better weight management and body fat control, increased ability to deal with stress, and greater self-esteem and confidence.


## EXERCISE INTENSITY

To maximize the benefits of exercising, it is important to exercise with the proper intensity. The proper intensity level can be found by using your heart rate as a guide. For effective aerobic exercise, your heart rate should be maintained at a level between 70% and 85% of your maximum heart rate as you exercise. This is known as your training zone. You can find your training zone in the table below. Training zones are listed for both unconditioned and conditioned persons according to age.

| AGE | TRAINING ZONE (BEATS/MIN.) |             |
|-----|----------------------------|-------------|
|     | UNCONDITIONED              | CONDITIONED |
| 20  | 138–167                    | 133–162     |
| 25  | 136–166                    | 132–160     |
| 30  | 135–164                    | 130–158     |
| 35  | 134–162                    | 129–156     |
| 40  | 132–161                    | 127–155     |
| 45  | 131–159                    | 125–153     |
| 50  | 129–156                    | 124–150     |
| 55  | 127–155                    | 122–149     |
| 60  | 126–153                    | 121–147     |
| 65  | 125–151                    | 119–145     |
| 70  | 123–150                    | 118–144     |
| 75  | 122–147                    | 117–142     |
| 80  | 120–146                    | 115–140     |
| 85  | 118–144                    | 114–139     |

During the first few months of your exercise program, keep your heart rate near the low end of your training zone as you exercise. After a few months of regular exercise, your heart rate can be increased gradually until it is near the middle of your training zone as you exercise. To measure your heart rate, stop exercising and place two fingers on your wrist. Take a six second heartbeat count.

Multiply the result by ten to find your heart rate. (A six second count is used because your heart rate drops quickly when you stop exercising.) If your heart rate is too high, decrease the intensity of your exercise. If your heart rate is too low, increase the intensity of your exercise.



**⚠ CAUTION:** If you feel pain or dizziness at any time while exercising, stop immediately and begin cooling down. Consult your physician before continuing with your fitness program.

## WORKOUT GUIDELINES

A well-rounded workout includes the following three phases:

**A warm-up phase**, lasting 5 to 10 minutes. Begin with slow, controlled stretches, and progress to more rhythmic stretches to increase body temperature, heart rate, and circulation in preparation for strenuous exercise.

**A cardiovascular phase**, including 20 to 30 minutes of exercising with your heart rate in your training zone.

**A cool-down phase**, consisting of 5 to 10 minutes of stretching. Thorough stretching offsets muscle contractions and other problems caused when you stop exercising suddenly. Stretching for increased flexibility is often most effective during this phase. This phase should leave you relaxed and comfortably tired.

To maintain or improve your condition, complete three workouts each week, with at least one day of rest between workouts. After a few months of regular exercise, you may complete up to five workouts each week, if desired. Whatever time you choose, be consistent and stick with it. Remember, the key to success is to make exercise a regular and enjoyable part of your everyday life.

# PART LIST—Model No. QVTL15050


R1095A

| Key No. | Qty. | Description                 | Key No. | Qty. | Description                 |
|---------|------|-----------------------------|---------|------|-----------------------------|
| 1       | 1    | Left Upper Body Arm w/Foam  | 41      | 1    | Right End Cap               |
| 2       | 1    | Right Upper Body Arm w/Foam | 42      | 2    | Rear Roller Adjustment Bolt |
| 3       | 1    | Hairpin Cotter              | 43      | 2    | Adjustment Plate            |
| 4       | 8    | Platform Screw              | 44      | 2    | Foam Grip                   |
| 5       | 4    | Screw                       | 45      | 1    | Walking Belt                |
| 6       | 10   | #8 Finish Washer            | 46      | 1    | Friction Cover              |
| 7       | 1    | Console                     | 47      | 1    | Pivot Bolt                  |
| 8       | 1    | Walking Platform            | 48      | 1    | Control Washer              |
| 9       | 2    | Incline Leg                 | 49      | 2    | Belt Guide                  |
| 10      | 1    | Upright                     | 50      | 1    | Wrench Clip                 |
| 11      | 1    | Lock Pin                    | 51      | 1    | Magnet                      |
| 12      | 1    | Flywheel Shaft w/Hardware   | 52      | 1    | Pad Knob                    |
| 13      | 2    | Eye Bolt                    | 53      | 1    | Allen Wrench                |
| 14      | 1    | Hood                        | 54      | 1    | Cable Tie                   |
| 15      | 1    | Arm Resistance Control      | 55      | 2    | Arm Cap                     |
| 16      | 2    | Friction Bracket            | 56      | 1    | E-Ring                      |
| 17      | 4    | Washer                      | 57      | 1    | Speed Control               |
| 18      | 2    | Upper Body Arm Housing      | 58      | 1    | Cable Tie Clip              |
| 19      | 2    | Friction Plate              | 59      | 1    | Resistance Clamp Screw      |
| 20      | 2    | Side Trim                   | 60      | 1    | Resistance Clamp            |
| 21      | 10   | #8 Flat Head Screw          | 61      | 1    | Knob Washer                 |
| 22      | 2    | Rear Foot                   | 62      | 1    | Reed Switch Extension Wire  |
| 23      | 4    | Rear Foot Screw             | 63      | 2    | Abdominal Pad Washer        |
| 24      | 1    | Upright Bolt                | 64      | 1    | Reed Switch Screw           |
| 25      | 1    | Upright Flat Washer         | 65      | 4    | Belt Guide Screw            |
| 26      | 2    | Incline Pin                 | 66      | 1    | Roller Push Nut             |
| 27      | 1    | Front Roller                | 67      | 1    | Resistance Belt             |
| 28      | 1    | Rear Roller                 | 68      | 2    | Incline Wheel Nut           |
| 29      | 1    | Reed Switch/Sensor Wire     | 69      | 2    | Incline Wheel Bolt          |
| 30      | 2    | Nylon Washer                | 70      | 2    | Incline Wheel               |
| 31      | 1    | Star Washer                 | 71      | 1    | Belt Resistance Cable       |
| 32      | 1    | Cage Nut                    | 72      | 1    | Abdominal Pad Extension     |
| 33      | 1    | Abdominal Pad               | 73      | 2    | Abdominal Pad Bolt          |
| 34      | 1    | Flywheel w/Hardware         | 74      | 1    | Cable Adjustment Screw      |
| 35      | 1    | Flywheel Belt               | 75      | 2    | Cable Adjustment Nut        |
| 36      | 2    | Retainer                    | 76      | 1    | Cable Clamp Bolt            |
| 37      | 1    | Frame                       | 77      | 4    | Cable Clamp Washer          |
| 38      | 2    | Nut                         | 78      | 1    | Cable Clamp Nut             |
| 39      | 2    | Frame Cap                   | 79      | 1    | Resistance Spring           |
| 40      | 1    | Left End Cap                | #       | 1    | User's Manual               |

Note: “#” Indicates a non-illustrated part. Specifications are subject to change without notice. See the back cover of this manual for information about ordering replacement parts.

# EXPLODED DRAWING—Model No. QVTL15050

R1095A



# ORDERING REPLACEMENT PARTS

To order replacement parts, simply call our Customer Service Department toll-free at 1-800-999-3756, Monday through Friday, 6 a.m. until 6 p.m. Mountain Time (excluding holidays). When ordering parts, please be prepared to give the following information:

- The MODEL NUMBER of the product. (QVTL15050)
- The NAME of the product. (WESLO® CARDIO WALK Dual Motion Manual treadmill)
- The SERIAL NUMBER of the product. (See the front cover of this manual.)
- The KEY NUMBER of the part(s) needed. (See page 10 of this manual.)
- The DESCRIPTION of the part(s) needed. (See page 10 of this manual.)

If possible, place the CARDIO WALK near your telephone for easy reference when calling.

## LIMITED WARRANTY

ICON Health & Fitness, Inc. (ICON) warrants this product to be free from defects in workmanship and material, under normal use and service conditions, for a period of ninety (90) days from the date of purchase. This warranty extends only to the original purchaser. ICON's obligation under this warranty is limited to replacing or repairing, at ICON's option, the product at one of its authorized service centers. All products for which warranty claim is made must be received by ICON at one of its authorized service centers with all freight and other transportation charges prepaid, accompanied by sufficient proof of purchase. All returns must be pre-authorized by ICON. This warranty does not extend to any product or damage to a product caused by or attributable to freight damage, abuse, misuse, improper or abnormal usage or repairs not provided by an ICON authorized service center or for products used for commercial or rental purposes, or for products used as store display models. No other warranty beyond that specifically set forth above is authorized by ICON.

ICON is not responsible or liable for indirect, special or consequential damages arising out of or in connection with the use or performance of the product or damages with respect to any economic loss, loss of property, loss of revenues or profits, loss of enjoyment or use, costs of removal, installation or other consequential damages of whatsoever nature. Some states do not allow the exclusion or limitation of incidental or consequential damages. Accordingly, the above limitation may not apply to you.

The warranty extended hereunder is in lieu of any and all other warranties and any implied warranties of merchantability or fitness for a particular purpose is limited in its scope and duration to the terms set forth herein. Some states do not allow limitations on how long an implied warranty lasts. Accordingly, the above limitation may not apply to you.

This warranty gives you specific legal rights. You may also have other rights which vary from state to state.

**ICON HEALTH & FITNESS, INC., 1500 S. 1000 W., LOGAN, UT 84321-9813**