

TAOS INSTALL GUIDE

RPD110144 / RPD110244 / RPD110344 / RPD110451

INSTRUCTIONS:

1. To prevent electrical shock, disconnect transformer from electrical supply and make sure power supply is completely off before installation. Fixtures should always be installed by a licensed electrician.
2. Secure the **mount** in the desired location.
3. Strip the outer insulation off the end of the 2-conductor **fixture lead wire** to separate them, then strip about ¼" of insulation off each conductor.
4. Unscrew the ½" **adapter**, leaving the **fixture lead wire** running through it (see figure).
5. Pull the **main supply cable** through the **mount** and connect it to the **fixture lead wire** using **UL listed wire connectors** suitable for the location (see figure).
6. Neatly return the connected wires back through the **mount** then screw the ½" **adapter** into the **mount**. Use an adjustable wrench to tighten it down.
7. Screw the fixture back into the ½" **adapter** and tighten down firmly by hand to ensure it is securely attached.

