

# Asphalt Anchor Installation Instructions

## #59367

1. Using a masonry or similar abrasive blade in a circular saw, cut a slot 8" long x 1 1/2" deep in the asphalt where the anchor is to be installed with the plates of the anchor parallel to the structure.
2. With a 5/8" masonry bit installed in a hammer drill, pre-drill a hole approx. 12" deep through the asphalt in the center of the slot.
3. Drive the anchor into the asphalt using a minimum 10 lb. sledge hammer or heavy hammer drill until the upper edge of the top anchor plate is 1" under the asphalt.

For horizontal anchorage at a maximum of 50 degrees, not for vertical anchorage.

