
Restoration Vision

From Now





Long-Term

To Phase 1


Medium-Term



We Add a Bunch of Structure

In Phase 1:

- To address structural starvation deficit
- Mimic wood accumulation... and promote beaver dam activity



Process Takes Over

 After some floods, those processes should be occurring (both through promotion & naturally)

We add subsequent phase(s) to keep pushing toward stage 0



Process Become Self-Sustaining

• In long-term, we see anastomosing becoming self-sustaining... and wood accumulation being fed by increased riparian vegetation




Some Indicators to Track


INDICATOR	EXISTING	AS-BUILT	2 – YEAR	GOAL (_? YEAR)
Proportion Active Channel & Floodplain (by VB area)	~20%	~ 25%	~ 40%	~ 90% ± 10
Cluer & Thorne (2013) – CEM Stage Proportions (by VB length)	0% (s0) 25% (s8) 35% (s7) 10% (s5) 20% (s2)	0% (s0) 25% (s8) 35% (s7) 10% (s5) 20% (s2)	0% (s0) 75% ± 10 (s8) 15% ± 10 (s7) <5% (s5) <5% (s2)	80% ± 20 (s0) 15% ± 10 (s8) 5% ± 5 (s7) 0% (s5) 0% (s2)
LWD Accumulations (structures per mile)	~ 2 /mi	~101/mi (PALS)	~200/mi (PALS) (Add 100 more PALS & some natural)	~ 200/mi (natural)
LWD Loading (count per mile)	~ 30 /mi	~ 4000 /mi	~ 6500 /mi (add ~ 2000 recruit ~ 500)	~ 6500 /mi (natural)
Beaver Dam Density (dams per mile)	0 /mi	50 /mi (BDAs)	75 / mi (mix of new BD, occupied BDAs, and new BDAs)	30–60 /mi (occupied BDs)

ZOIs Can and Do Overlap


Reiterate Design Concepts with Vignette from Wychus Creek



Add Structure... Watch Grow













DESIGN


- Overlapping zones of influence
- Complex function (primary complex objective)
- Hydraulic zone of influence is a hypothesis & guides next phases...






POND & WETLAND CREATION





OBJECTIVE: More Green & Blue



RIVERSCAPE EVOLUTION MODEL STAGE

