

PRO·FORM®

Model No. PF200410

CONNEXION STEPPER™

Congratulations for purchasing the CONNEXION STEPPER for your system. Please read these instructions carefully before assembling the CONNEXION STEPPER. If you have additional questions, please call our Customer Service Department toll-free at 1-800-999-3756, Monday - Friday, 6 a.m. - 6 p.m. Mountain Time (except holidays). To help us assist you, please mention the product model number (PF200410) when calling.

ASSEMBLY

Two persons are recommended in order to assemble the CONNEXION STEPPER. Remove all parts from the packing carton. **Make sure that all parts are included before disposing of the packing materials.** Assembly can be completed using two adjustable wrenches (not included).

Note: The CONNEXION STEPPER is designed to fit on a variety of systems. Your system may differ slightly from the system shown in the drawings below.

1. The CONNEXION STEPPER can be attached to either the right or left sides of your system. Remove the lower frame cap from the frame, on the side where you plan to attach the CONNEXION STEPPER. Slide the Extension (1) onto the frame. Align the holes in the Extension with the holes in the frame, and insert two Bolts (2) through the Extension and frame. It may be necessary to tilt the system slightly in order to align the holes. Tighten two Locknuts (3) onto the Bolts.

2. Rotate the Pedals (6, 7) to the position shown. Attach the Stepper Bracket (5) to the frame with two Bolts (2), Washers (4) and Locknuts (3).

Insert the right Cylinder Bracket (11) into one of the holes in the Right Pedal (7). The tab on the Bracket must be against the inside of the Pedal. Tighten a Knob (18) onto the end of the Bracket. Attach the left Cylinder Bracket to the Left Pedal (6) in the same manner.

3. Attach the Handlebar (21) to the top of the frame with two Bolts (2), Washers (4) and Locknuts (3).

