

Pilot Assembly Conversion

1. Vertically pull the Pilot Head to remove it from the pilot assembly.



2. Unscrew the orifice with an allen key and remove the old orifice



3. Screw in the replacement orifice hand tight.



4. Re-position the pilot head making sure it fits in the groove. Ensure the pilot hood is installed properly by giving it a light pull to ensure it is seated all the way down and clipped in.



**#51
NATURAL GAS**



**#30
PROPANE**



**#62
NATURAL GAS**

