

PCR instruction manual

1. Turn PCR machine on by pressing power button on side of machine.
2. After the LCD screen powers on, use the buttons on the front of the machine to dial in settings.
3. Place samples into well plate and shut the lid, ensuring that it is in direct contact with the top of the Eppendorf tubes.
4. Wait until machine displays a stop signal on the LCD screen. When this light flashes, the process has been completed.
5. Remove Eppendorf tubes from well plate and use them as desired.