

Installation Instructions

Locate OEM antenna on roof of vehicle and remove by unscrewing in a counter clockwise rotation. Install PERRIN antenna to roof making sure to only hand tighten.



Mounting Stud is adjustable in and out

NOTE: Threaded portion of mounting stud is adjustable in and out of base. Alternatively, you can remove stud and place into factory base on roof of vehicle. then screw PERRIN antenna onto stud.