

IOR TACTICAL SCOPES

SIGHTING IN:

ALL IOR TACTICAL SCOPES HAVE FINGER ADJUSTABLE KNOBS AND SUPER ACCURATE , AUDIBLE CLICKS.

-DO NOT ADJUST MAGNUM LOCK DEVICE

-DO NOT OVERTIGHTEN RING SCREWS WHEN MOUNTING RIFLESCOPES-12 IN/LB MAX.

-IF YOU ARE PLANNING TO USE ONE SCOPE ON MULTIPLE RIFLES, INSTALL 1913 PICATINNY BASES ON ALL RIFLES AND MOVE THE SCOPE AND RINGS TOGETHER INSTEAD OF TAKING THE SCOPE OUT OF RINGS AND REMOUNTING IT IN A NEW SET OF RINGS

-IF YOU TRAVEL BY AIRPLANE, DO NOT CHECK YOUR OPTICS. TAKE YOUR SCOPE & RINGS AND YOUR BINOCULARS ON BOARD.

SIGHTING IN:

NOTE: THIS PROCEDURE TAKES PATIENCE TO DO CORRECTLY BUT IS WELL WORTH YOUR TIME.

ZEROING THE TACTICAL SCOPE FOR ELEVATION

1] PLACE RIFLE ON SANDBAGS TO ENSURE A STABLE PLATFORM.

2] FIRE ONE ROUND AT SIGHTING IN TARGET.

3] MAKE YOUR ADJUSTMENTS IN 1/2 OR 1/4 MOA CLICKS, AS MARKED ON KNOB.

4] AFTER OBTAINING POINT OF IMPACT DESIRED, LOOSEN THE TWO LARGE OUTER SCREWS ON THE ELEVATION KNOB, ABOUT 3/4 TURN. **DO NOT TAKE SCREWS OUT AND DO NOT TOUCH SMALL CENTER SCREW** (SEE FIG .1)

5] WITH OUTER SCREWS LOOSE , GRASP TOP KNURLED PLATE WITH THUMB AND FORE FINGER TO INSURE "0" POSITION DOES NOT CHANGE. WITH OTHER HAND TURN KNOB TO "0" MARK. YOU WILL HEAR CLICKS BUT POINT OF IMPACT WILL NOT CHANGE BECAUSE YOU ARE HOLDING THE PLATE INTO PLACE. AFTER MAKING THE ADJUSTMENT TIGHTEN THE 2 SCREWS AND TAKE ANOTHER 3 OR 5 SHOTS. OBSERVE YOUR GROUP.

FOLLOW THE SAME PROCEDURE TO ADJUST FOR WINDAGE.

WHEN FINISHED, MAKE SURE ALL SCREWS ARE PROPERLY TIGHTENED. NOW, YOU ARE READY TO GO.

DO NOT FORGET TO PUT THE CAPS BACK ON THE TURRETS.