


2

CONNECT THE WIRES


Gently pull the supply wires. Connect the black (or brown) fixture wire to the black supply wire and the white (or blue) fixture wire to the white supply wire. Connect the fixture ground wire to the ground wire from the J-Box. Secure all connections with the supplied wire connectors and U.L listed electrical tape (not supplied). Tuck all wires carefully into the J-Box.



3

MOUNT THE CANOPY


Insert the nipple into the central hole of the crossbar, and adjust to suitable length. Fasten the Hex nut against the Crossbar so that the nipple will not rotate further. Position the Canopy against the ceiling, make the nipple pass through the center hole of the Canopy, then secure the Canopy against the ceiling by screwing the Decorative cap onto the nipple.



4

ATTACH THE GLASS SHADE

Install the shade on to fixture as figure shows.




5

INSERT THE BULB

Insert the bulb.

MAXIMUM WATTAGE 18W.

DO NOT EXCEED THE RECOMMENDED WATTAGE AS STATED ON THE WARNING LABEL AND INSTRUCTION SHEETS.



6

RESTORE THE ELECTRICITY AND CHECK THE

OPERATION OF YOUR NEW ACCESS FIXTURE

