

Boiler must be grounded in accordance with ANSI National Electric Code.

IMPORTANT: The wiring shown for devices supplied and installed by others is suggested only. Certification of, and responsibility for the correctness of the wiring is the responsibility of the supplier of these devices. Manufacturer accepts no responsibility for the correctness or safety or execution of this wiring or of the operation of such devices.

