

› Climate FieldView™ Drive Overview and Installation



The FieldView™ Drive is an in-cab hardware device that plugs into your equipment's CAN diagnostic port, capturing both machine and field data. It connects your equipment to your iPad® via Bluetooth®, monitoring and displaying data as you pass through your fields.

1. Check to see if your equipment is compatible by contacting your local Climate Dealer or visiting Climate.com/equipment.
2. Download the Climate FieldView™ app for free from the Apple App Store.
3. Use the Climate FieldView™ Plus Starter Kit to successfully install the FieldView Drive. Fit the case to your iPad, install the iPad mount in the cab, and plug in the USB charger.
 - A. On the underside of the FieldView Drive, you will find a unique, 12-character address which will help you identify the FieldView Drive when pairing with Bluetooth®.
 - B. Plug the FieldView Drive into your machine's nine-pin CAN diagnostic port and turn clockwise to lock into place. Power on your machine. The light on the FieldView Drive will blink green twice, indicating a successful docking.
4. Launch the Climate FieldView™ Cab app, and log into your account. The FieldView Drive's light will then glow green.
5. On your iPad in the Cab app home screen, navigate to "Settings", then to "Devices", select "Pair New Device", and then select the Drive and use the Bluetooth® feature to wirelessly connect.
6. The FieldView Drive's indicator light will glow blue. This means installation and Bluetooth pairing has been successful.



A. FieldView Drive
12-character address



B. Nine-pin CAN
diagnostic port

