


2.0 QUICK USE GUIDE

- Press the button **5x to turn on and off.**
- Press button **2x to cycle through each level.**

VARIABLE VOLTAGE LEVELS			
LOW 2.4V	MEDIUM 3.2V	HIGH 4.0V	WAX 4.0V
SMOOTH & MELLOW	MILD & BALANCED	RICH & ROBUST	STRONG & POTENT

- In **wax mode**, the battery can only be activated by pressing the stylus tip button. You can preheat the battery in the other three modes by pressing and holding the stylus tip button.
- The O.penVAPE 2.0 Variable Voltage Battery is equipped with a **rapid charge USB**, because we know your time is valuable.
- To activate rapid charge mode, simply swipe your finger across the , the light will change from orange to red once in rapid charge mode. When fully charged, the light on the USB and battery will be green.



A FRIEND FOR LIFE ALL O.PENVAPE PRODUCTS
COME WITH A LIFETIME BATTERY WARRANTY
OPENVAPE.COM

