

Fabric Light Box —QUICK START INSTRUCTIONS



1. Lay Aspen Fabric Frame parts out.
- Frame
 - AC adapter
 - Power cord



2. Connect the AC adapter to the frame and power cord.



3. Plug in.



4. The Aspen Fabric Frame can be hung either by landscape or portrait.

