CASITA CANOPY TENTS™ STEEL10FT STOCK

OUTDOOR BANNER STAND

PRODUCT CODE: CASTL-STK10

LIFE TIME on frame | 1 YEAR on graphic | OUTDOOR USE | ADJUSTABLE HEIGHT

Available Canopy Colors:

286c 2275c 485c Black 4c White

Available Vinyl Colors:

201c 348c 282c 2945c 124c White Black

PRODUCT DESCRIPTION	
Our Casita Canopy Tents™ are an excellent way to provide shade during outdoor events. This canopy has a 10’ x 10’ footprint with five height settings on the legs. Each square leg is 30mm thick. Heat Press stock canopies are available with 1 or 2 color logos. The logos are die-cut from vinyl and then imprinted onto fabric using a heat press transfer system. Choose up to 6 imprint locations (2 peaks and 4 valances).	
DISPLAY DIMENSIONS	118.75”W x 135”H x 118.75”D
MIN. HEIGHT	99”H
MAX. HEIGHT	133”H
LOWEST SETTING TO PEAK	120.25”H
FLOOR TO LOWEST SETTING	22”H
GRAPHIC DIMENSIONS	Peak Imprint Area: 52”W x 82”H Valance Imprint Area: 78”W x9.5”H
GRAPHIC MATERIAL	
Water proof canvas	
GRAPHIC FINISHING	
Pre-finished with imprinted heat press vinyl logo/graphic.	
DISPLAY CONSTRUCTION	
30mm Steel frame	
SHIPPING WEIGHTS & DIMENSIONS	
Shipping Weight	60 lbs (frame only) 70 lbs (frame and graphic)
Shipping Dimensions	63”H x 11”W x 11”D (over size)
LARGE QUANTITY FREIGHT	
Freight Shipping	18 boxes per 48”L x 40”W x 67”H skid
Freight Weight	621 lbs (frame only) 781 lbs (frame & graphic)
GRAPHIC TURN AROUND TIME	
4 business days after proof approval (up to 2 sets)	
AVAILABLE ACCESSORIES	
Rope	Sand Bag
Stakes	La Caja Hard Case
Flag Holder	Travel Bag Wheels
AVAILABILITY	CA Only
WIND RATING	20 mph

Standard Travel Bag

Optional Bag With Wheels

Optional La Caja Hardcase

Optional Rope & Stakes w/Bag

Optional Water Base

Crank for peak adjustment

Optional Flag Mount

Optional Sand Bag

CASITA CANOPY TENTS™ STEEL10FT STOCK

OUTDOOR BANNER STAND

PRODUCT CODE: CASTL-STK10

PARTS LIST

(qty 1) Canopy Frame

(qty 1) Travel Bag

CASITA CANOPY TENTS™ STEEL10FT STOCK

OUTDOOR BANNER STAND

PRODUCT CODE: CASTL-STK10

SET UP INSTRUCTIONS

(5FT CANOPY SHOW BELOW)

Step 1

Take your frame and slightly expand it open to expose the corner bars.

Step 2

Take your canopy graphic and place it on top of the frame.

Step 3

Adhere each corner of the canopy to each corner of the frame. Inside each corner of the canopy, there is a strip of loop Velcro sewn to it and each corner of the frame has a strip of hook Velcro.

Step 4

With the canopy securely in position, expand the frame until the corner latches lock into place.





Step 5

Increase the height by extending the lower legs.

Step 6

Pull each leg down until the latch locks into place.

Step 7

Locate the spindle under the canop y, in the middle of the frame. Pull the lever out and rotate to extend the upper peak pole. The dome cap will push out the canopy creating tension to flush out any loose areas.

Step 8

The install is complete.