CASITA CANOPY TENTS™ 5FT STOCK

PRODUCT CODE: CASTL-STK5





















Optional Water Base



Crank for peak adjustment

Optional Flag Mount



Optional Sand Bag

PRODUCT DESCRIPTION

Our Casita Canopy Tents™ are an excellent way to provide shade during outdoor events. This canopy has a 5' x 5' footprint with five height settings on the legs. Each square leg is 32mm thick. Heat Press stock canopies are available with 1 or 2 color logos. The logos are die-cut from vinyl and then imprinted onto fabric using a heat press transfer system. Choose up to 6 imprint locations (2 peaks and 4 valances).

DISPLAY DIMENSIONS	59.75"L x 59.75"W x 103.25"D
MIN. HEIGHT	95.5"H
MAX. HEIGHT	130.25"H
LOWEST SETTING TO PEAK	118"H
FLOOR TO LOWEST SETTING	22"H
GRAPHIC DIMENSIONS	Peak Imprint Area: 25"W x 13.5"H Valance Imprint Area: 40"W x 8"H

GRAPHIC MATERIAL

Water proof canvas

GRAPHIC FINISHING

Pre-finished with imprinted heat press vinyl logo/graphic.

DISPLAY CONSTRUCTION

Steel frame (Leg thickness: 32mm)

SHIPPING WEIGHTS & D	MENSIONS		
Shipping Weight	39 lbs (frame only) 43 lbs (frame and graphic)		

LARGE QUANTITY FREIO	RGE QUANTITY FREIGHT		
Freight Shipping	18 boxes per 50"L x 40"W x 74"H skid		

Shipping Dimensions 50"H x 9"W x 19"D (over size)

Freight Weight | 747 lbs (frame only) 849 lbs (frame & graphic) **GRAPHIC TURN AROUND TIME**

4 business days after proof approval (up to 2 sets)

AVAILABLE ACCESSORIES	ABLE ACCESSORIES		
Rope	Sand Bag		
Stakes	La Caja Hard Case		
Flag Holder	Travel Bag Wheels		
AVAILABILITY	CA Only		
WIND RATING	20 mph		



Standard Travel Bag



Optional Bag With Wheels



Optional La Caja Hardcase

PARTS LIST




(qty 1) Canopy Frame



(qty 1) Rope



(qty 1) Travel Bag



(qty 4) Stakes



(qty 1) Bag for Rope & Stakes

SET UP INSTRUCTIONS

Step 1

Take your frame and slightly expand it open to expose the corner bars.



Step 3

Adhere each corner of the canopy to each corner of the frame. Inside each corner of the canopy, there is a strip of loop Velcro sewn to it and each corner of the frame has a strip of hook Velcro.



Step 5

Increase the height by extending the lower legs.



Step 7

Locate the spindle under the canopy, in the middle of the frame. Pull the lever out and rotate to extend the upper peak pole. The dome cap will push out the canopy creating tension to flush out any loose areas.




Step 2

Take your canopy graphic and place it on top of the frame.



Step 4

With the canopy securely in position, expand the frame until the corner latches lock into place.



Step 6

Pull each leg down until the latch locks into place.



Step 8

The install is complete.

