




4 Leg Activity Tables
Assembly Instructions




022-3203 - Qty 4
Upper Leg




017-1170 - Qty 4
Lower Leg



Table comes with either glides or casters. NOT both.




015-0045 - Qty 4
Threaded Glide



015-0175 - Qty 4
2 1/2" Stem
Caster w/Brake




SC1054 - Qty 28
1/4-20 x 3/4" Phillips Screw





030-0396 - Qty 8
3/8-16 x 1/2"
Socket Set Screw

1

THIS STEP IS ONLY FOR TABLES 60"L AND LARGER





2




3

DEPENDING ON YOUR MODEL INSTALL EITHER CASTERS OR GLIDES



4



Bretford
11000 Seymour Avenue
Franklin Park, IL 60131
TEL: 847.678.2545
800.521.9614
FAX: 847.678.0852
800.343.1779

Bretford Ltd.
2 Etongate
110 Windsor Road, Slough
Berkshire SL1 2JA England
TEL: 011 44 17 5353 9955
FAX: 011 44 17 5353 9478