eurøstyle

Assembly Instructions Anderson Dining Table





A (12 pcs) 6x15mm



B (4 pcs) 8x45mm



C (4 pcs)



D (4 pcs) 9x12x1.5mm



s) E (4 pcs) nm 8x17x12mm



F (1 pc)




G (1 pc)



H (1 pc)

PLEASE NOTE: Check that you have received all components and hardware before assembling. If you are missing any parts, contact your retailer, or email: cs@euro.style.



During assembly, hand tighten screws only. When the screws are in place, tighten completely.