

eurøstyle

Assembly Instructions ALISA Dining Table



PLEASE NOTE: Check that you have received all components and hardware before assembling. If you are missing any parts, contact your retailer, or fax Eurø Style at 415.455.8033 or email: cs@gotoeurostyle.com.



During assembly, hand tighten screws only. When the screws are in place, tighten completely.