



Assembly Instructions








WESLEY Coffee Table



PLEASE NOTE: Check that you have received all components and hardware before assembling. If you are missing any parts, contact your retailer.



Note: Indentation side of thread rod (Part A) must be thread into the table top.





During assembly, hand tighten screws only. When the screws are in place, tighten completely.

Assembly Instructions

WESLEY Coffee Table

PLEASE NOTE: Check that you have received all components and hardware before assembling. If you are missing any parts, contact your retailer.



NOTE: If the table is wobbly, the plastic feet (6 pcs) can be adjusted as needed. Turn right to bring the feet in, or turn left to bring the feet out more.