

C570R

7/28/2009

Bbl#	Description	Qty	Part #
1	Display Assembly	1	C570R-01
2	Wire, Alternator to Drive Board	1	C570R-02
3	Wire, Battery Charger	1	C570R-03
4	Wire, Battery to Drive Board	1	C570R-04
5	Wire, Display to Cardio Board	1	C570R-05
6	Wire, CSAFE upper to Pedestal	1	C570R-06
7	Drive Belt, 470J8	1	XT20-21
8	Flywheel w/ one way bearing	1	C570R-08
9	Alternator Belt, 330J5	1	XT20-23
10	Alternator	1	XT20-04
11	Alternator Bracket	1	C570R-11
12	Wire, CSAFE Lower to Pedestal	1	C570R-12
13	Wire, Flywheel Mag. to Dr. Bd.	1	C570R-13
14	Drive Board	1	C570R-14
15	Battery Bracket	1	XT20-03
16	Battery	1	5002-14
17	CSAFE Board	1	C570R-17
18	Display Back Piece	1	C570R-18
47	Connector, Pedestal to Frame	1	C570R-47
48	Transport Wheel & Axle	2	C570R-48
49	Face Plate, On/Off Switch	1	C570R-49
50	AV Terminal Board for LCD	1	T670-61
51	Front Lower cover	1	C570R-51
52	Fan cover	1	C570R-52
53	Wire, Fan	1	C570R-53
54	Wire, Display to Pedestal	1	C570R-54
55	Pedestal	1	C570R-55
56	Book Holder	1	T680-02
57	Cardio Board	1	C570R-57
58	Cover connector	1	C570R-58
59	Cover soft Connector	2	C570R-59
60	Cover Positioner	1	C570R-60
61	Frame	1	C570R-61
62	Pedals w/ Strap, Pair	1	C570R-62
*	Pedal Straps, Pair	*	C570R-500
63	Crank Arm, Right	1	C570R-63
64	Side Cover, Right	1	C570R-64
65	Spring, Idler Pulley	1	XT20-07
66	Idler Pulley	1	C570R-66
67	Crank Connector	2	C570R-67
68	Spindle	1	C570R-68
69	Drive Pulley	1	XT20-18
70	Support Right cover	1	C570R-70
71	Wire, Hub to Drive Board	1	C570R-71
72	Wire, HTR, Coiled	1	C570R-72
73	Hub Board	1	C570R-73
74	Front Frame Cover	1	C570R-74
75	Rear Frame Cover	1	C570R-75
76	Rear Support Front Cover	1	C570R-76
77	Rear Support Frame	1	C570R-77
78	Rear End Cap	2	XT20-44A
79	Leveler	2	2100-72
80	Right Rear Tube Inner Cover	1	C570R-80
81	Right Rear Tube Outer Cover A	1	C570R-81
82	Left Rear Tube Inner Cover A	1	C570R-82
83	Left Rear Tube outer Cover	1	C570R-83
84	Rear Frame Rear Cover	1	C570R-84
85	Right Bottle Hlder	1	C570R-85
86	Cover Between Bottle Holders	1	C570R-86
87	Left bottle Holder	1	C570R-87
88	Wire, Handlebars to HTR Board	1	C570R-88
89	HTR PC Board	1	3100-74
90	Handlebar, HRC	1	C570R-90

Bbl#	Description	Qty	Part #
91	Left Support Cover	1	C570R-91
92	Support Front Cover	1	C570R-92
93	Wire, Drive Board to Pedestal	1	C570R-93
94	Cover Positioner A	1	C570R-94
95	Cover Positioner C	1	C570R-95
96	Wire, Optic Sensor to Drive Board	1	C570R-96
97	Optic Sensor	1	C570R-97
98	Upper Cover	1	C570R-98
99	cover Soft Connector	2	C570R-99
100	Side Cover Left	1	C570R-100
101	Crank Arm, Left	1	C570R-101
102	Seat Position Label	1	C570R-102
103	Seat Position Rail	1	C570R-103
104	Seat Stopper	2	5002-13
105	Seat Rail	1	C570R-105
106	Sopper Axle	2	C570R-106
107	Cable Cover	1	C570R-107
108	Seat Support Bracket	1	XT20-109
109	Seat Bottom	1	5150-44
110	Seat Back	1	C570R-110
111	Seat Back Cover	1	C570R-111
112	Seat Back Frame	1	C570R-112
113	Seat Back Connection Cover	2	C570R-113
114	Doublehead Key	1	C570R-114
115	Seat Back Left Rotator	1	C570R-115
116	Seat Back Right rotator	1	C570R-116
117	Self Lubricating Bearing	2	C570R-117
118	Seat Adjust Axle Sheath	1	C570R-118
119	Adjustment Block	1	C570R-119
120	Right Spraing	1	C570R-120
121	Screw Sheath	1	C570R-121
122	Seat Mojnt	1	C570R-122
123	Seat Adjust Rod	1	C570R-123
124	CLN Connector 41-1R 3 Prong	1	C570R-124
125	Gear cover	1	C570R-125
126	Rotator Spring	1	C570R-126
127	Position Pin	1	C570R-127
128	Spring Bracket	11	C570R-128
129	Seat rod Key	1	5002-40
130	HTR Board Cover	1	5100-82
131	Handle	1	C570R-131
132	Positioner Rod	1	C570R-132
133	Lock Mechanism, Seat	1	5002-42
134	Rotator Spring A	1	C570R-134
135	Curley Wire Bracket	1	C570R-135
136	Seat Mount Position Rod	1	C570R-136
137	Seat Mount Assembly	1	C570R-137
138	H/R Transmitter Strap	1	3100-03A
139	HRC Receiver Board	1	C570R-139
140	Air channel Cover	1	C570R-140
141	Fan	1	C570R-141
142	Fan Bracket	1	C570R-142
143	Air blocker Cover	1	C570R-143

*	Owner's Manual	1	C570R-OM
*	Keypad for Display *No Overlay*	1	C570R-144
*	Display Overlay C570R	1	C570R-501