

PART LIST—Model No. 831.159201

Rev. 10/92

Key No.	Reorder No.	Qty.	Description	Key No.	Reorder No.	Qty.	Description
1	109306	1	Base	32	108734	2	Leg Lever Foam Pad
2	109305	1	Upright	33	108737	1	Leg Lever Pin
3	110577	1	Seat Frame	34	015043	1	Hairpin Cotter Pin
4	109204	3	Base Endcap	35	109318	3	Retainer Spring
5	110225	1	Right Pedal Assembly	36	109695	2	Short Pull Pin
6	110224	1	Left Pedal Assembly	37	109696	1	Long Pull Pin
7	106872	2	Pedal Cover	38	110229	1	"D" Axle
8	109867	2	Pedal Bushing Set	39	103903	2	1/2" Axle Cap
9	109868	2	Pedal Spacer	40	109823	2	VKR Hook
10	103735	2	3/4" Axle Cap	41	106468	1	VKR Pad
11	109871	2	Resistance Cylinder	42	109685	2	Arm Foam Pad
12	109872	4	Cylinder Bushing Set	43	110306	1	Lat Bar Cotter Pin
13	109873	2	Cylinder Spacer	44	110578	1	Right Arm
14	100151	2	5/8" Axle Cap	45	109315	1	Left Arm
15	109692	2	Carriage Bolt	46	109314	1	Lat Bar
16	014156	2	Washer	47	105318	1	Backrest
17	012159	2	Nut	48	109317	1	Swing Arm
18	012108	2	Nylock Nut	49	109309	2	#1 Weightband
19	013184	2	Backrest Bolt	50	107317	2	Large #1 Wt. Hub
20	104049	2	Seat Frame Bolt	51	109689	2	Small #1 Wt. Hub
21	013456	4	Short Bolt	52	109693	2	Arm Pin
22	013498	1	Long Seat Bolt	53	109310	2	#2 Weightband
23	105376	1	Seat	54	110468	2	Lock Washer
24	108741	1	Seat Frame Endcap	55	109694	2	Small Cotter Pin
25	111132	1	Leg Lever Pin	56	107319	2	Large #2 Wt. Hub
26	013512	1	Screw	57	109690	2	Small #2 Wt. Hub
27	108697	1	Weightband Tube	58	014062	7	Small Lock Washer
28	108726	1	Foam Pad Tube	#	110499	1	Owner's Manual
29	103805	2	Foam Pad	#	109698	1	Exercise Manual
30	108635	1	Leg Lever	#	104838	1	Grease
31	108742	2	Leg Lever Endcap				

Note: "#" indicates a non-illustrated part. Specifications are subject to change without notice. See the back cover for information about ordering replacement parts.

Rev. 10/92

