


Model No. 831.286870



See the back cover of this manual for information on ordering replacement parts.

Specifications are subject to change without notice.

PARTS LIST

Lifestyler 2200 • Model No. 831.286870

No.	Description	Qty.	Reorder	No.	Description	Qty.	Reorder
1	Lifestyler 2200 Frame	1	004042	18	Square Tube Cap	2	040035
1A	Upright Bench Bracket	1	On Frame	19	Side Frame Bar	2	006070
1B	Chrome Bar Bracket	1	On Frame	20	Top Frame Insert	2	008052
1C	Foot Rest Mount	1	On Frame	22	Carriage Bolt	4	013205
1D	Bench Bracket	1	On Frame	23	Washer	4	014019
2	Square Rubber Cap	4	040019	24	"T" Wingnut	2	017001
3	Acorn Nut	1	012013	25	Bolt, Washer & Locknut	4 sets	070015
4	Foot Rest	2	039001	26	Rowing Arm	2	002030
5	Foot Rest Shaft	1	049008	27	Hand Grip	2	041003
6	Washer	2	014019	28	Abdominal Bar	1	006048
7	Locknut	4	012002	29	Foam Roller Pad	2	057002
8	Bench Bar	1	006080	30	Roller Pad Cover	2	057003
9	Long Bolt	1	013050	31	Black "H" Clamp	2	016016
10	Bench	1	042006	32	Joint Cap	2	040017
11	Thumb Screw	2	017011	34	Rowing Handle	2	002027
12	Rowing Seat	1	070048	35	Handle Pin	2	015016
13	Wheel Assembly	2 sets	070011	36	Recoiler Hydrlic Shock	2	043006
14	Chrome Rowing Bar	1	006015	37	Plug	2	040052
15	Rectangle Bar Cap	3	040014	38	Velcro Strap	1	035005
16	Long Hitch Pin	1	015004	39	Locking T-Wingnut	1	017003
16A	Arm Hitch Pin	2	015003	40	Bushing	2	019043
17	T-Frame Support Bar	1	006016				