


PART LIST - Model No. 831.287262

Rev. 5/90


Key No.	Reorder No.	Qty.	Description	Key No.	Reorder No.	Qty.	Description
1	100387	4	Axle Nut	32	012120	4	Acorn Nut
2	014030	6	Flat Washer	33	014100	4	Curved Washer
3	012169	1	Thin AxleNut	34	100506	2	Stabilizer
4	019322	1	Axle Spacer	35	040207	4	Stabilizer Cap
5	049107	1	AxleShaft	36	013092	4	Carriage Bolt
6	018007	1	Bearing	37	010199	2	Fan Shield
7	021053	1	Fan w/Sprocket	38	100508	1	Right Handlebar
8	040062	2	Handlebar Endcap	39	070902	1	Crank/Sprocket Assy.
9	041065	2	Foam Grip	40	042005	1	Seat
10	100507	1	Left Handlebar	41	007123	1	Seat Post
11	038045	1	Left Pedal	42	012002	3	Seat Nut
12	012042	4	Lock Nut	43	010124	1	Bellows
13	058028	1	Short Spring Assy.	44	019288	1	Seat Post Sleeve
14	019325	2	Outer Pivot Bushing	45	015073	1	Seat Pin
15	100544	1	Left Side Shield	46	NSP	1	Frame
16	013282	2	Side Shield Screw	47	033184	1	Sensor Wire Reed Switch
17	100547	1	Pivot Shaft	48	100498	3	Sensor Magnet
18	013336	1	Shaft Screw	49	054035	4	Clip
19	032051	1	Electronic Monitor	50	013538	6	Fan Shield Screw
20	062011	3	Adhesive Tape	51	100545	1	Right Side Shield
21	050001	1	Strap Buckle	52	025071	1	Chain
22	013572	1	Strap Buckle Screw	53	038046	1	Right Pedal
23	100261	1	Resistance Strap	54	008279	1	Fan Shield Bracket
24	072057	1	Resistance Knob/Cable	55	013594	4	Self-Tapping Screw
25	013569	2	Knob Screw	56	019331	2	Pedal Bushing
26	100509	2	Link Arm	57	019287	2	Link Arm Bushing
27	019208	2	Handlebar Bushing	58	100475	1	Bearing Cup Assembly
28	100546	4	Inner Pivot Bushing	#	100792	1	Owner's Manual
29	012111	1	Adjustment Bolt	#	089016	1	Monitor Guide
30	014171	1	Formed Washer	#	045028	1	Socket Tool
31	013568	1	Adjustment Bolt	#	100496	1	Screwdriver Tool

Note: “#” indicates a non-illustrated part.

10 See the back cover of this manual for part ordering information.



Crank Assembly



*Specifications are subject to change without notice.