

PART LIST—Model No. 831.287590

Rev. 8/5

Key No.	Part No.	Qty.	Description	Key No.	Part No.	Qty.	Description
1	NSP	1	Frame	29	101459	2	5/8" Washer
2	013356	9	3/16" Small Screw	30	100906	2	Pedal
3	102576	4	3/16" x 3/4" Shield Screw	31	014041	2	5/16" Pedal Washer
4	100387	4	5/16" Fan Nut	32	012146	2	5/16" Pedal Nut
5	014030	7	5/16" Washer	33	040158	2	Pedal Cap
6	012002	6	5/16" Locknut	34	113155	4	Handlebar Bushing
7	104824	2	Fan Bushing	35	101758	2	3/8" Plastic Cap ^{5/8"} 100151
8	012096	2	1/4" Adjustment Nut	36	114467	1	Right Handlebar
9	104583	2	1/4" x 2" Adjustment Bolt	37	114468	1	Left Handlebar
10	100128	2	Adjustment Bracket	38	112776	2	Handlebar Foam
11	107826	1	Fan Axle	39	113094	2	Stabilizer
12	105681	1	Fan w/Sprocket	40	100290	4	Endcap
13	013226	2	5/16" x 1 3/4" Screw	41	012096	4	1/4" Seat Nut
14	101841	2	Access Cover	42	113086	1	Seat Post
15	101116	1	Sprocket	43	104787	1	Seat Post Sleeve
16	100905	2	Pedal Shaft	44	111903	2	3/16" x 1/2" Screw
17	105032	1	Chain	45	107106	1	Spacer
18	101115	1	Crank	46	112777	1	Electronic Monitor
131768-19	101241	2	Protective Cap	47	100364	2	Link Arm Bushing
20	013510	1	3/16" x 3/4" Screw	48	105022	1	Seat
21	033148	1	Reed Switch/Sensor Wire	49	013374	4	5/16" x 2 1/2" Carriage Bolt
22	013336	1	1/4" Shaft Screw	50	114469	1	Right Side Shield
23	100904	2	1/2" Locknut	51	114470	1	Left Side Shield
24	114487	1	1/2" Pedal Spacer	52	015073	1	Seat Pin
25	101036	2	Pedal Bushing	53	100498	1	Sensor Magnet
26	113093	2	Link Arm	54	114488	1	Handlebar Shaft
27	114491	1	Monitor Bracket	55	101460	2	Pedal Spring
28	114490	1	Crank Assembly	56	103571	2	11/16" Washer
				#	114471	1	Owner's Manual

Note: "#" indicates a non-illustrated part. Specifications are subject to change without notice. See the back cover of this manual for information about ordering replacement parts.

EXPLODED DRAWING—Model No. 831.287590

Rev. 8/93

