

PARTS LIST

NO. DESCRIPTION QTY. REORDER NO.

1	Aluminum Bar	2	006060
2	Bracket Bolt	4	013266
3	Rear Bracket w/ Drum	1	008078
3A	Bracket Plate	1	061009
4	Frame Bracket	1	008079
5	Drum Bracket Adj. Knob	1	013047
6	Rear Crossbar	1	
6A	Nut	4	012026
6B	Washer	4	014030
7	Hitch Pin	2	015003
8	Middle Crossbar	1	00068
9A	Washer	2	014019
9	Crossbar Bolt	2	013265
10	Swivel Arm Bushing	2	019029
11	Swivel Arm Bolt	2	013109
12	Washer	2	014019
13	Foot Pad Screw	6	013106
14	Rubber Foot	6	051003
15	End Cap	2	040067
15A	Mdl. Crsbr. Hsng. Cap	2	040030
15B	Front Cross Hsng. Cap	2	040030

16A	Bolt	4	012010
16B	Washer	4	014005
16C	Nut	4	012002
17	Swivel Arm	2	006036
18	"T" Wing Nut	2	017001
19	"H" Clamp	2	016022
20	Hydraulic Shock	2	043003
21	Nut	4	012003
22	Washer	4	014019
23	Carriage Bolt	4	013051
24	Rowing Arm	2	002018
25	Hitch Pin	2	015002
27	Rowing Handle	2	002035
28	Foam Handgrip	2	041008
29	End Cap	2	040066
30	Front Bracket w/ Drums	1	008077
30A	Bracket Plate	1	061008
30B	Bracket Bolt	1	013267
31	Front Crossbar	1	006081
32	Locknut	2	012075
33	Washer	2	014058

34	Foot Rest Shaft	2	049046
35	Foot Rest	2	039001
36	Stopper Bolt	2	013268
36A	Spacer	2	019103
37	Front Bracket	1	008077
38	Nylon Strap	1	026009
39	Hitch Pin	2	015007
40	Rowing Seat	1	042009
41	Strap	2	035014
43	Left Skiing Pedal	1	038015
44	Right Skiing Pedal	1	038015
45	Nut	8	013030
46	Washer	8	014042
48	Roller Wheel	8	020004
49	Bolt	8	013080
50	Skiing Pole	2	006028
51	Skiing Pole Handgrip	2	041010
52	End Cap	2	004004
53	Bolt	2	
53A	Wingnut	2	
54	Phillips Head Screws	8	

