

PART LIST

Lifestyler 525 (Model 29123)

No.	Description	Qty.	Reorder No.
1	Crossbar	1	006003
2	Carriage Bolt	2	013011
2A	Molded Washer	2	014006
2B	Acorn Nut	2	012001
3	Frame	1	004006
4	Right Pedal	1	038006
5	Crank w/Sprocket	1	023002
6	Left Pedal	1	038005
7	Seat Post	1	007003
8	Seat	1	042004
9	Seat Tube	1	On Frame
10	Clamp	1	016001
10A	Bolt	1	013001
10B	Washer	1	014005
10C	T-Wingnut	1	017001
11	Handlebar	1	001006
12	Handgrip	2	041001
13	Handgrip Cap	2	040004
14	Resistance Control w/Cable	1	072006
15	Speedometer Drive	1	028002
16	Pivot Rod	1	049004
17	Bolt	1	013020
17A	Washer	1	014003
18	Plastic Cap	2	040011
19	Meter Hood	1	009005
19A	Meter Hood Screw	2	013016
20	Hydraulic Shock	1	043001
21	Bolt	1	013052
22	Nut	2	012002
23	Bolt	1	013010
23A	Washer	1	014005
24	Shock Hood	1	009003
25	Long Screw	1	013028
25A	Short Screw	1	013023
26	Chain	1	025002

No.	Description	Qty.	Reorder No.
27	Right Chain Guard	1	010023
27A	Chain Guard Screw	1	013021
28	Left Chain Guard	1	010022
29	Brake Bracket	1	008002
30	Right Control Bar	1	072003
31	Left Control Bar	1	072002
32	Right Brake Shoe	1	036001
33	Left Brake Shoe	1	036002
34	Flywheel	1	021004
35	Brake Adjustment Screw	1	016006
36	Front Rubber Cap	2	040001
37	Rear Rubber Cap	2	040006
38	Plastic Axle Cap	2	017008
39	Bolt	2	013018
39A	Washer	2	014022
39B	Nut	2	012003
40	Speedometer	1	027006
40A	Speedometer Cable	1	
41	Timer	1	029001
42	Newton Meter Frame	1	034007
42A	Newton Meter Spring	1	058003
42B	Clear Plastic Cover	1	073003
42C	Cloth Chart	1	034006
42D	Front Roller	1	034009
42E	Back Roller	1	034006
43	Meter Chart Decal	1	034006
44	Axle	1	049002
44A	Thick Nut	2*	012032
44B	Thin Nut	2*	012031
44C	Thick Spacer	1*	019020
44D	Thin Spacer	2*	019021
44E	Tapered Spacer	2*	014001
44F	Washer	8*	014015
45	Wrench	1	045003

*Quantity may vary

Replacement parts may be ordered by calling customer service toll-free at 1-800-824-3109 (In Canada, 1-800-824-8949) during regular business hours: 8 a.m. -5 p.m., Mon.-Fri., Mountain Standard Time.

