


REMOVE THIS EXPLODED DRAWING AND PART LIST FROM THE MANUAL!

Save this EXPLODED DRAWING and PART LIST for future reference.



Note: Specifications are subject to change without notice. For information about ordering replacement parts, see the back cover of this manual.

PART LIST—Model No. DRTL20351

R0496A

Key No.	Qty.	Description	Key No.	Qty.	Description
1	2	Crossbar Bolt	63	2	Guard Spring
2	10	Crossbar Bracket Screw	64	8	Cage Nut
3	1	Left Crossbar Bracket	65	2	Crossbar Bracket
4	12	Console Screw	66	2	Stabilizer Plate Washer
5	1	Key/Clip	67	6	Nut
6	1	Left Upright	68	2	Incline Leg
7	1	Pot Wire Harness	69	1	Right Rear Adjustment Bolt
8	1	100" Ground Wire	70	1	Motor Lock Nut
9	1	Console Crossbar	71	1	Stabilizer Plate Bolt
10*	1	Console	72	1	Rear Hood
11	2	Motor Nut	73	1	Base
12	1	Motor	74	1	Left Rear Adjustment Bolt
13	1	Pulley/Flywheel/Fan	75	1	Rear Roller
14	1	Base Shock	76	1	Rear Roller Tension Spring
15	1	Motor Belt	77	1	Spring Sleeve
16	7	Motor Tension Bolt/Upright Bolt	78	1	Roller Tension Nut
17	1	Motor Tension Washer	79	1	Rear Roller Guard
18	5	Star Washer	80	4	Roller Guard
19	2	Motor Bolt	81	8	Hood Anchor Screw
20	1	Motor Tension Nut	82	8	Platform Screw
21	1	Front Hood	83	1	Allen Wrench
22	1	Motor Mount Bracket	84	1	4" Wire Tie
23	1	Motor Swivel Bolt	85	2	8" Wire Tie
24	1	Reed Switch/Sensor Wire	86	1	Tie Holder Clamp
25	1	Magnet	87	8	Platform Isolator
26	2	Adhesive Clip	88	1	Right Upright
27	14	Screw	89	1	Wire Guard
28	3	Wire Clip	90	4	Incline Leg Spacer
29	4	Hood Anchor	91	2	Incline Leg Bracket
30	1	Safety Cover Plug	92	1	Upright Plug
31	1	Electronics Bracket	93	4	Wheel Spacer
32	1	Controller	94	1	Stabilizer Plate
33	1	Upright Wire Harness	95	8	Base Pad
34	1	Choke	96	4	Resistance Bracket Bolt
35	1	Circuit Breaker	97	2	Resistance Bracket
36	1	Right Crossbar Bracket	98	2	Resistance Bolt
37	1	Front Roller Adj. Bolt	99	2	Resistance Sleeve
38	5	Adjustment Washer	100	2	Resistance Cone
39	1	Power Cord	101	2	Resistance Knob
40	1	Grommet	102	2	Upper Body Arm
41	1	Reed Switch Extension Wire	103	2	Foam Grip
42	1	Speed Control Knob	104	4	Crossbar Screw
43	1	Safety Cover	105	1	Front Hood Spacer
44	30	Safety Cover Screw	106	1	Rear Hood Spacer
45	1	Front Roller/Pulley	107	4	Rubber Hood Mount
46	1	Walking Platform	108	4	3/8" Flat Washer
47	1	Walking Belt	109	4	Thrust Washer
48	2	Foot Rail	110	2	Thrust Bearing
49	1	Frame	111	2	Spring Washer
50	4	Incline Leg Bolt/Wheel Bolt	112*	1	Motor/Pulley/Flywheel/Fan
51	2	Incline Leg Spring	113	2	Crossbar Bracket Washer
52	2	Belt Guide	114	2	Cable Loom
53	2	Upright Pivot Washer	115	4	Ratchet Mounting Screw
54	1	Water Bottle Insert	116	2	Wire Grommet
55	2	Wheel Nut	117	4	Resistance Bracket Washer
56	2	Upright Pivot Bolt	118	6	Isolator Cover
57	2	Incline Wheel Bolt	119	1	Battery Cover
58	4	Wheel	#	1	8" White Wire, Male/Female
59	2	Incline Leg Latch	#	1	4" Black Wire, Male/Female
60	1	Stabilizer Plate Nut	#	1	User's Manual
61	1	Potentiometer			
62	1	Wire Tie			

* Includes all the parts shown in the box

These parts are not illustrated

EXPLODED DRAWING—Model No. DRTL20351

R0496A

