

PART LIST/EXPLODED DRAWING


Model No. FMKBRK10.0 R0511A

Key No.	Qty.	Description
1	1	Upper Tray
2	1	Base
3	8	Screw
4	8	Washer
5	1	Lower Tray
6	4	Cap
7	4	Foot
*	—	User's Manual

Note: Specifications are subject to change without notice. To order replacement parts, see the information below. *These parts are not illustrated.

Assembled Dimensions

Length: 2 ft. 6 in. (76 cm)
Width: 3 ft. 7 in. (109 cm)
Weight: 66 lbs. (30 kg)



HOW TO CONTACT CUSTOMER CARE

If you have questions after reading this manual, or if parts are damaged or missing, please contact Customer Care at one of the phone numbers or addresses listed below. **Please note the model number, serial number, and name of the product (see the front cover of this manual) before contacting Customer Care. If you are ordering replacement parts, please also note the key number and description of each part (see the PART LIST/EXPLODED DRAWING above).**

In the United States and Canada

Call: 1-800-201-2109, Mon.–Fri. 8 a.m.–5 p.m. MT

Write:

FreeMotion Fitness
1500 South 1000 West
Logan, UT 84321-9813
United States

Outside the United States and Canada

Call: 001-435-786-3521

Email: intlcustomercare@freemotionfitness.com