


PART LISTS AND EXPLODED DRAWINGS

DIGITAL TV FOR ELLIPTICAL/EXERCISE BIKE

R0515A

Key No.	Qty.	Description
1	1	Digital TV
2	1	Mounting Bracket
3	1	Bracket Cover
4	1	Remote Control
5	1	Controller
6	4	M8 Washer
7	4	M8 x 15mm Screw
8	4	M4 x 12mm Screw
9	2	M5 x 12mm Screw
10	1	Power Adapter/Wire
11	1	TV Power Wire
12	1	TV Coaxial Cable
*	-	User's Manual




Note: Specifications are subject to change without notice. For information about ordering replacement parts, see the back cover of this manual. *These parts are not illustrated.

DIGITAL TV FOR TREADMILL

R0515A

Key No.	Qty.	Description
1	1	Digital TV
2	1	Mounting Bracket
3	1	Bracket Cover
4	1	Remote Control
5	1	Controller
6	2	M8 x 20mm Screw
7	2	M8 x 50mm Screw
8	4	M8 Spring Washer
9	4	M4 x 10mm Screw
10	2	M5 x 15mm Screw
11	1	Power Adapter/Wire
12	1	TV Power Wire
13	1	TV Coaxial Cable
14	2	M4 x 20mm Screw
15	1	Bumper
*	-	User's Manual



Note: Specifications are subject to change without notice. For information about ordering replacement parts, see the back cover of this manual. *These parts are not illustrated.