

# PART LIST—Model No. IM392012

Rev. 10/92

Key No.	Qty.	Description	Key No.	Qty.	Description
1	1	Side Rail w/Foam Grip	43	12	Plastic Clip
2	2	Foam Grip	44	2	Front Wheel
3	1	Console	45	3	Wheel Bolt/Incline Motor Bolt
4	26	Screw	46	1	Incline Leg
5	1	Speed Dial	47	2	Leg Bolt
6	1	Clothes Clip	48	2	U-Nut
7	1	Incline Control	49	1	Right Foot Rail
8	1	Bezel	50	1	Controller
9	1	Pulse Earclip	51	1	Choke
10	1	Handrail Bolt	52	3	Adjustment Washer
11	1	Upright Post	53	1	Swivel Bolt
12	1	Handrail/Foam Grip	54	1	Front Roller Adjustment Bolt
13	1	Safety Key/Clip	55	1	J-Bolt
14	1	Push Nut	56	1	Safety Cover
15	1	Incline Motor	57	1	Swivel Nut
16	6	Platform Clamp Bushing	58	1	Front Roller/Pulley
17	6	Small Bushing	59	6	Platform Screw
18	1	Flywheel	60	1	Walking Belt
19	4	Motor Mount Washer	61	1	Walking Platform
20	4	Motor Mount Nut	62	1	Frame
21	1	Motor	63	2	Rear Leg Endcap
22	1	Fan	64	6	Rear Leg Screw/Guard Screw
23	1	Motor Pulley	65	1	Right Endcap
24	3	Motor Mount Bolt	66	1	Allen Wrench
25	1	Motor Mount Bracket	67	2	Rear Roller Adjustment Bolt
26	1	Lower Motor Pin	68	1	Wrench Clip
27	1	Cotter Pin	69	1	Rear Roller
28	1	Incline Motor Spacer	70	2	Roller Guard
29	1	Power Supply Plate	71	2	High Density Foam
30	1	Power Supply	72	1	Left Endcap
31	4	Plastic Stand-off	73	1	Left Foot Rail
32	3	Wire Clip	74	1	Motor Hood w/Decal
33	6	Platform Clamp	75	1	Side Rail Bolt
34	4	Locknut	76	1	Side Rail Nut
35	1	Lock Knob Washer	77	4	Hood Mount Anchor
36	1	Lock Knob	78	1	Magnet
37	1	Pivot Bolt	79	1	Front Roller Insert
38	2	Washer	80	1	Reed Switch/Sensor Wire
39	1	Star Washer	81	2	Endcap Screw
40	1	Grommet	82	1	Belt
41	1	Power Cord	#	1	Owner's Manual
42	1	Circuit Breaker			

Note: "#" indicates a non-illustrated part. Specifications are subject to change without notice. See the back cover for information about ordering replacement parts.

# EXPLODED DRAWING—Model No. IM392012

Rev. 10/92

