

PART LIST—Model No. WL425010

Rev. 1/92

Key No.	Qty.	Description	Key No.	Qty.	Description
1	1	Side Rail/Foam	43	1	Walking Platform
2	1	Side Rail Foam Grip	44	2	Roller Spacer
3	1	Clothes Clip	45	1	Power Cord
4	1	Pulse Earclip	46	2	Shaft Bolt
5	9	Control Knob	47	12	Plastic Fastener
6	1	Programmable Console	48	1	Sensor Wire/Reed Switch
7	1	Speed Pot. Wire	49	1	Magnet
8	1	Power Switch Wire	50	1	Belt
9	1	Incline Cable	51	1	Front Roller/Pulley
10	1	Safety Key/Clip	52	1	Motor Tension Spring
11	1	Console	53	1	Motor Tension Washer
12	1	Electronic Monitor	54	1	J-Bolt
13	1	Incline Indicator	55	3	Adjustment Washer
14	2	Monitor Screw	56	1	Front Roller Adjustment Bolt
15	3	Small Screw	57	6	Platform Screw
16	1	Handrail Endcap	58	2	Wheel Locknut
17	1	Handrail Foam Grip	59	2	Wheel
18	1	Short Side Rail Bolt	60	2	Wheel Bolt
19	1	Upright Post	61	1	Incline Leg
20	1	Lock Knob	62	2	Incline Leg Mounting Bolt
21	1	Lock Knob Washer	63	2	U-Nut
22	4	Pivot Washer	64	1	Right Foot Rail
23	1	Pivot Bolt	65	1	Frame
24	1	Pivot Nut	66	2	Rear Leg Endcap
25	5	Motor Mount Nut	67	1	Ground Washer
26	4	Motor Mount Washer	68	2	Roller Guard
27	1	Pulley/Flywheel/Fan	69	1	Rear Roller
28	1	Safety Cover	70	1	Right Endcap
29	1	Motor	71	2	Rear Roller Adjustment Bolt
30	4	Motor Mount Bolt	72	1	Allen Wrench
31	1	Motor Mount Bracket	73	1	Wrench Clip
32	1	Grommet	74	1	Left Endcap
33	1	Controller	75	1	Left Foot Rail
34	4	Rear Leg/Guard Screw	76	1	Side Rail Nut
35	1	Lift Cylinder Release	77	1	Side Rail Bolt
36	1	E-Clip	78	4	Hood Screw
37	1	Cylinder Mount Bracket	79	1	Motor Hood/Decal
38	1	Lift Cushion	80	4	Hood Mount Anchor
39	1	Lift Cylinder	81	1	Walking Belt
40	1	Cylinder Pin	82	7	Screw
41	1	Cotter Pin	#	1	Monitor Operation Guide
42	1	Circuit Breaker	*#	1	Owner's Manual

Note: "*" indicates a non-illustrated part. Specifications are subject to change without notice. See the back cover for information about ordering replacement parts.

