

PART LIST—Model No. NEL90950

R1107A

Key No.	Qty.	Description	Key No.	Qty.	Description	Key No.	Qty.	Description
1	1	Frame	47	1	Resistance Motor	90	1	M6 x 38mm Bolt
2	1	Rear Stabilizer	48	1	Power Board Cover	91	1	Magnet Bracket Bolt
3	1	Right Upright	49	1	Power Board	92	36	M4 x 16mm Screw
4	1	Left Upright	50	1	Power Board	93	1	M6 x 8mm Button Screw
5	1	Incline Ramp			Bracket			
6	1	Console Frame	51	1	Idler Pulley Bracket	94	8	M8 Washer
7	2	Pivot Arm	52	1	Reed Switch Clamp	95	2	M8 x 25mm Washer
8	1	Power Cord	53	1	Reed Switch	96	3	M8 x 9.5mm Screw
9	1	Right Handlebar	54	2	Pillow Block Set	97	5	M5 x 16mm Bolt
10	1	Left Handlebar	55	2	Bearing Block Set	98	2	M8 x 23mm Washer
11	1	Right Pedal Arm	56	4	Crank Arm Bushing	99	4	M8 x 28mm Washer
12	1	Left Pedal Arm	57	4	Pulley Spacer	100	2	Wave Washer
13	1	Right Pedal	58	1	Crank Spacer	101	12	M8 Split Washer
14	1	Left Pedal	59	4	Ramp Bushing	102	13	M8 Nylon Locknut
15	2	Pivot Shaft	60	4	Incline Motor Spacer	103	2	Large Snap Ring
16	6	M4 Star Washer	61	4	Pedal Wheel	104	2	M4 x 12mm Round Head Screw
17	1	Console			Bushing			
18	1	Hand Grip Pulse Sensor	62	4	Pivot Bushing	105	8	M4 x 25mm Screw
			63	2	Inner Upright Cover	106	8	M4 x 16mm Round Head Screw
19	1	Rear Base Plate	64	2	Pivot Arm Cover			
20	1	Front Base Plate	65	1	Magnet	107	2	Bolt Set
21	1	Right Rear Side Shield	66	1	Wedge	108	4	M8 x 56mm Button Screw
			67	1	Incline Reed Switch			
22	1	Left Rear Side Shield	68	1	Power Receptical	109	1	Reed Switch Plate
			69	1	Belt	110	4	M8 x 68mm Button Screw
23	1	Right Front Side Shield	70	1	Grommet			
			71	2	Hairpin	111	8	M4 x 12mm Screw
24	1	Left Front Side Shield	72	2	Snap Ring	112	4	M8 x 76mm Button Bolt
			73	1	Flywheel Spacer			
25	1	Front Cover	74	2	Outer Upright Cover	113	2	M8 x 20mm Button Screw
26	1	Right Foot Rail	75	1	Upper Wire Harness			
27	1	Left Foot Rail	76	1	Extension Wire	114	2	M6 Nut
28	1	Upper Ramp Cap			Harness	115	4	M6 x 10mm Button Screw
29	4	Pivot Shaft Sleeve	77	1	Lower Wire Harness			
30	4	Handle Bar Cover	78	1	Lower Ramp Cap	116	5	M4 x 19mm Screw
31	4	Frame Endcap	79	4	M5 Nylon Locknut	117	2	M4 x 30mm Screw
32	2	Frame Cushion	80	2	M8 x 45mm Button	118	1	Short Clevis Pin
33	4	Leveling Foot			Screw	119	1	Long Clevis Pin
34	2	Wheel	81	4	M8 x 25mm Button	120	2	Foam Grip
35	2	Pedal Wheel			Screw	121	1	Left Pedal Insert
36	1	Flywheel	82	4	M5 Washer	122	1	Right Pedal Insert
37	1	Pulley	83	2	Flange Screw	123	4	M4 x 14mm Screw
38	1	Right Crank Arm	84	2	M8 x 52mm Button	124	2	Handlebar Endcap
39	1	Left Crank Arm			Screw	#	2	Hex Key
40	1	Incline Axle	85	2	M8 x 41mm Button	#	1	Grease
41	1	Pulley Axle			Screw	#	1	Teflon® Lubricant Packet
42	1	Lift Motor	86	2	Large Wave Washer			
43	1	"C" Magnet	87	2	M8 x 16mm Washer	#	1	User's Manual
44	1	Spring	88	6	M8 x 23mm Flat			
45	1	Small Pulley			Head Screw			
46	1	Idler Pulley	89	1	M8 x 57mm Screw			

Note: # indicates a non-illustrated part. Specifications are subject to change without notice. See the back cover of this manual for information about ordering replacement parts.

EXPLODED DRAWING—Model No. NEL90950

R1107A



