


Unpack Your eMotion™

Unpack your eMotion™ exerciser where you intend to use it. Please retain all packing materials and verify the parts with those shown below. For easier identification, the hardware is shown actual size.



Contents of Box

- A Upper Frame Assembly and Rear Frame Support with Rollers
- B Information Packet
- C Front Frame Support
- D 60mm Carriage Bolts (4)
- E Leg Tubes with Foot Pedals (2)
- F Arm Handles (2)
- G 13mm Phillips Head Screws (4)
- H Large Lock Nuts (4)
- I Steel Washers (4)
- J 16mm Long Button Head Screws (4)
- K Hex Key Wrench
- L 52mm Pivot Sleeve (4)
- M Screwdriver/Wrench Combination Tool
- N Detent Pin (2)
- O Electronics Package

