

PART LIST—Model No. NTL29105.0

R0106B

To locate the parts listed below, see the EXPLODED DRAWING on pages 30 and 31.

Key No.	Qty.	Description	Key No.	Qty.	Description
1	1	Motor Hood	54	1	High Voltage Decal
2	2	Hood Screw	55	4	Motor Bolt
3	2	Sensor Bracket Screw	56	1	Power Supply Box
4	4	Hood Mounting Clip	57	1	Power Wire Harness
5	2	Rear Foot	58	1	Wiring Plate, Right
6	6	Platform Screw	59	1	#10 Screw Allen Wrench
7	6	Isolator	60	1	CD Holder Foam, Long
8	2	Breaker Screw	61	1	Incline Motor
9	6	Isolator Nut	62	1	Incline Motor Bolt, Lower
10	1	Foot Rail, Left	63	1	Cup Holder Foam
11	2	Foot Rail Inset	64	2	Wheel Bolt
12	4	Pulse Sensor Base	65	2	Wheel
13	1	Front Endcap, Left	66	2	Incline Leg Bolt
14	1	Belt Tension Bolt	67	2	Incline Leg Nut
15	4	Pulley Screw	68	4	Mounting Clips
16	2	Outlet Bolt	69	1	Incline Leg
17	4	Power Box Screw	70	1	Walking Platform
18	1	Power Cord Bracket	71	1	Walking Belt
19	2	Bracket Screw	72	1	Front Endcap, Right
20	1	Motor Belt	73	1	Front Roller/Pulley
21	1	Idler Bolt	74	18	Foot Rail Screw/Power Box Screw
22	2	Outlet Nut	75	1	Foot Rail, Right
23	1	Belt Tension Nut	76	1	Frame
24	2	Frame Inserts	77	14	Small Insert
25	1	Belt Tension Wheel	78	10	Endcap Screw
26	1	Front Roller Bolt	79	1	Rear Roller
27	2	Lock Washer	80	2	Roller Guard Screw
28	2	Ground Nut	81	1	Roller Guard, Right
29	1	Static Decal	82	2	Rear Roller Adj. Bolt
30	1	Belt Tension Spring	83	1	Roller Guard, Left
31	4	Motor Nut	84	1	Rear Endcap, Left
32	1	Belt Tension Bracket	85	1	Cup Holder Insert
33	1	Speed Disk	86	1	CD Holder Insert
34	3	Speed Disk Screw	87	1	Key/Clip
35	2	Sensor Screw	88	1	Console
36	1	Speed Sensor	89	1	Console Base
37	1	CD Holder Foam	90	2	Handrail Endcap
38	1	Sensor Bracket	91	1	Handrail
39	2	Sensor Bracket Nut	92	13	Console Back Screw
40	1	Motor	93	4	Console Back Screw
41	1	Motor Isolator	94	1	Console Back
42	2	Incline Motor Nut, Top/Idler Nut	95	1	Upright, Right
43	1	Incline Motor Bolt, Top	96	8	Upright Bolt
44	4	Pulse Sensor Screw	97	1	Upright, Left
45	1	7" Filter Wire	98	4	Pulse Sensor
46	2	Hood Bracket, Front	99	8	Handrail Bolt
47	1	On/Off Circuit Breaker	100	1	Upright Wire Harness
48	1	Power Cord	101	1	Controller Wire
49	1	Power Cord Outlet	102	1	Allen Wrench, 7/32"
50	2	Wheel Spacer	103	1	Allen Wrench, 5/16"
51	1	Warning Decal	104	1	Tie Block
52	4	Motor Bushing	105	2	Belt Guide Bolt
53	4	Motor Mount Washer	106	1	Voltage Decal, Small

Key No.	Qty.	Description	Key No.	Qty.	Description
107	5	Cable Tie	123	1	Ferrite Clamp
108	2	Belt Guide	#	1	28" Wire Harness, 3 Wire
109	1	Motor Controller Box	#	1	25" Wire Harness, 5 Wire
110	1	Rear Endcap, Right	#	1	22" Wire Harness
111	1	Motor Flywheel	#	1	20" Wire Harness, 8 Wire
112	1	Motor Pulley	#	1	20" Wire Harness, 3 Wire
113	2	Rear Foot Locknut	#	1	12" Green Wire, 2 Ring
114	1	Foam Grip, Left	#	1	12" Green Wire, F/M Ring
115	2	Rear Roller Adj. Washer	#	1	4" Green Wire F/Ring, 14Ga
116	2	Wheel Washer	#	1	4" Black Wire, 2F
117	1	Right Foam Grip	#	1	4" White Wire, M/F
118	2	Nylon Incline Washer	#	1	Wire w/Resistor
119	2	Ground Screw	#	1	User's Manual
120	2	Hood Bracket, Back			
121	1	Incline Motor Spacer			
122	1	iFIT Cable			

These parts are not illustrated

ORDERING REPLACEMENT PARTS

To order replacement parts, see the front cover of this manual. When ordering parts, please be prepared to provide the following information:

- the MODEL NUMBER OF THE PRODUCT (NTL29105.0)
- the NAME OF THE PRODUCT (NordicTrack S3000 treadmill)
- the SERIAL NUMBER OF THE PRODUCT (see the front cover of this manual)
- the KEY NUMBER AND DESCRIPTION OF THE PART(S) (see the PART LIST on pages 28 and 29 and the EXPLODED DRAWING on pages 30 and 31).

EXPLODED DRAWING—Model No. NTL29105.0

R0106B



