

PART LIST—Model No. PETL5013.4

R0405A

To locate the parts listed below, see the EXPLODED DRAWING attached in the centre of this manual.

Key No.	Qty.	Description	Key No.	Qty.	Description
1	2	Foot Rail Cover	51	1	Right Front Endcap
2	1	Left Foot Rail	52	1	Walking Belt
3	1	Left Front Endcap	53	1	Walking Platform
4	2	Belt Guide	54	1	Frame
5	4	Belt Guide Screw	55	2	Platform Nut
6	45	3/4" Screw	56	1	Right Foot Rail
7	1	Left Decal Holder	57	1	Rear Roller
8	2	Cushion Spring	58	1	Right Rear Foot
9	4	Catch Screw/Isolator Screw	59	1	Allen Wrench
10	1	Warning Decal	60	2	Rear Roller Adj. Bolt
11	2	Rear Platform Bolt	61	2	Rear Roller Washer
12	1	Latch Catch	62	1	Right Rear Endcap
13	2	Spring Bolt (Bottom)	63	1	Left Rear Foot
14	2	Spring Bolt (Top)	64	1	Left Rear Endcap
15	2	Front Isolator	65	2	Small Endcap Screw
16	2	Front Platform Screw	66	2	Endcap Washer
17	2	Platform Pivot Bolt	67	4	Front Endcap Screw
18	1	Magnet	68	1	Left Handrail
19	2	Lift Frame Spacer	69	1	Left Upright
20	1	Motor Pivot Bolt	70	1	Latch Knob
21	7	Wheel Nut	71	2	1" Bolt
22	2	Frame Spacer	72	4	Internal Washer
23	1	Reed Switch Clip	73	1	Left Handrail Bracket
24	1	Reed Switch	74*	1	Latch Assembly
25	1	Reed Switch Screw	75	1	Latch Knob Sleeve
26	1	Lift Frame	76	1	Latch Pin Collar
27	1	Motor Tension Nut	77	1	Latch Spring
28	1	Motor	78	1	Motor Sleeve
29	1	Pulley/Flywheel/Fan	79	1	Pin Clip
30	1	Motor Belt	80	1	Latch Pin
31*	1	Motor Assembly	81	1	Right Handrail
32	1	Motor Tension Bolt	82	1	Right Upright
33	1	Motor Tension Washer	83	1	Wire Harness
34	1	Motor Star Washer	84	1	Left Accessory Tray
35	2	Motor Bracket Bolt	85	1	Console Base
36	7	Small Screw	86	4	Fan Screws
37	2	Ground Wire	87	1	Fan
38	1	Transformer	88	1	Console
39	1	Hood	89	1	Fan Housing
40	1	Controller	90	1	Right Accessory Tray
41	2	Power Cord	91	1	Key/Clip
42	1	iFIT.com Wire Nut	92	2	1 1/4" Screw
43	1	iFIT.com Wire	93	2	2" Sliver Screw
44	1	Receptical	94	1	Access Door
45	2	Static Decal	95	1	Console Back
46	1	On/Off Switch	96	1	Tie Holder
47	5	Belly Pan Screw	97	1	Releasable Tie
48	1	Belly Pan	98	1	Plastic Tie
49	1	Photo Switch Wire	99	2	Base Endcap
50	1	Filter Wire	100	2	Front Base Pad

Key No.	Qty.	Description
101	2	Clevis Pin
102	2	Hairpin Cotter
103	4	Cage Nut
104	4	1 1/4" Bolt
105	2	Rear Base Pad
106	2	Wheel Housing
107	2	Wheel Bolt
108	2	Wheel
109	1	Base
110	1	Incline Stop Bracket
111	2	Incline Motor Bolt
112	1	Incline Motor
113	1	Right Handrail Bracket
114	1	Right Decal Holder
115	1	5/16" Allen Wrench
116	1	iFIT.com Cable
117	1	Motor Bracket
118	2	J-Nut
119	1	Front Roller Adj. Bolt
120	1	Front Roller/Pulley
121	4	Long Belly Pan Screw
122	1	Controller Wire
123	2	Rear Roller Star Washer
124	1	Pulse Wire
125	1	Pulse Bar
126	2	Caution Decal
127	2	Nylon Washer
128	2	Motor Pivot Bushing

Key No.	Qty.	Description
129	1	Electronics Bracket
130	1	Choke
131	1	Filter
132	1	Circuit Breaker
133	1	Motor Fan
134	1	Photo Switch Washer
135	1	Splitter
136	1	Optic Disk
137	1	Photo Switch
138	1	Photo Switch Nut
139	1	Photo Switch Bolt
#	1	8" Green Wire, F/Ring
#	1	4" Green Wire, F/Ring
#	1	18" Blue Wire, 2 F
#	1	16" Blue Wire, M/F
#	1	10" Blue Wire, 2 F
#	1	4" Blue Wire, 2 F
#	1	20" Wire Harness
#	1	10" White Wire, 2 F
#	1	6" White Wire, 2 F
#	1	12" Red Wire, M/F
#	1	User's Manual

* Includes all parts shown in the box


These parts are not illustrated

Specifications are subject to change without notice.

EXPLODED DRAWING—Model No. PETL5013.4

R0405A

To identify the parts shown on this EXPLODED DRAWING, see the PART LIST on pages 30 and 31 of the user's manual.



EXPLODED DRAWING—Model No. PETL5013.4

R0405A

