

# PART LIST—Model No. PETL51305.2

R0106A

To locate the parts listed below, see the EXPLODED DRAWING attached in the centre of this manual.

Key No.	Qty.	Description	Key No.	Qty.	Description
1	1	Left Foot Rail	51	1	Circuit Breaker
2	8	Foot Rail Screw	52	1	Receptical
3	2	Pulse Receiver Screw	53	3	Belly Pan Clip
4	2	Isolator Decal	54	1	Belly Pan
5	1	Catch	55	1	Releasable Tie
6	2	Front Isolator	56	1	Photo Switch Wire
7	2	Isolator	57	1	Tie Holder Clamp
8	1	Pulse Receiver	58	9	Cable Tie
9	2	Isolator Bracket Cover	59	1	Frame
10	2	Isolator Screw	60	1	Right Rear Foot
11	1	Roller Bushing	61	2	Motor Tension Bolt
12	2	Isolator Bolt	62	2	Rear Roller Adj, Bolt
13	1	Walking Platform	63	1	Rear Roller
14	2	Belt Guide	64	1	Hex Key
15	4	Belt Guide Screw	65	1	Chest Pulse Sensor
16	2	Walking Platform Screw, Rear	66	1	Left Rear Foot
17	2	Frame Pivot Bolt	67	1	Right Foot Rail
18	1	Front Roller/Pulley	68	1	Walking Belt
19	1	Magnet	69	1	Latch Warning Decal
20	8	Nut	70	1	Motor Plate
21	2	Pivot Spacer	71	2	Motor Tension Washer
22	1	Reed Switch	72	1	Motor Star Washer
23	2	Motor Tension Nut	73	2	Small Star Washer
24	1	Reed Switch Clip	74	1	Wire Harness
25	2	Shock Pin	75	1	Motor Pivot Nut
26	1	Motor Bracket	76	1	Right Handrail
27	1	Right Bottom Handgrip	77	1	Ground Wire
28	1	Motor Belt	78	2	Small Nut
29	1	Filter	79	1	Lift Motor Bolt, Bottom
30	1	Transformer	80	4	Extension Leg Bolt
31	1	Right Top Handgrip	81	1	Left Top Handgrip
32	1	Drive Motor	82	1	Latch Assembly
33	1	Lift Frame	83	1	Controller Wire
34	1	Static Decal	84	1	Motor Pivot Bolt
35	2	Walking Platform Nut	85	1	Front Roller Nut
36	2	Plastic Bushing	86	2	Upright Endcap, Large
37	1	Incline Motor	87	1	Console Bracket
38	3	Incline Bolt	88	2	Rear Roller Bracket
39	4	1/4" Washer	89	4	Console Bolt
40	6	Base Pad Screw	90	2	Wheel Bolt
41	1	Front Roller Adj. Bolt	91	2	Caution Decal
42	2	Walking Platform Screw, Front	92	1	iFIT.com Wire
43	1	Left Bottom Handgrip	93	1	Hood
44	54	Screw	94	2	Wheel
45	1	Shock	95	2	Upright Endcap, Small
46	1	Controller Bracket	96	1	Access Door
47	1	On/Off Switch	97	1	Upright Base
48	1	Controller	98	1	Photo Switch
49	1	Power Cord	99	6	Base Pad
50	1	Power Cord Adapter	100	2	Small Bolt

Key No.	Qty.	Description	Key No.	Qty.	Description
101	1	Console Base, Top	120	1	Roller Ground Wire
102	1	Optic Disk	121	1	Lift Frame Ground Wire
103	1	Console Back	122	1	5/32" Hex Key
104	1	Key Clip	123	8	Hood Screw/Endcap Screw
105	1	Left Handrail	124	3	Tie
106	1	Console Fan	125	2	Rear Roller Star Washer
107	1	Console	#	2	4" Black Wire, F/F
108	15	Screw	#	1	18" Red Wire, M/F
109	2	Motor Bracket Bolt	#	1	16" Black Wire, M/F
110	1	Pulse Bar	#	1	12" Blue Wire, F/F
111	1	Right Accessory Tray	#	1	6" Blue Wire, M/F
112	1	Left Accessory Tray	#	1	10" Blue Wire, F/F
113	4	Internal Star Washer	#	1	6" Green/Yellow Wire, F/R
114	1	Latch Insert	#	1	4" Green/Yellow Wire, F/R w/Torrid
115	2	Extension Leg	#	2	10" White Wire, F/F
116	2	Base Endcap	#	1	User's Manual
117	1	Chest Pulse Sensor Strap			
118	3	Belly Pan Screw			
119	1	Large Belly Pan Screw			

#These parts are not illustrated.  
Specifications are subject to change without notice.

# EXPLODED DRAWING—Model No. PETL51305.2

R0106A

To identify the parts shown on this EXPLODED DRAWING, see the PART LIST on pages 30 and 31 of the User's Manual.



