


PART LIST—Model No. TLTL23040

R495A

Key No.	Qty.	Description	Key No.	Qty.	Description
1	1	Left Upright/Handrail	58	2	Incline Leg Washer
2	4	Pulley Nut	59	9	3/8" Nut
3	6	Pulley Washer	60	2	Incline Leg Cap
4	4	Pulley	61	2	Incline Leg Pad
5	4	Pulley Bushing	62	1	Incline Leg
6	2	Long Pulley Spacer	63	1	Controller
7	2	Upright Cap	64	1	Controller Plate
8	1	24" Cable Loom	65	6	Endcap Screw
9	2	1/4" x 2" Bolt	66	1	Cable Tie Clip
10	1	Safety Key/Clip	67	1	Cable Tie
11	2	Crossbar Cover	68	1	Right Rear Endcap
12	4	3/8" x 3/4" Bolt	69	4	Roller Guard
13	1	20" Wire Harness	70	1	Video Cable
14	1	Crossbar	71	2	Rear Roller Adjustment Bolt
15	2	1/4" x 1 3/4" Bolt	72	1	3/16" Allen Wrench
16	2	Upper Body Cord	73	2	Upper Body Cord Handle
17	1	70" Wire Harness	74	1	Rear Roller
18	2	Short Pulley Spacer	75	1	Left Rear Endcap
19	2	Upper Body Cord Grip	76	1	Left Foot Rail
20	1	Power Board	77	6	Platform Screw
21	1	Console	78	1	Walking Platform
22	1	Right Upright/Handrail	79	1	Choke Bracket
23	1	Left Front Endcap	80	3	Star Washer
24	1	Circuit Breaker	81	1	Choke
25	1	Power Cord	82	1	Motor Tension Washer
26	1	Optic Switch Wire Harness	83	1	Motor Tension Nut
27	1	Power Board Plate	84	2	Cord Guard
28	1	Wrench Clip	85	1	Motor Mount Bracket
29	1	Front Roller/Pulley	86	1	Pulley/Flywheel/Fan
30	4	Upright Cage Nut	87	1	Motor Belt
31	4	Plastic Stand-Off	88	2	Motor Bolt
32	1	Front Roller Adjustment Bolt	89	1	Motor
33	3	Roller Adjustment Washer	90	2	Motor Nut
34	1	Front Right Endcap	91	1	Motor Pivot Bolt
35	2	Wheel Bolt	92	1	Optic Switch Bolt
36	2	Wheel Bushing	93	1	Optic Switch
37	2	Front Wheel	94	1	Optic Switch Bracket Nut
38	2	Wheel Nut	95	1	Optic Disk
39	1	Right Foot Rail	96	1	Optic Switch Bracket
40	2	12" Cable Loom	97	1	Optic Switch Nut
41	4	Upright Washer	98	1	Right Rear Incline Cover
42	4	Upright Bolt	99	1	Left Rear Incline Cover
43	6	Small Screw	100	2	Round Plug
44	2	Upright Spacer	101	2	Resistance Cord Clip
45	1	Belt Guide	102	1	Fat Burn Videocassette
46	10	Screw	103	1	Aerobic Videocassette
47	16	Safety Cover Screw	104	1	Cross Training Videocassette
48	1	Frame	105	1	On/Off Switch
49	1	Safety Cover	106	2	Handrail Endcap
50	1	Walking Belt	#	1	14" Black Wire, 2 Female
51	2	Spring Screw	#	1	9" Black Wire, Male/Female
52	1	Power Cord Grommet	#	1	4" Black Wire, 2 Female
53	5	Incline Leg Bolt/Motor Lock Bolt	#	1	14" White Wire, 2 Female
54	2	Incline Leg Spring	#	1	8" White Wire, Male/Female
55	10	Utility Screw	#	1	8" Blue Wire, 2 Female
56	2	Foot Incline Latch	#	1	14" Red, White, Black Wire
57	4	Incline Leg Spacer	#	1	8" Green Ground Wire
58	2	Incline Leg Washer	#	1	Owner's Manual

EXPLODED DRAWING—Model No. TLTL23040

R495A



Specifications are subject to change without notice.