


EXPLODED DRAWING—Model No. WC705023

R1294A

© 1994 Proform Fitness Products, Inc., a Subsidiary of Weider Health and Fitness, Inc.



MODEL NUMBER: WC70502
VERSION: 03
PRODUCT NAME: CSA CROSSWALK
PRODUCT DESC: TREADMILL

MODEL/PART BOOK LISTING

PAGE 1
IN1023P1
RUN DATE: 12/15/94
RUN TIME: 15:20:42

KEY NUMBER	PART NUMBER	DESCRIPTION	QUANTITY
.	.	CSA CROSSWALK	0
1	110824	LT UPPER BODY ARM ASSY.	1
.	.	111826 LT UPPER BODY ARM	1
.	.	110194 FOAM GRIP	1
.	.	110823 ARM HOUSING	1
2	110825	RT UPPER BODY ARM ASSY.	1
.	.	111828 RT UPPER BODY ARM	1
.	.	110194 FOAM GRIP	1
.	.	110823 ARM HOUSING	1
3	111998	RELAY	1
4	112589	PULSE/CLOTHES CLIP ASSY.	1
5	106337	SAFETY KEY/CLIP	1
6	108080	SCREW	15
7	116252	CONSOLE ASSEMBLY	1
.	.	111095 CONSOLE	1
.	.	088003 INCLINE LEVER	1
.	.	110255 REPLACEMENT INSTR.	1
8	110000	SPEED CONTROL KNOB	1
9	109791	INCLINE LEVER W/RI	1
.	.	088003 INCLINE LEVER	1
.	.	109783 REPLACEMENT INSTR.	1
10	112969	UPRIGHT	1
11	112138	LOCK PIN	1
12	116251	CONTROLLER W/RI	1
.	.	112921 CONTROLLER	1
.	.	116250 REPLACEMENT INSTR.	1
13	108404	MOTOR HOOD SCREW	4
14	118307	MOTOR HOOD W/DECALS	1
.	.	113771 MOTOR HOOD	1
.	.	110081 MOTOR HOOD DECAL	1
.	.	118560 WIRE DIAGRAM DECAL	1
15	109511	RESISTANCE CONTROL	1
16	110193	FRICTION BRACKET	2
17	014087	FLAT WASHER	2
18	120527	PLATFORM SHIM ASSEMBLY	2
.	.	118127 PLATFORM SHIM	1
.	.	107109 NAIL	3
.	.	120524 REPLACEMENT INSTR.	1
19	112286	FRICTION PLATE	2
20	112012	INCLINE CABLE	1
21	012082	TENSION/WHEEL NUT	3
22	104514	TENSION SPRING	1
23	014041	TENSION WASHER	2
24	013207	CARRIAGE BOLT	1
25	113106	MOTOR HOOD BRACKET	3
26	109382	CIRCUIT BREAKER	1
27	019084	GROMMET	1
28	120630	BELT GUIDE SCREW	4
29	031238	CHOKE	1
30	106903	POWER CORD	1
31	013282	MOTOR PAN SCREW	8
32	114316	MOTOR PAN	1
33	012108	LOCK NUT	3
34	052014	FRONT WHEEL	2

MODEL NUMBER: WC70502
VERSION: 03
PRODUCT NAME: CSA CROSSWALK
PRODUCT DESC: TREADMILL

MODEL/PART BOOK LISTING

PAGE 2
INI023P1
RUN DATE: 12/15/94
RUN TIME: 15:20:42

KEY NUMBER	PART NUMBER	DESCRIPTION	QUANTITY
35	013564	WHEEL BOLT	2
36	088004	SHOCK RELEASE	1
37	115672	SHOCK BRACKET	1
38	054016	E-CLIP	1
39	059019	SHOCK CUSHION	1
40	118391	INCLINE SHOCK W/RI	1
	.	112582 INCLINE SHOCK	1
	.	109785 REPLACEMENT INSTR.	1
41	106616	SHOCK PIN	1
42	106334	COTTER PIN	1
43	101263	MOTOR PIVOT BOLT	1
44	116812	MOTOR MOUNT PLATE W/RI	1
	.	117161 MOTOR MOUNT PLATE	1
	.	116809 REPLACEMENT INSTR.	1
45	115706	MOTOR MOUNT ISOLATOR	2
46	118450	MOTOR W/RI	1
	.	115386 MOTOR	1
	.	116809 REPLACEMENT INSTR.	1
46A	118451	MOTOR/PULY/FLYWHL/FAN ASY	1
	.	115386 MOTOR	1
	.	108276 PULY/FLYWHL/FAN	1
	.	116809 REPLACEMENT INSTR.	1
47	100994	MOTOR MOUNTING BOLT	2
48	108276	PULLEY/FLYWHEEL/FAN ASSY.	1
49	116506	FOOT RAIL	2
50	031182	MOTOR GROUND WIRE	1
51	013303	INCLINE LEG BOLT	2
52	113412	INCLINE LEG	1
53	NSP	FRAME	1
54	118351	WALKING PLATFORM W/RI	1
	.	118128 WALKING PLATFORM	1
	.	118352 REPLACEMENT INSTR.	1
55	100691	PLATFORM SCREW	6
56	014127	ROLLER ADJUSTMENT WASHER	3
57	112609	FRONT ROLLER ADJ. BOLT	1
58	117273	FRONT ROLLER/PULLEY ASSY.	1
59	110821	WALKING BELT W/RI	1
	.	025058 WALKING BELT	1
	.	110585 REPLACEMENT INSTR.	1
60	109250	COVER MOUNTING SCREW	2
61	110407	REAR LEG PAD	1
62	112293	RIGHT ENDCAP	1
63	013162	SMALL SCREW	4
64	105444	REAR ROLLER ADJ. BOLT	2
65	016028	WRENCH CLIP	2
66	045010	ALLEN WRENCH	1
67	110245	REAR ROLLER W/RI	1
	.	070084 REAR ROLLER	1
	.	103847 REPLACEMENT INSTR.	1
68	010206	ROLLER GUARD	3
69	112965	SHORT UPRIGHT COVER	1
70	109265	BELT GUIDE	2
71	112292	LEFT ENDCAP	1
72	033066	MAGNET	1

MODEL NUMBER: WC70502
VERSION: 03
PRODUCT NAME: CSA CROSSWALK
PRODUCT DESC: TREADMILL

MODEL/PART BOOK LISTING

PAGE 3
IN1023P1

RUN DATE: 12/15/94
RUN TIME: 15:20:42

KEY NUMBER	PART NUMBER	DESCRIPTION	QUANTITY
73	115572	REED SWITCH/SENSOR WIRE	1
74	113838	MECHANISM COVER	1
75	106939	BELT	1
76	016055	WIRE CLIP	6
77	017088	LOCK KNOB	1
78	014156	LOCK KNOB/CONTROL WASHER	2
79	109517	FRICTION COVER	1
80	109515	PIVOT BOLT	1
81	112023	UPPER BODY ARM FOAM GRIP	2
82	101049	MOTOR HOOD BRACKET SCREW	3
83	105477	MOTOR NUT	2
84	111869	CAGE NUT	1
85	111114	SPRING CLIP	1
86	112958	LONG UPRIGHT COVER	1
.	.	NON-ILLUSTRATED PARTS:	0
#	033021	BATTERY (1.5 VOLT)	2
#	110402	BATTERY COVER (SNAP-ON)	1
#	110196	FRAME DECAL	2
#	118560	WIRE DIAGRAM DECAL	1
#	112029	WIRE HARNESS, PWR TO UPRT	1
#	112084	JUMPER WIRE, WHITE, 2	1
.	.	WIRE, 2 FEMALE ENDS, 1	0
.	.	MALE END, 1 8"L, 1 4"L	0
#	112083	JUMPER WIRE, BLUE, 2	1
.	.	FEMALE ENDS, 8" L	0
#	114105	JUMPER WIRE, M/F, 4" L	1
#	114106	PIGTAIL WIRE, 2 WIRE, 4"L	1
.	.	2 MALE ENDS, 1 FEMALE, BLK	0
#	119180	OWNER'S MANUAL	1
#	119230	OWNER'S MANUAL, FRENCH	1
.	119181	LITERATURE PACKET	1
.	.	119180 OWNER'S MANUAL	1
.	.	119230 OM, FRENCH	1
.	.	112589 PULSE/CLOTHES CLIP	1
.	.	017088 LOCK KNOB	1
.	.	070307 SILICONE	1
.	.	112817 HARDWARE KIT	1
.	.	016028 WRENCH CLIP	1
.	.	045010 ALLEN WRENCH	1
.	.	014156 LOCK KNOB WASHER	1