

# PART LIST—Model No. WEBE1441DVD.0

R0907A

Key No.	Qty.	Description	Key No.	Qty.	Description
1	1	Top Frame	32	1	Cable
2	1	Bottom Frame	33	2	Cable Clip
3	1	Backrest Frame	34	2	Handle
4	1	Backrest	35	4	Bungee Cord
5	1	Adjustment Leg	36	2	M8 Bright Zinc Nylon Locknut
6	1	Stabilizer	37	2	M10 x 30mm Bolt
7	1	Support Leg	38	2	M8 x 90mm Bolt
8	1	Foot Plate	39	4	M6 Washer
9	2	M10 x 20mm Bolt	40	3	M8 x 52mm Bolt
10	1	Bungee Bracket	41	2	M10 x 63mm Screw
11	1	Backrest Bracket	42	1	M10 x 175mm Bolt
12	4	50mm Outer Cap	43	1	M10 x 80mm Bolt
13	2	50mm Inner Cap	44	1	Short Knob
14	2	25mm Round Inner Cap	45	7	M10 Nylon Locknut
15	2	Handgrip	46	7	M8 Black Zinc Nylon Locknut
16	2	Foam Pad	47	6	ST4 x 20mm Screw
17	4	L-Pin	48	1	Adjustment Bracket
18	2	Pulley Housing	49	2	56/45mm Bushing
19	2	70mm Pulley	50	2	38mm Round Inner Cap
20	1	90mm Pulley	51	4	M6 x 38mm Bolt
21	1	Right 38/32mm Bushing	52	2	M10 Ball Head Nut
22	1	M10 x 45mm Bolt	53	2	M8 x 85mm Bolt
23	6	Small Bushing	54	3	M8 Black Zinc Washer
24	2	Small Wheel	55	2	M8 Bright Zinc Washer
25	2	Big Bushing	56	2	M10 Washer
26	2	Big Wheel	57	1	Left 38/32mm Bushing
27	2	Bumper	58	1	Long Knob
28	2	32mm Round Inner Cap	*	—	User's Manual
29	1	Handlebar	*	—	Exercise Guide
30	2	60mm Eyebolt	*	—	Exercise DVD
31	2	108mm Eyebolt			

Note: Specifications are subject to change without notice. See the back cover of this manual for information about ordering replacement parts. \*These parts are not illustrated.

# EXPLODED DRAWING—Model No. WEBE1441DVD.0

R0907A

