

PART LIST—Model No. WL078020



Rev. 8/92

Key No.	Qty.	Description	Key No.	Qty.	Description
1	1	Console	32	4	Handlebar Bushing
2	1	Resistance Knob	33	2	Mount Screw
3	1	Handlebar Pushnut	34	1	Right Side Shield
4	4	Screw	35	1	Tension Spring Assembly
5	1	Seat	36	1	Link Arm Bolt
6	1	Seat Post	37	2	Link Arm
7	4	Seat Nut	38	2	Pedal Shaft
8	1	Seat Pin	39	1	Magnet
9	2	Handlebar	40	2	Foam Grip
10	2	Pedal	41	1	Tension Buckle
11	1	Frame	42	1	Roller Axle
12	2	Stabilizer Endcap	43	2	Roller Bushing
13	1	Stabilizer	44	1	Reed Switch Screw
14	4	Stabilizer Bolt	45	1	Seat Post Glide
15	16	Side Shield Screw	46	1	Sprocket
16	1	Left Side Shield	47	1	Crank Assembly
17	2	Nut	48	2	Outer Pedal Washer
18	2	Flange Nut	49	2	Outer Pedal Nut
19	1	Spacer	50	2	Pedal Cap
20	2	Bearing	51	2	Spring Washer
21	1	Large Spacer	52	2	Pedal Spring
22	1	Small Sprocket	53	1	Reed Switch/Sensor Wire
23	1	Flywheel Axle	54	2	Pedal Washer
24	2	Roller	55	2	Pedal Bushing
25	1	Flywheel	56	2	Shaft Washer
26	1	Chain	57	2	Handlebar Spacer
27	1	Crank	58	2	Link Arm Bushing
28	1	Resistance Strap	59	2	Lock Rod Pushnut
29	1	Tension Buckle	60	1	Console Mount
30	1	Seat Post Collar	61	2	Shaft Nut
31	1	Resistance Cable	#	1	Owner's Manual

Note: "#" indicates a non-illustrated part. See the back cover of this manual for information about ordering replacement parts. Specifications are subject to change without notice.

EXPLODED DRAWING—Model No. WL078020

Rev. 8/92



CRANK ASSEMBLY (47)