

PART LIST—Model No. WL315020

Rev. 6/92

Key No.	Qty.	Description	Key No.	Qty.	Description
1	1	Left Handrail w/Foam Grip	37	3	Roller Adjustment Washer
2	2	Foam Grip	38	1	J-Bolt
3	1	Clothes Clip	39	1	Tension Washer
4	1	Pulse Earclip	40	1	Tension Spring
5	1	Electronic Monitor	41	1	Front Roller/Pulley
6	9	Screw	42	1	Walking Belt
7	1	Speed Control Knob	43	6	Platform Screw
8	2	Short Handrail Bolt	44	1	Belly Pan
9	1	Console	45	4	Hood Anchor
10	1	Incline Indicator	46	1	Frame
11	1	Upright Post	47	1	Walking Platform
12	1	Safety Key/Clip	48	1	Right Foot Rail
13	1	Speed Pot Assembly	49	1	Controller
14	4	Motor Mount Washer	50	1	Choke
15	5	Motor Mount Nut	51	2	Bumper
16	1	Motor	52	1	Right Roller Bracket
17	1	Pulley/Flywheel/Fan	53	2	Rear Roller Adjustment Bolt
18	1	Left Incline Leg	54	1	Allen Wrench
19	4	Motor Mount Bolt	55	1	Wrench Clip
20	1	Motor Mount Swivel Shaft	56	1	Rear Roller
21	1	Right Incline Leg	57	2	Roller Guard
22	1	Pivot Nut	58	1	Left Roller Bracket
23	4	Flat Washer	59	2	Long Handrail Bolt
24	1	Lock Knob Washer	60	2	Handrail Nut
25	1	Lock Knob	61	1	Right Handrail w/Foam Grip
26	1	Pivot Bolt	62	1	Motor Hood w/Decal
27	1	Power Cord	63	1	Left Foot Rail
28	4	Bumper Screw	64	1	Magnet
29	1	Grommet	65	1	Sensor Wire/Reed Switch
30	1	Circuit Breaker	66	1	Belt
31	3	Wire Clip	67	1	On/Off Wire
32	1	Ground Washer	68	2	Hose Clamp
33	12	Plastic Fastener	69	2	Roller Guard Screw
34	2	Swivel Shaft Bolt	70	5	Small Screw
35	2	Hitch Pin	#	1	Owner's Manual
36	1	Front Roller Adjustment Bolt			

Note: "#" indicates a non-illustrated part. Specifications are subject to change without notice. See the back cover for information about ordering replacement parts.

EXPLODED DRAWING—Model No. WL315020

Rev. 6/92

